

Smarter, Greener, Together,

Industrial Automation Headquarters

Delta Electronics, Inc.
Taoyuan Technology Center
No.18, Xinglong Rd., Taoyuan City,
Taoyuan County 33068, Taiwan
TEL: 886-3-362-6301 / FAX: 886-3-371-6301

Wujiang Economic Development Zone Wujiang Giry, Jiang Su Province, People's Republic of China (Post code: 215200) TEL: 86-512-6340-3008 / FAX: 86-769-6340-7290 Asia Delta Electronics (Jiangsu) Ltd. Wujiang Plant 3 1688 Jiangxing East Road,

Delta Greentech (China) Co., Ltd.
238 Min-Xia Road, Pudong District,
ShangHai, P.R.C.
Post code: 201209
TEL: 86-21-586336678 / FAX: 86-21-58630003

Delta Hybrid Energy Saving System HES Series User Manual

Delta Electronics (Japan), Inc.

Tokyo Office 2-1-14 Minato-ku Shibadaimon, Tokyo 105-0012, Japan TEL: 81-3-5733-1111 / FAX: 81-3-5733-1211

Delta Electronics (Korea), Inc. 1511. Syudysan Digital Valley 6-cha, Gasan-dong, 1511. Syudysan Digital Valley 6-cha, Gasan-dong, Geurncheon-gu, Seoul, Korea, 153-704. TEL: 82-2-515-5303 / FAX: 82-2-515-5302

Delta Electronics Int'I (S) Pte Ltd 4 Kaki Bukit Ave 1, #05-05, Singapore 417939 TEL: 65-6747-5155 / FAX: 65-6744-9228

Delta Electronics (India) Pvt. Ltd.
Plot No 43. Sector 35, HSIIDC
Gurgaon, Plv 122001, Havyana, India
TEL: 91-124-4874900 / FAX: 91-124-4874945

Americas

Delta Products Corporation (USA)
Ralegip Office
P.O. Box 12173,5101 Davis Drive,
Research Triangle Park, NC 27709, U.S.A.
TEL: 1-919-767-3800 / FAX: 1-919-767-3800

Delta Greentech (Brasil) S.A

Sao Paulo Office Rua Itapeva, 26 - 3° andar Edificio Itapeva One-Bela Vista 01332-000-São Paulo-SP-Brazil FEL: +55 11 3568-3855 / FAX: +55 11 3568-3865

Delta Electronics (Netherlands) B.V.

Eindhoven Office De Witbogt 20, 5652 AG Eindhoven, The Netherlands TEL: +31 (0)40-8003800 / FAX: +31 (0)40-8003898

"We reserve the right to change the information in this catalogue without prior notice. DELTA_IA-MDS_VFD-HES_UM_EN_20190222



Delta Hybrid Energy Saving HES Series User Manual System





www.deltaww.com

Copyright notice

©Delta Electronics, Inc. All rights reserved.

All information contained in this user manual is the exclusive property of Delta Electronics Inc. (hereinafter referred to as "Delta") and is protected by copyright law and all other laws. Delta retains the exclusive rights of this user manual in accordance with the copyright law and all other laws. No parts in this manual may be reproduced, transmitted, transcribed, translated or used in any other ways without the prior consent of Delta.

Limitation of Liability

The contents of this user manual are only for the use of the AC motor drives manufactured by Delta. Except as defined in special mandatory laws, Delta provides this user manual "as is" and does not offer any kind of warranty through this user manual for using the product, either express or implied, including but not limited to the following: (i) this product will meet your needs or expectations; (ii) the information contained in the product is current and correct; (iii) the product does not infringe any rights of any other person. You shall bear your own risk to use this product.

In no event shall Delta, its subsidiaries, affiliates, managers, employees, agents, partners and licensors be liable for any direct, indirect, incidental, special, derivative or consequential damages (including but not limited to the damages for loss of profits, goodwill, use or other intangible losses) unless the laws contains special mandatory provisions to the contrary.

Delta reserves the right to make changes to the user manual and the products described in the user manual without prior notice and afterwards.

Preface

Thank you for choosing the Hybrid Energy System (HES) designed exclusively for the Delta Injection Machine, which consists of Hybrid Servo Controller (VFD-VJ) series and servo oil pump.

These production instructions provide the users with complete information regarding the installation, parameter configuration, anomaly diagnosis, troubleshooting, and routine maintenance of the Hybrid Servo Driver. To ensure correct installation and operation of the hybrid servo driver, please read the instructions carefully before installing the machine. In addition, please store the enclosed CD-ROM properly and pass down to the machine users.

The Hybrid servo driver is a delicate power electronics product. For the safety of the operators and the security of the machine, please only allow professional electrical engineers to conduct installation, tests, and adjust machine parameters. Please carefully read the contents of the instructions that are marked with "Danger" and "caution". Please contact your local Delta agents for any questions and our professional team will be happy to assist you.


PLEASE READ PRIOR TO INSTALLATION FOR SAFETY.



- ✓ Make sure to turn off the power before starting wiring.
- ☑ Once the AC power is turned off, when the POWER indicator of the Hybrid Servo Controller is still on, it means there is still high voltage inside the Hybrid Servo Controller, which is very dangerous and do not touch the internal circuits and components. To conduct the maintenance safely, please make sure the voltage between +1 and is lower than 25Vdc using the handheld multimeter before starting the operation.
- ☑ The internal circuit board of Hybrid Servo Controller houses CMOS IC, which is vulnerable to electrostatics. Please do not touch the circuit board by and without any anti-electrostatics measures.
- ☑ Never modify the components or wiring inside the Hybrid Servo Controller.
- ☑ The E[⊕] terminal of Hybrid Servo Controller must be grounded correctly. The 230V series uses the third type of ground scheme while the 460V series uses special ground.
- ☐ This series of products cannot be operated in environments that endanger human safety.
- Please keep children or strangers from approaching Hybrid Servo Controller.



- ☑ Never connect AC power to the output terminals U/T1, V/T2, and W/T3 of Hybrid Servo Controller.
- ☑ Please do not conduct stress test on the internal components of Hybrid Servo Controller, for the semiconductor devices therein may be damaged by high-voltage breakdown.
- ☑ Even when the servo oil pump is off, the main loop terminal of Hybrid Servo Controller can still be loaded with high voltage that can be seriously dangerous.
- ☑ Only qualified professional electrical engineers can conduct tasks of installation, wiring, and maintenance of Hybrid Servo Controller ∘





- ☑ Please choose a safe area to install Hybrid Energy System, where there is no high temperature, direct sunlight, moisture, and water dripping and splash.
- ☑ Please follow the instructions when installing Hybrid Energy System. Any unapproved operation environment may lead to fire, gas explosion, and electroshock.
- When the wiring between the hybrid controller and the hybrid servo motor is too long, it may compromise the interlayer insulation of the motor. Please install a reactor between them (please refer to Appendix A) to avoid burning of the hybrid servo motor from damaged insulation.
- ☑ The voltage rating of the power supply of Hybrid Servo Controller 230 series cannot be higher than 240V (no higher than 480V for 460 series) and the associated current cannot exceed 5000A RMS (no higher than 10000A RMS for models with 40HP (30kW))

NOTE

- To provide detailed product descriptions, the illustrations are made with the exterior cover or safety shield removed. When the product is running, please make sure the exterior cover is secured and the wiring is correct to ensure safety by following the instructions of the manual.
- The figures in the manual are made for illustration purposes and will be slightly different from the actual products. However, the discrepancy will not affect the interests of clients.
- Since our products are being constantly improved, for information about any changes in specifications, please contact our local agents or visit http://www.deltaww.com/iadownload acmotordrive to download the most recent versions.

Table of Contents

Chapter i Ose and installation	
1-1 Exterior of Product	1-2
1-2 Specifications	1-3
1-3 Introduction of Hybrid Energy System	1-8
1-4 Installation	1-9
Chapter 2 Wiring	
2-1 Wiring	2-2
2-2 Wiring of Servo oil Pump	2-9
2-3 Main Circuit	2-12
2-4 ControlTerminals	2-17
Chapter 3 Start Up	
3-1 Description of Control Panel	
3-2 Adjustment Flow Chart	3-5
3-3 Explanations for the Adjustment Steps	3-6
Chapter 4 Parameter Functions	
4-1 Summary of Parameter Settings	4-2
4-2 Detailed Description of Parameters	4-12
Chapter 5 Methods of Anomaly Diagnosis	
5-1 Unusual Signal	5-2
5-2 Over Current (oc)	5-9
5-3 Ground Fault (GFF)	5-9
5-4 Over Voltage (ov)	5-10
5-5 Low Voltage (Lv)	5-11
5-6 Overheat (oH1)	5-12
5-7 Overload (oL)	5-12
5-8 Phase Loss (PHL)	5-13
5-9 Resolutions for Electromagnetic Noise and Induction Noise	5-14
5-10 Environment and Facilities for Installation	5-15

Chapter 6 Maintenance

	6-1 Maintenance and Inspection	. 6-2
	6-2 Greasy Dirt Problem	. 6-2
	6-1 Fiber Dust Problem	. 6-2
	6-1 Erosion Problem	6-2
	6-1 Industriasl Dust Problem	6-2
	6-1 Wiring and Installation Problem	. 6-2
	6-1 Multi-funciton Input/ Output Terminals Problem	6-2
Αp _l	pendix A. Instructions of Product Packaging	
	A-1 Descriptions of Product Packaging: v.A	A-2
	A-2 Unpacking: v.A	A-3
	A-3 Detailed List of Product Packaging: v.A	A-4
	A-4 Detailed List of Product Packaging: v.C	A- 50
Ар	pendix B Optional Accessories	
	B-1 Non-fuse Circuit Breaker	B - 2
	B-2 Reactor	B-3
	B-3 Digital Keypad KPV-CE01	B - 9
	B-4 Communication Card	B-13
	B-5 EMI Filter	B-14
	B-6 Brake UnitE	3-16

Chapter 1 Use and Installation

- 1-1 Exterior of Product
- 1-2 Product Specifications
- 1-3 Introduction of Hybrid Energy System
- 1-4 Product Installation

Upon receipt of the product, the clients are advised to keep the product in its original packaging box. If the machine won't be used temporarily, for future maintenance safety and compliance with the manufacturer's warranty policy, pay attention to the following for product storage:



- ☑ Store in a clean and dry location free from direct sunlight or corrosive fumes.
- ☑ Store within an ambient temperature range of -20 °C to +60 °C.
- ☑ Store within a relative humidity range of 0% to 90% and non-condensing environment.
- ✓ Avoid storing the product in environments with caustic gases and liquids.
- ☑ Avoid placing the product directly on the ground. The product should be placed on suitable benches and desiccators should be placed in the packaging bags in harsh storage environments.
- ✓ Avoid installing the product in places with direct sunlight or vibrations.
- ☑ Even if the humidity is within the required value, condensation and freezing can still happen when there is drastic change of temperature. Avoid storing products in such environment.
- ☑ If the product has been taken out of the packaging box and in use for over three months, the temperature of the storage environment must be below 30°C. This considers the fact when the electrolytic capacitor is stored with no current conduction and the ambient temperature is too high, its properties may deteriorate. Do not store the product in the situation of no current conduction for more than one year.

1-1 Exterior of Product


All Hybrid Energy System has passed strict quality control before being shipped out from the factory, with enforced packaging that sustains impacts. Upon opening the packaging of the Hybrid Energy System, the customers are recommended to conduct the examination by the following steps:

- ☑ Check if there is any damage to Hybrid Energy System during shipping.
- ☑ Upon opening the box, check if the model number of Hybrid Energy System matches that listed on the external box.
- ☑ See Appendix A for the description and the detailed list of product packaging

For any mismatch of the listed data with your order or any other issues with the product,

contact your local agent or retailer.

Model Explanation



1-2 Specifications

230V Series Specifications HES____23A

Madel Norse							HE	S 2	3A				
	Model Name		063H	080G	H080	100G	100H	100Z	125G	125H	160G	160H	200G
Oi	Pump Capacity	cc/rev	25	3	2		40		5	0	6	4	80
te	Flow Rate	L/min	63	8	0		100		12	25	16	60	200
Flow Rate Specifications	Linearity	%					Bel	ow 1% F	F.S.				
FI	Magnetic Hysteresis	%		Below 1% F.S.									
,,	Maximum Pressure	Мра	18	14	18	14	18	18	14 18 14 18 14				
o Si	Minimum Pressure	Мра						0.1					
Sur	Linearity	%					Bel	ow 1% F	F.S.				
Pressure Specifications	Magnetic Hysteresis	%					Bel	ow 1% F	₹.S.				
	Power	kW			11				1	5		2	0
_ ဋ	Insulation Clas						U	L: Class					
양형	Cooling Metho							an Cooli					
ĕğŽ	Ambient Tempera							0 ~ 40 °C					
S i	Ambient Humic					20 ~	90 RH	(Non-cc	ndensat	ion)			
Servo Motor Specifications	Weight	kg		82		8		95		108 110		144	
	VFDVL23A	\(_)	110 (06HA)	110 (08GA)	150 (08HA)	150 (10GA)	185 (10HA)	220 (10ZA)	220 (12GA)	300 (12HA)	300 (16GA)	370 (16HA)	370 (20GA)
	Input Voltage	(V)	3-Phase 200~240V, 50/60Hz										
	Rated Output Capacity	kVA		9	2	:5	29	3	34		46		56
S S	Weight	kg	1	0			13			36			
엹	Brake Unit	1				Built-in				Ex	ternal: V		
<u> </u>	Brake resistor	W		_				1000				15	00
eci.		Ω	8	.3					5.8				
S	Speed Detect					0 401		Resolve					
e e	Pressure Comman			0~10V Support three-point calibration 0~10V Support three-point calibration									
ntroll	Flow Rate Commar Multi-functional I					0~10V		DC24V		oration			
Servo Controller Specifications	Terminal Multi-functional O	utput				2 ch D				output			
) er	Terminal		2 ch DC24V 50mA, 1 ch Relay output										
0)	Analog Output Vo		2 ch dc 0~10V										
	Cooling Methor Ambient Tempera							an Cooir I0 ~ 45 °					
	Ambient Humic					Polo			ondensa	tion)			
		•	Over	current	ovor vo						ng of AC	` motor	drivo
	Protection Funct	ions	Over current, over voltage, low current, overload, or overheating of AC motor drive, overload or overheating of motor, operation speed error										
	Working Medic	ım			Sverioa				rt1/2 R		ou ontol		
li O r	Working Medium Operation Temperature					112 1121		20 to 10		00,1110			
ļ ţi	remperature	@40 °C						67.83					
Actuation Oil	Viscosity @100 °C 8.62												
	Miscellaneous		P	Available upon purchase: safety valve, Reactor, and EMI filter are optional.									

230V Series HES____23C

N	lodel Name				}	HES23	С					
			063H	H080	100H	125H	160H	200H	250G			
Oil Pum	p Capacity	cc/rev	25	32	40	50	64	80	100			
	Flow Rate	L/min	63	80	100	125	160	200	250			
Flow rate	Linearity	%	Below 1% F.S.									
Specifications	Hysteresis	%	Below 1% F.S.									
	Maximum Pressure	Мра	18	18	18	18	18	18	14			
Pressure	Minimum Pressure	Мра				0.1						
Specifications	Linearity	%			В	Below 1% F.	S.					
	Magnetic Hysteresis	%			В	Below 1% F.	S.					
	Power	kW	10.4	14.6	14.6	18.4	23.1	27.6	27.6			
	Insulation (Class				Class F						
Servo Motor	Certificati					CE						
Specifications	Cooling Me					Fan Cooling]					
	Ambient Temp					0 ~ 40 °C						
	Ambient Hu					H (Non-con		101	1.45			
	Weight	kg	83	90	90	97	105	121	145			
	Model Name VFD- VL23Ā()		110A	150A	150A	220A	300A	300A	370A			
			(06HC) (08HC) (10HC) (12HC) (16HC) (20HC) (25GC) Three Phase AC 220 ~ 240V, 50/60Hz									
	Input Volt			II	nree Pnase	AC 220 ~ 2	40V, 50/60	HZ ⊺				
	Rated Outpu Power	l kW	11	15	15	22	30	30	37			
	Brake U			Bui	ilt-in		Exte	ernal VFDB	2022			
	Brake Resisto	or W	300									
		12	8.3 5.8									
Servo	Speed Determine Pressure Cor		Resolver									
Controller	Pressure Cor Input	nmana	0~10V Support three-point calibration									
Specifications	Flow Rate Co Input	mmand	0~10V Support three-point calibration									
	Multi-function	al Input	5ch DC24V 8mA									
	Termina		SCH DGZ4V ONA									
	Multi-functiona Termina		2 ch DC24V 50mA, 1 ch Relay output									
	Analog Output		2 ch dc 0~10V									
	Cooling Me		Fan Cooling									
	Protection Fu	nctions	Over current, over voltage, low current, overload, or overheating of AC motor drive, overload or overheating of motor, operation speed error									
				<u> </u>		Ţ.	1					
	Certificati	ons	CETIFIED SMETTISCA LETTOST2									
	Working Me	dium		Н	L-HLP DIN	51 524 Part	1/2 R68,R	46				
	Operation	°C				-12 to 100		<u> </u>				
Actuation Oil	Temperature											
		@40 °C @100 °C				67.83 8.62						
N/I	iscellaneous	<i>w</i> 100 ∪	8.62 Available upon purchase: safety valve, Reactor, and EMI filter are optional.									
IVI	iscellarieous		Available	e apon para	niase. Saiet	y vaive, nea	acioi, and E	ivii iiitei aie	optional.			

460V Series Specifications HES____43A

								HES	43A					
	Model Name		063G	063H	080G	H080	100G	100H	100Z	125G	125H	160G	160H	200G
Oil F	Pump Capacity	cc/rev	2			2		40			0	6		80
	Flow Rate	L/min		63 80 100 125 160 200										
ا ۾ ڏ	Linearity	%		Below 1% F.S.										
Flow rate Specifications	Magnetic Hysteresis	%						Below 1						
દ	Maximum Pressure	Мра	14	18	14	18	14	18	18	14	18	14	18	14
Pressure Specifications	Minimum Pressure	Мра						0.	1					
Siji l	Linearity	%						Below 1	% F.S.					
Spe	Magnetic Hysteresis	%						Below 1	% F.S.					
_ <u>v</u>	Power	kW				11					15			20
Servo Motor Specifications	Insulation (Class						UL: Cl	ass A				•	
gat ⊠	Cooling Me	ethod						Fan Co	ooling					
\$ \frac{1}{5} \big	Ambient Tem							0 ~ 4	0 °C					
) ser	Ambient Hu	midity					20 ~ 9	0 RH(No	condens	ation)				
0.0	Weight	kg		8	2		8	3	95	10	08	11	0	144
	Model Nur VFDVL	.43 <mark>A</mark> (_)	110 <mark>A</mark> (06GA)	150 B (06HA)	150 B (08GA)	185 B (08HA)	185 B (10GA)	220A (10HA)	<u>'</u>	220 <mark>A</mark> (12GA)	300 B (12HA)	300 B (16GA)	370B (16HA)	370 B (20GA)
	Input Volt		Three-Phase 380 ~ 460V, 50/60Hz											
	Rated Output Capacity	KVA	19	2	5	2	:9	34			46		5	56
,	Weight	kg			10					13			3	36
Servo Controller Specifications	Brake U		Built-in External VFDB-4045											
<u>i</u>	Brake resistor	W					10	000		-				500
		Ω (2			2	:5			2	0		14	1	3
&	Speed Det							Resc						
<u> </u>	Pressure Comm					C)~10V Su	pport thre	e-point c	alibration				
	Flow Rate Co					C	~10V Su	pport thre	e-point c	alibration				
	Input													
\ \frac{2}{2}	Multi-function Termin	al						5ch DC2	4V 8mA					
Se	Multi-functiona Termina	al				2	ch DC24			ay output				
	Analog Output							2 ch dc						
	Cooling Me							Fan Co						
	Ambient Tem							-10 ~ 4						
	Ambient Hu		Over cu	rrent. o	ver vo l ta	ge, low		0 RH(No over l oad			of AC n	notor driv	ve, over	load or
Protection Functions						overh	eating of	motor,	operatio		error			
Working Medium HL-HLP DIN51 524 Part1/2 R68,R46 Operation 90														
<u>iö</u>	Temperature	°C						-20 to	100					
Actuation Oil	Vigogoity	@40 °C						67.						
Ā	•	@100 °C						8.6						
	Miscellaneous	3		Availa	able upo	n purcha	ase: safe	ety valve	, Reacto	or, and E	MI filter	are option	onal.	


460V Series Specifications HES____43C

	N4I - I NI					HE	S 43C						
	Model Nam	1e 	063H	080H	100H	125H	160H	200H	250M	320M			
Oil Pum	p Capacity	cc/rev	25	32	40	50	64	80	125	160			
	Flow Rate		63	80	100	125	160	200	250	320			
ate cat	Linearity	%		Below 1% F.S.									
Flow rate Specificati ons	Magnetic Hysteresis	%		Below 1% F.S.									
e uo	Maximum Pressure	Мра					18						
Pressure Specification	Minimum Pressure	Мра	0.1										
Pre	Linearity	%				Belo	w 1% F.S.						
<u> </u>	Magnetic Hysteresis						w 1% F.S.						
<u> </u>	Power	kW	10	10	14	18	23	25	45	52			
용을		on Class					/inding H grad	de)					
s ig		Method					n Cooling						
Servo Motor Specification s		emperature					~ 40 °C						
Ser	Ambient	: Humidity				20 ~ 90 RH(No condensa						
0, 0,	Weight	kg	83	83	90	97	105	121	206	224			
	Model nan	ne VFD	110VL 43A 06HC	150VL43B 08HC	185VL43B 10HC	220VL43A 12HC	300VL43B 16HC	300VL43B 20HC	550VL43A 25MC	550VL43A 32MC			
	Input Voltage				Т	hree Phase 3	80 ~ 480V, 5	0/60Hz	1				
	Rated Output Capacity	KVA	19	25	29	34	46	46	80	80			
	Weight	kg	10	10	10	13	13	13	50	50			
SUC	Brake Unit		Built-in External VFDB-4045										
atic	Brake	W	300	300	1000	1000	1000	1000	1500	1500			
ifi	resistor	Ω	25	25	25	25	14	14	13	13			
Sec	Speed	Detector		Resolver									
Ñ		Command	0~10V Support three-point calibration										
<u>=</u>	In	put			0~	10V Support	tnree-point ca	ilibration					
ontro		Command put		0~10V Support three-point calibration									
Servo Controller Specifications		tional Input minal	5ch DC24V 8mA										
٠.	Ter	ional Output minal		2 ch DC24V 50mA, 1 ch Relay output									
		tput Voltage					dc 0~10V						
		Method	Fan Cooling										
		emperature	-10 ~ 45 °C										
	Ambient	Humidity				3elow 90 RH(Non-condens	sation)					
	Protection	n Functions	Over current, over voltage, low current, overload, or overheating of AC motor drive, overload or overheating of motor, operation speed error										
	Certifications C C CERTIFED CERTIFICATION CERTIFIC												
	Working	Medium	<u> </u>		HL	-HLP DIN51 5	24 Part1/2	R68,R46					
Actuation Oil	Operation Temperatu	ı °C			- · · -		0 to 100	,					
of C		@40 °C					67.83						
	Viscosity	@100°C					8.62						
	Miscellaned	ous		Available u	pon purchas	se: safety va	Ive, Reacto	r, and EMI fi	Iter are option	nal.			

460V Series HES____43C

Model Name Color	Model Name					HES	43C						
Flow Rate Urrim 63 80 100 125 160 200		Model Name		063M	080M			160M	200M				
Magnetic Hysteresis Wagnetic Hysteresis	Oil Pu												
Maximum Mpa 18 Pressure Linearity % Below 1% F.S.	, n			63	80			160	200				
Pressure Mpa 18 18 18 18 18 18 18 1	Magnetic Hysteresis %												
Hysieresis % 10 10 14 18 23 32	- C	Pressure	Мра		18								
Hysieresis % 10 10 14 18 23 32	ssure	Pressure	·										
Hysieresis % 10 10 14 18 23 32	Pre		%			Below :	1% F.S.						
Insulation Class Efficiency	S	Hysteresis											
Efficiency Class				10	10			23	32				
Ambient Humidity 8g 83 83 90 97 105 121	် စ												
Ambient Humidity 8g 83 83 90 97 105 121	Moto					(
Ambient Humidity 8g 83 83 90 97 105 121	ryo Scifi	Cooling Me	ethod			Fan C	Sooling						
Weight kg 83 83 90 97 105 121	Spe												
Model Name 150VL43 185VL43 220VL43 300VL43 300VL43 (20MC)			ımidity			0 RH (Non-conder	nsation), altitude <						
VFD-						Ų							
Rated Output RW 15 18.5 22 30 30 37		VFD				(10MC)	(12MC)						
Output Power Name			tage				I						
Weight kg		Output	kW	15	18.5	22	30	30	37				
Bake Unit Built-in External VFDB-4045			kg		10		13						
Output Terminal Analog Output Voltage Cooling Method Ambient Temperature Ambient Humidity Protection Functions Working Medium Operation Temperature Wiscosity Wiscosity Output Terminal 2 ch dc 0~10V 2 ch dc 0~10V Below 90 RH (Non-condensation) Below 90 RH (Non-condensation) Over current, over voltage, low current, overload, or overheating of AC motor drive, overload or overheating of motor, operation speed error HL-HLP DIN51 524 Part1/2 R68,R46 -20 to 100 67.83 Wiscosity Operation Temperature Output Terminal 2 ch dc 0~10V Ambient Temperature -10 ~ 45 °C Below 90 RH (Non-condensation) Over current, over voltage, low current, overload or overheating of motor, operation speed error HL-HLP DIN51 524 Part1/2 R68,R46 -20 to 100 -20 to 100 -20 8.62	SU												
Output Terminal Analog Output Voltage Cooling Method Ambient Temperature Ambient Humidity Protection Functions Working Medium Operation Temperature Wiscosity Wiscosity Output Terminal 2 ch dc 0~10V 2 ch dc 0~10V Below 90 RH (Non-condensation) Below 90 RH (Non-condensation) Over current, over voltage, low current, overload, or overheating of AC motor drive, overload or overheating of motor, operation speed error HL-HLP DIN51 524 Part1/2 R68,R46 -20 to 100 67.83 Wiscosity Operation Temperature Output Terminal 2 ch dc 0~10V Ambient Temperature -10 ~ 45 °C Below 90 RH (Non-condensation) Over current, over voltage, low current, overload or overheating of motor, operation speed error HL-HLP DIN51 524 Part1/2 R68,R46 -20 to 100 -20 to 100 -20 8.62	atio	Brake	W	30	00	1000		1000					
Output Terminal Analog Output Voltage Cooling Method Ambient Temperature Ambient Humidity Protection Functions Working Medium Operation Temperature Wiscosity Wiscosity Output Terminal 2 ch dc 0~10V 2 ch dc 0~10V Below 90 RH (Non-condensation) Below 90 RH (Non-condensation) Over current, over voltage, low current, overload, or overheating of AC motor drive, overload or overheating of motor, operation speed error HL-HLP DIN51 524 Part1/2 R68,R46 -20 to 100 67.83 Wiscosity Operation Temperature Output Terminal 2 ch dc 0~10V Ambient Temperature -10 ~ 45 °C Below 90 RH (Non-condensation) Over current, over voltage, low current, overload or overheating of motor, operation speed error HL-HLP DIN51 524 Part1/2 R68,R46 -20 to 100 -20 to 100 -20 8.62	jį.			2									
Output Terminal Analog Output Voltage Cooling Method Ambient Temperature Ambient Humidity Protection Functions Working Medium Operation Temperature Wiscosity Wiscosity Output Terminal 2 ch dc 0~10V 2 ch dc 0~10V Below 90 RH (Non-condensation) Below 90 RH (Non-condensation) Over current, over voltage, low current, overload, or overheating of AC motor drive, overload or overheating of motor, operation speed error HL-HLP DIN51 524 Part1/2 R68,R46 -20 to 100 67.83 Wiscosity Operation Temperature Output Terminal 2 ch dc 0~10V Ambient Temperature -10 ~ 45 °C Below 90 RH (Non-condensation) Over current, over voltage, low current, overload or overheating of motor, operation speed error HL-HLP DIN51 524 Part1/2 R68,R46 -20 to 100 -20 to 100 -20 8.62	bed					Res	olver						
Output Terminal Analog Output Voltage Cooling Method Ambient Temperature Ambient Humidity Protection Functions Working Medium Operation Temperature Wiscosity Wiscosity Output Terminal 2 ch dc 0~10V 2 ch dc 0~10V Below 90 RH (Non-condensation) Below 90 RH (Non-condensation) Over current, over voltage, low current, overload, or overheating of AC motor drive, overload or overheating of motor, operation speed error HL-HLP DIN51 524 Part1/2 R68,R46 -20 to 100 67.83 Wiscosity Operation Temperature Output Terminal 2 ch dc 0~10V Ambient Temperature -10 ~ 45 °C Below 90 RH (Non-condensation) Over current, over voltage, low current, overload or overheating of motor, operation speed error HL-HLP DIN51 524 Part1/2 R68,R46 -20 to 100 -20 to 100 -20 8.62	ller S	Input			0~10V Support three-point calibration								
Output Terminal Analog Output Voltage Cooling Method Ambient Temperature Ambient Humidity Protection Functions Working Medium Operation Temperature Wiscosity Wiscosity Output Terminal 2 ch dc 0~10V 2 ch dc 0~10V Below 90 RH (Non-condensation) Below 90 RH (Non-condensation) Over current, over voltage, low current, overload, or overheating of AC motor drive, overload or overheating of motor, operation speed error HL-HLP DIN51 524 Part1/2 R68,R46 -20 to 100 67.83 Wiscosity Operation Temperature Output Terminal 2 ch dc 0~10V Ambient Temperature -10 ~ 45 °C Below 90 RH (Non-condensation) Over current, over voltage, low current, overload or overheating of motor, operation speed error HL-HLP DIN51 524 Part1/2 R68,R46 -20 to 100 -20 to 100 -20 8.62	ontro	I nput			0~10V Support three-point calibration								
Output Terminal Analog Output Voltage Cooling Method Ambient Temperature Ambient Humidity Protection Functions Working Medium Operation Temperature Wiscosity Wiscosity Output Terminal 2 ch dc 0~10V 2 ch dc 0~10V Below 90 RH (Non-condensation) Below 90 RH (Non-condensation) Over current, over voltage, low current, overload, or overheating of AC motor drive, overload or overheating of motor, operation speed error HL-HLP DIN51 524 Part1/2 R68,R46 -20 to 100 67.83 Wiscosity Operation Temperature Output Terminal 2 ch dc 0~10V Ambient Temperature -10 ~ 45 °C Below 90 RH (Non-condensation) Over current, over voltage, low current, overload or overheating of motor, operation speed error HL-HLP DIN51 524 Part1/2 R68,R46 -20 to 100 -20 to 100 -20 8.62	70	Termin	al		5ch DC24V 8mA								
Voltage Cooling Method Ambient Temperature Ambient Humidity Protection Functions Working Medium Operation Temperature Viscosity Wiscosity Viscosity Voltage Cooling Method Fan cooling Fan cool	Se	Output Ter	minal	2 ch DC24V 50mA, 1 ch Relay output									
Ambient Temperature Ambient Humidity Protection Functions Working Medium Operation Temperature Viscosity Wiscosity Ambient Temperature Ambient Temperature Ambient Temperature Ambient Temperature Ambient Temperature Ambient Temperature Below 90 RH (Non-condensation) Over current, overload, or overheating of AC motor drive, overload or overheating of motor, operation speed error HL-HLP DIN51 524 Part1/2 R68,R46 -20 to 100 @40 °C @40 °C @100 °C 8.62		Voltag	e										
Ambient Humidity Protection Functions Working Medium Operation Temperature Viscosity Wiscosity Ambient Humidity Protection Functions Over current, over voltage, low current, overload, or overheating of AC motor drive, overload or overheating of motor, operation speed error HL-HLP DIN51 524 Part1/2 R68,R46 -20 to 100 67.83 8.62													
Protection Functions Over current, over voltage, low current, overload, or overheating of AC motor drive, overload or overheating of motor, operation speed error Working Medium Operation Temperature Viscosity Over current, over voltage, low current, overload, or overheating of AC motor drive, overload or overheating of motor, operation speed error HL-HLP DIN51 524 Part1/2 R68,R46 -20 to 100 @40 °C Viscosity @40 °C @100 °C 8.62													
Working Medium				Over current, over voltage, low current, overload, or overheating of AC motor drive, overload or									
Operation Temperature °C -20 to 100 Viscosity @40 °C 67.83 Viscosity @100 °C 8.62				<u> </u>									
, oC	io r	Operation						ru					
, oC	atio	remperature	<i>@</i> 40 °∩										
	Actui	Viscosity	@100										
		Miscellaneou		Availa	able upon purch	ase: safety valve	e, Reactor, and l	EMI filter are op	tional.				

1-3 Introduction of Hybrid Energy System



1-4 Installation


Servo Oil Pump

Install the servo oil pump in an environment with the following conditions to ensure safe product operation:


Conditions of Operation	Ambient Temperature	0°C~ 40°C
Environment	Relative Humidity	20%~90%, No condensation
	Oil Temperature	0°C~ 60°C (15°C~ 50°C is recommended)

The figure below shows that HES version A is installed on the machine. The screws must be secured to the rubber mat to fixate the servo oil pump. It is recommended to add iron bars as the support of the hybrid servo motor.

HES version A:



Installation Space



Installation Distance

Since heat is generated as the hybrid servo motor is running, certain space must be reserved to ensure good circulation of the cooling air as shown in the figure above.


When the hybrid servo motor is running, the temperature of the external cover will reach to about 100°C. Do not touch it with hand to avoid burns.




Do not let any foreign objects such as fiber, paper pieces, wood chips or metal pieces to adhere to the cooling fan of the hybrid servo motor.

HES version C:

The figure below shows that HES version C is installed on the machine. Beside absorbing the vibration produced by the running motor, the height and the position of the anti-vibration rubber pads can also be adjusted.





NOTE

Do not let any foreign objects such as fiber, paper pieces, wood chips or metal pieces to adhere to the cooling fan of the hybrid servo motor.

Pipelines & Connections

- Remove all protection caps on the pump
- Choose suitable oil tube and connectors (Maximum intake flow rate 1m/s)

Recommended Specifications of intake oil tube						
Flow Rate(L/min)	Tube Diameter (inch)	Length (m)				
80	Above 1.5	Within 1.5				
100	Above 1.5	Within 1.5				
125	Above 2	Within 1.5				
160	Above 2.25	Within 1.5				
200	Above 2.5	Within 1.5				
250	Above 3.0	Within 1.5				
320	Above 3.5	Within 1.5				

- Absolute intake oil pressure: Maximum 2 bar
- Prior to assembly, the iron dusts in the connectors and oil tubes must be removed.
- The filter for the oil inlet must be above 150mesh.



For safety, install safety valve in the oil line loop.


Do not add check valve to the oil outlet of the oil pump to avoid poor response of Hybrid Energy System.


Hybrid Servo Controller

Install the Hybrid Servo Controller in an environment with the following conditions to ensure safe product operation:

Conditions of Operation Environment	Ambient Temperature Relative Humidity Pressure Installation heights Vibration	-10°C~ +45°C <90% , No condensation 86 ~ 106 kPa <1000m
Conditions of Storage and Shipping Environment	Ambient Temperature Relative Humidity Pressure Vibration	<pre><20Hz: 9.80 m/s² (1G) max; 20~50H:5.88 m/s² (0.6G) max -20°C~ +60°C (-4°F ~ 140°F) <90% , No condensation 86 ~ 106 kPa <20Hz: 9.80 m/s² (1G) max; 20 ~ 50Hz: 5.88 m/s² (0.6G) max</pre>
Contamination Protection Grade		ctory environments with medium to low contamination

Installation Space





HP	W	Н
ПР	mm (inch)	mm (inch)
7.5-20HP	75 (3)	175 (7)
25-75HP	75 (3)	200 (8)
100HP	75 (3)	250 (10)

- ☑ The Hybrid Servo Controller must be installed vertically with screws to sturdy structures. Do not install it upside down, tilted, or horizontally.
- ☑ Since heat is generated when Hybrid Servo Controller is running, good circulation of the cooling air must be provided as shown in the figure above. Certain space is reserved in the design to allow the heat generated to dissipate upwards. As a result, do not install the machine below any equipment that cannot stand excessive heat. If the machine is installed in the control plate, special care must be given to maintain good air flow for cooling so that the surrounding temperature of Hybrid Servo Controller won't exceed the regulated values. Do not install Hybrid Servo Controller in any closed box with poor air flow and cooling, which will lead to machine malfunction.
- ☑ As the Hybrid Servo Controller is running, the temperature of the cooling plate will change with the ambient temperature and the load, with the maximum temperature reaching to about 90°C. Therefore, the backside of installation materials for Hybrid Servo Controller must be able to sustain high temperature.
- When multiple Servo Controllers are installed in one single control plate, it is recommended to install them with laterally to avoid heat interference among each other. If stacking installation is needed, spacers must be installed to minimize the effect of the heat from the lower machine on the upper machine.

NOTE

Do not let any foreign objects such as fiber, paper pieces, wood chips or metal pieces to adhere to the cooling fan of the hybrid servo motor. The product should be installed in a control plate made of inflammable materials such as metal to avoid the risk of fire.

Chapter 2 Wiring

- 2-1 Wiring
- 2-2 Wiring of Servo Oil Pump
- 2-3 Descriptions of Main circuit Terminals
- 2-4 Descriptions of Control Loop Terminals

Upon opening the top cover of the Hybrid Servo Controller and reveal the wiring terminal bus, check if the terminals of each Main circuit and control loop circuit are labeled clearly. Pay attention to the following wiring descriptions to avoid any incorrect connection.

- ☑ The Main circuit power terminals R/L1, S/L2, and T/L3 of the Hybrid Servo Controller are for power input. If the power supply is connected by mistake to other terminals, the Hybrid Servo Controller will be damaged. In addition, it is necessary to verify that the voltage/current rating of power supply is within the numbers listed on the name plate.
- ☑ The ground terminal must be grounded well, which can avoid being stricken by lightning or occurrence of electrocution and minimize interference by noise.
- ☑ The screw between each connection terminal and the wire must be tightened securely to avoid sparking by getting loose from vibration.



- ☑ If the wiring is to be changed, first step is to turn off the power of the Hybrid Servo Controller, for it takes time for the DC filter capacitor in the internal loop to completely discharge. To avoid any danger, the customer can wait for the charging indicator (READY light) to be off completely and measure the voltage with a DC voltmeter. Make sure the measured voltage is below the safety value of 25V_{DC} before starting the wiring task. If the user fails to let the Hybrid Servo Controller completely discharge, residual voltage will build up internally, which will cause short circuit and spark if wiring is conducted. Therefore, it is recommended that the user should only conduct the wiring when there is no voltage to ensure his/her safety.
- ☑ The wiring task must be conducted only by professional personnel. Make sure that the power is off before starting to avoid incidence such as electrocution.




- During wiring, follow the requirements of the electrical regulations to select proper gauges and conduct wiring accordingly to ensure safety.
- ☑ Check the following items after finishing the wiring:
 - 1. Are all connections correct?
 - 2. No loose wires?
 - 3. No short-circuits between terminals or to ground?

2-1 Wiring


The wiring of the hybrid energy system consists of that for the servo oil pump and that for the Hybrid Servo Controller. The user must follow the wiring loop below for all wire connections.

Standard Wiring Diagram


HES063A23A~HES125G23A; HES063G43A~HES160G43A;




HES125H23A~HES200G23A; HES160H43A~HES200G43A;



HES063H23C, HES080H23C, HES100H23C, HES125H23C, HES063H43C, HES080H43C, HES100H43C, HES125H43C, HES160H43C, HES200H43C, HES063M43C, HES080M43C, HES100M43C, HES125M43C, HES160M43C, HES200M43C



HES160H23C, HES200H23C, HES250G23C, HES250M43C, HES320M43C





Old VJ control boards don't have the built-in precision resistor.


VFD-VJ produced before period T1532, W1523 don't have the built-in precision resistor.

To make KTY84 and motor work together, prepare a precision resistor of $2K\Omega$, 1/4W and have it connected in parallel to the +10V, AUI terminals on the I/O control board.

Note 1*


The RA, RC wiring of the braking unit: the overheat protection wiring of the braking unit.

Note 2*





Wiring Diagram of Pressure Sensor

Voltage type pressure Sensor => Pin1: 24V , Pin2: ACM , Pin3: PO



Current type pressure Sensor => Pin1: 24V , Pin2: PO , Pin3: N/A





NOTE

- *1 For firmware version 2.03 and above, the operating commands are given through the communications.

 Therefore, the parameters for the slave is Pr01-01 = 2
- *2 For firmware version 2.03 and above, it is not necessary to install this check valve. By selecting the slave parameter Pr03-21 at the slave to see if the slave will perform the reverse depressurization. Parameters Pr03-21 = 0 for not performing the reverse depressurization.
- *3 For firmware version 2.03 and above, the diversion/confluence signal are supplied to only Master 2/Slave. It is not necessary to supply the signal to Master 1.For the following control arrangement, it is necessary to disconnect the communications during diversion.

When the signals are Confluence, the communication will be a short circuit. When the signals are Diversion, the communication becomes an open circuit. → Hydraulic outlet 1 → Hydraulic outlet 2 SG+ SG-SG+ SG-SG+ SG-Pressure SG+ SG-Command Pressure Command Flow Command Flow Command QI Confluence/Diversion Signals Master 1 Slave Slave Master 3 03-13=1 03-13=2 03-13=2 03-13=3 PO PO •


M

M

M


2-2 Wiring of Servo Oil Pump

HES____A servo oil pump:




Note 1: After week 06 of year 2016, the temperature rise protection has been modified from On/Off switch (terminal 1 and 2) to KTY84-130 (terminal 5 and 6). Therefore, the wiring method between the temperature rise protection and the hydraulic servo motor is different.

HES_____C servo oil pump:



Encoder CBHE-E5M:


PTC (yellow)



The colors mentioned in the Connector Pin Definition table are only the colors of lines inside the motor. They are not the colors of the lines on the encoder CBHE-E5M

Note 2: The signal of KTY840-130 temperature rising protection is integrated into the encoder. The production serial numbers after TW1744/ W1744 have PTC temperature rising protection.

Crimp Terminals



Terminal Torque: 82kg-m (71in-lbf)





Figure 1 Figure 2

External Wiring of Hybrid Servo Controller



Power Supply	Please follow the power rating listed in the user's manual (chapter 1)
Fuse/NFB (Optional)	A larger current may be generated when the power is turned on. Please refer to Appendix B-1 to select suitable non-fused switch or fu
Magnetic Contactor	Turning on/off the side electromagnetic contactor can start/stop the hybrid servo controller. However, frequent switching may lead to malfunction. It is advised not to turn on/off the hybrid servo controller for more than 1 time/hour.
Input AC Line Reactor (Optional)	When the output capacity exceeds 1000kVA it is recommended to add an AC reactor to improve the power factor, with the wiring distance within 10m. Please refer to Appendix B-2 for details.
Zero-Phase Reactor	This is to reduce the radiation interference, especially in places with audio devices. It can also reduce the interferences at the input and output sides. Please refer to appendix B-2 for details. The effective range is from AM band to 10MHz.
EMI Filter	It can be used to reduce electromagnetic interference. Please refer to Appendix B-5 for details.

2-3 Main Circuit


Terminal Label	Description	
R/L1, S/L2, T/L3	AC line input terminals	
U/T1, V/T2, W/T3	Output of Hybrid Servo Controller, connected to hybrid servo motor	
	For power improvement of the connection terminal of DC reactor. Please	
+1, +2/B1	remove the shorting plate in installation (DC reactors are built-in in models	
	with power ≥ 37KW)	
+2/B1, B2	Connection terminal of brake resistor. Please follow the selection table to	
	purchase suitable ones.	
	Earth connection, please comply with local regulations.	



- The wiring for the Main circuit must be isolated from that for the control loop to avoid malfunction.
- Please use isolation wires for control wiring as much as possible. Do not expose the section where the isolation mesh is stripped before the terminal.
- Please use isolation wire or wire tube for power supply wiring and ground the isolation layer or both ends of wire tube.
- Usually the control wire does not have good insulation. If the insulation is broken for any reason, high voltage may enter the control circuit (control board) and cause circuit damage, equipment accident, and danger to operation personnel.
- Noise interferences exist between the Hybrid Servo Controller, hybrid servo motor, and their wirings. Check if the pressure sensor and associated equipments for any malfunction to avoid accidents.
- The output terminals of the Hybrid Servo Controller must be connected to the hybrid servo motor with the correct order of phases.
- When the wiring between the Hybrid Servo Controller and hybrid servo motor is very long, it may cause tripping of hybrid servo motor from over current due to large high-frequency current generated by the stray capacitance between wires. In addition, when the leakage current increases, the precision of the current value becomes poor. In such case, an AC reactor must be connected to the output side.
- ☐ The ground wire of the Hybrid Servo Controller cannot be shared with other large current load such as electric welding tool. It has to be grounded separately.
- For your safety and to reduce noise interference, apply Class D grounding method ($\stackrel{\oplus}{}$) on 230V series and apply Class C grounding method ($\stackrel{\oplus}{}$) on 460V series. (with the ground resistance of 10 Ω or less)

Voltage Series	Grounding Method	Grounding Resistance
230V	Class D	100Ω or less
460V	Class C	10Ω or less

- ☑ To avoid lightning strike and incidence of electrocution, the external metal ground wire for the electrical equipments must be thick and short and connected to the ground terminal of the Hybrid Servo Controller system.
- When multiple Hybrid Servo Controllers are installed together, all of them must be directly connected to a common ground terminal. Please refer to the figure below to make sure there is no ground loop.



Mains power terminals (R/L1, S/L2, T/L3):

- ☑ Connect these terminals (R/L1, S/L2, and T/L3) via a non-fuse breaker or earth leakage breaker to 3-phase AC power (some models to 1-phase AC power) for circuit protection. It is unnecessary to consider phase-sequence.
- ☐ The wire between the three-phase AC input power supply and the Main circuit terminals (R/L1, S/L2, and T/L3) must be connected to a non-fused switch.
- ☑ Please make sure to fasten the screw of the main circuit terminals to prevent sparks, which is made by the loose screws due to vibration.
- ☑ Verify the voltage of power supply and the associated maximum available current.

 Please refer to Chapter 1 Descriptions of Specifications.
- ☑ If the Hybrid Servo Controller is equipped with a leakage circuit breaker for leakage protection, please select the circuit breaker that has a sensing current above 200mA and action time over 0.1 second to avoid malfunction.

✓ Please use isolation wire or wire tube for power supply wiring and ground the isolation layer or both ends of wire tube.

Output terminals for main circuit (U, V, W):

☑ The output side of Hybrid Servo Controller cannot be connected with advance phase capacitor, surge absorber, advance phase capacitor, or L-C and R-C filters.

Terminals [+1, +2] for connecting DC reactor, terminals [+1, +2/B1] for connecting brake resistor:

☑ These terminals are used to improve the power factor of DC reactor. There are shorting plates on them when they leave the factory. Remove the shorting plates before connecting the DC reactor.



Shorting Plate of DC Reactor

- ☑ For models with power ≥ 30kW (except VFD300VL43BXXXX), there is no driver loop for brake resistor inside. To increase the brake capability, please use an external brake unit and brake resistor (both are optional).
- \square Never short [B2] or [-] to [+2/B1], which will damage the Hybrid Servo Controller.

Main Circuit Terminals

Model No.	Wiring	tightening torque on the drive's terminal	Crimp Terminal
HES063H23A			12.8 Max.
HES063H23C	4AWG	30kgf-cm	N S S S S S S S S S S S S S S S S S S S
HES080G23A	(21mm²)	(26 lbf-in)	Ø12 Max. Heat Shrink Tube
HES080H23A HES080H23C	4AWG (21mm²)		18.5 Max. 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8
HES100G23A	4AWG		Ø6.3 Min. Ring lug Ring lug O
HES100H23A	(21mm²) 4AWG	EQLf	
HES100H23C	(21mm ²)	50kgf-cm (43.4 lbf-in)	│
HES100Z23A	2AWG (33mm²)	(70.7 101-111)	Signature of the strink Tube
HES125G23A	2AWG (33mm²)		WIRE
HES125H23A			28 Max. 28 Max. 24 Lt
HES125H23C			28 Max.
HES160G23A			Ring lug Ring lug
HES160H23A	2AWG	200kgf-cm	Name Name Name Name Name Name Name Name
HES160H23C	(33mm ²)	(173 lbf-in)	13 Mii
HES200G23A			Ø28 Max. Heat Shrink Tube
HES200H23C			WIRE
HES063G43A			12.8 Max
HES063H43A			- CO N. CO
HES063M43C HES080G43A			Ring lug Ring lug
HES080G43A			N N N N N N N N N N N N N N N N N N N
HES080M43C	8AWG	30kgf-cm	1 2 7 Min.
HES100G43A	(8mm²)	(26 lbf-in)	0 412 4
HES063H43C			Heat Shrink Tube
HES080H43C			
HES100H43C			
HES100H43A	8AWG		18.5 Max ×
HES100M43C HES100Z43A	(8mm²)	-	Ø6.3 Min.
HES125G43A			Ring lug Ping lug Ping lug
HES125H43A		EOL-of and	Wo Work
HES125M43C	6AWG	50kgf-cm (43.4 lbf-in)	13 35 Min
HES160G43A HES160M43C	(13mm ²)	(13.1161111)	un ø16.5 Max.
HES125H43C	,		o) · · · wre
HES160H43C			
HES200H43C			

Chapter 2 Wiring | HES Series

Model No.	Wiring	tightening torque on the drive's terminal	Crimp Terminal	
HES160H43A			Z2 Max. Solo Ring lug ✓	
HES200M43C	4AWG	80kgf-cm	Ø8.2 Min. Ring lug	
HES200G43A	(21mm ²)	(70 lbf-in)	Heat Shrink Tube 20 Max. WIRE	
HES250M43C	2AWG (33mm²)	200kgf-cm	The motor drives to go with these two HES models have their wires tightened so you don't need to	
HES320M43C			crimp terminals.	




HES160H23A, HES200G23A installations must use 90°C wires.


The other model use UL installations must use 600V, 75°C or 90°C wire. Use copper wire only.

Contact Delta for more information; if you want to use higher class of overheat protection material.

2-4 Control Terminals

Description of SINK (NPN) /SOURCE (PNP) Mode Switching Terminal





Frame	Torque		Wire Gauge
C, D, E	8 kgf-com (6.9 in-lbf)		22-14 AWG (0.3-2.1mm ²)
	Terminal: 0V/24V	1.6 kgf-com(1.4 in-lbf)	30-16 AWG (0.051-1.3mm ²)


Terminal	Function	Factory Setting (NPN mode)
SON	Run-Stop	Between terminals SON-DCM: conducting (ON); run: open circuit (OFF), Stop
EMG	Abnormal input from outside	Abnormal input from outside
RES	Reset	reset
MI3	Multiple Function Input: Option 3	No function is set for default setting When conducting (ON), input voltage is 24V _{DC} (Max:30V _{DC})
MI4	Multiple Function Input: Option 4	and output impedance is 3.75kΩ; In open circuit (OFF), the
MI5	Multiple Function Input: Option 5	allowable leakage current is 10μA
СОМ	Common terminal of digital control signals (Sink)	Common terminal of multiple function input terminals
+E24V	Common terminal of digital control signals (Source)	+24V 80mA
DCM	Common terminal of digital control signals (Sink)	Common terminal of multiple function input terminals
RA	Malfunctioning abnormal connection 1 (Relay always open a)	Resistive Load:
RB	Malfunctioning abnormal connection	5A(N.O.)/3A(N.C.) 240V _{AC}
	1 (Relay always closed b)	5A(N.O.)/3A(N.C.) 24V _{DC} Inductive Load:
RC	Multi-function Relay Common	1.5A(N.O.)/0.5A(N.C.) 240V _{AC}
		1.5A(N.O.)/0.5A(N.C.) 24V _{DC}
MO1	Multi-function Output 1 (Photocoupler)	Hybrid Servo Controller outputs various types of monitoring signals with the transistor operating in open collector mode. Max: 48Vdc/50mA MO1 MO2
MO2	Multi-function Output 2 (Photocoupler)	Internal circuit MCM
МСМ	Multi-function Output Common (Photocoupler)	Max. 48V _{DC} 50mA
РО	PO/PI/QI circuit PO/PI/QI PO/PI/QICircuit	Pressure Feedback Impedance:200kΩ Resolution:12 bits Range:0 ~ 10V or 4~20mA= 0~maximum Pressure Feedback value (Pr.00-08) To input current, firmware v2.04 or above and a new I/O control board (the one has SW100 switch) are required. See parameter 03-12 for more information.
PI	ACM Internal Circuit	Pressure Command Impedance:200kΩ Resolution:12 bits Range:0 ~ 10V= 0~maximum pressure command value (Pr.00-07)

Terminal	Function	Factory Setting (NPN mode)
QI		Flow Rate Command Impedance:200kΩ Resolution:12 bits Range:0 ~ 10V=0~maxium flow rate
+10V	Configuration Voltage	Power supply for analog configuration +10V _{DC} 20mA (variable resistor $3\sim5k\Omega$)
+24V	Power supply terminal of pressure sensor	Configuration power supply for pressure sensor +24V _{DC} 100mA
AUI	Analog Voltage +10V AUI circuit AUI -10V Internal Circuit	Impedance:11.3k Ω Resolution:12 bits Range:-10~+10Vpc
AFM	AFM 7//7 ACM	Output Current: 2mA max Resolution: 0~10V corresponds to maximum operation frequency Range: 0~10V Function Setting: Pr.00-05
AFM1	PO 500Ω \$ 777	Output Current: 2mA max Resolution: 0~10V corresponds to maximum operation Pressure Range: 0~10V Function Setting: None Output: Pressure feedback signal only
ACM	Analog control signal (common)	Common for ACI, AUI1, AUI2

*Control signal wiring size: 18 AWG (0.75 mm²) with shielded wire.

Analog Input Terminals (PO, PI, QI, AUI, ACM)

- ☑ The maximum input voltage of PI, PO, and QI cannot exceed +12V and no more than +/-12V for AUI. Otherwise, the analog input function may become ineffective.
- Analog input signals are easily affected by external noise. Use shielded wiring and keep it as short as possible (<20m) with proper grounding. If the noise is inductive, connecting the shield to terminal ACM can bring improvement.
- ☑ The interference generated by the Hybrid Servo Controller can cause the pressure sensor to malfunction. IN this case, a capacitor and a ferrite core can be connected to the pressure sensor side, as shown in the figure below:



Transistor outputs (MO1, MO2, MCM)

- ☑ Make sure to connect the digital outputs to the right polarity.
- When connecting a relay to the digital outputs connect a surge absorber across the coil and check the polarity.

Chapter 3 Start Up

- 3-1 Description of Control Panel
- 3-2 Adjustment Flow Chart
- 3-3 Explanations for the Adjustment Steps




- ☑ Please verify again before operation that the wiring is done correctly, especially that the output terminals U/T1, V/T2, and W/T3 of the Hybrid Servo Controller cannot have any power input. Make sure that the ground terminal ⊕ is connected correctly.
- ☑ Do NOT operate the AC motor drive with humid hands.
- ☑ Check for loose terminals, connectors or screws.
- ☑ Make sure that the front cover is well installed before applying power.



☑ In case of abnormal operation of the Hybrid Servo Controller and the associated servo motor, stop the operation immediately and refer to "Troubleshooting" to check the causes of anomalies. After the output of the Hybrid Servo Controller is stopped, when the power terminals L1/R, L2/S, and L3/T of the main circuit are still connected, touching the output terminals U/T1, V/T2, and W/T3 of the Hybrid Servo Controller may lead to electric shock.

3-1 Description of Control Panel

Description of the Digital Keypad KPVJ-LE01



- 1 Status Display
 Display the driver's current status.
- 2 LED Display Indicates frequency, voltage, current, user defined units and etc.
- 3 UP and DOWN Key Set the parameter number and changes the numerical data, such as Master Frequenc
- MODE Change between different display mode.
- **5** ENTER Used to enter/modify programming parameters.

Descriptions of Function Display Items

Display Message	Descriptions
RUN• FWD• REV•	Displays the AC driver Master frequency
RUN• FWD• REV•	Displays the actual output frequency at terminals U/T1, V/T2, and W/T3.
RUN• FWD• REV•	User defined unit (where U = F x Pr.00.04)
RUN• FWD• REV•	Displays the output current at terminals U/T1, V/T2, and W/T3.
RUN• FWD• REV•	Displays the AC motor drive forward run status.
RUN• FWD• REV•	Displays the AC motor drive reverse run status.
RUN• FWD• REV•	Displays the parameter item
RUN• FWD• REV•	Displays the actual stored value of the selected parameter.


Chapter 3 Flow of machine Adjustment | HES Series

Display Message	Descriptions
RUN• FWD• REV•	External Fault.
FWD •	Display "End" for approximately 1 second if input has been accepted by pressing key. After a parameter value has been set, the new value is automatically stored in memory. To modify an entry, use the and keys.
RUN• FWD• REV•	Display "Err", if the input is invalid.

Reference Table for the 7-segment LED Display of the Digital Keypad

Numeric	0	1	2	3	4	5	6	7	8	9
Seven-segment Display	Ü	!	Ċ	3	4	5	5	-1	8	3
English Letter	Α	а	В	b	С	С	D	d	Е	е
Seven-segment Display	R	-	-	6		C	-	ď	E	-
English Letter	F	f	G	g	Н	h		i	J	j
Seven-segment Display	F	-		-	H	h	-	-	ij	-
English Letter	K	k	L		М	m	N	n	0	0
Seven-segment Display	H	-		-	-	-	-	n	-	O
English Letter	Р	р	Q	q	R	r	S	S	Т	t
Seven-segment Display	P	-	-	9	-		5	-	-	-
English Letter	U	u	V	٧	W	W	X	Х	Υ	У
Seven-segment Display		ū	-	Ū	-	-	-	-	4	-
English Letter	Z	Z								
Seven-segment Display	-	-								

3-2 Adjustment Flow Chart



^{*}The firmware version is 2.04 and above, just proceed the process to set up HES ID code.

^{*}The firmware version is 2.05 and above, starts from "Execute venting".

3-3 Explanations for the Adjustment Steps

Operate the following steps with the digital operator (KPVJ-LE01/ KPV-CE01)

Prior to starting running, please verify again if the wiring is correct, especially that the output terminals U/T1, V/T2, and W/T3 of the Hybrid Servo Controller must correspond to the U, V, and W terminals of the Hybrid servo motor, respectively.

Step 1. Parameter Entry of Hybrid Servo Motor

- Do not connect the external terminals SON-COM and EMG-COM for the time being.
- Restore the factory default values by setting the Parameter 00-02 = 10
 Parameter reset

Pr. 00-02 10: Parameter reset

 Please make sure if the command source has been restored to the factory default (operation by external terminals)

When KPVJ-LE01/KPV-CE01 is used, set Pr. 01-01=0

Source of Run Command

Pr. 01-01	0: Operated by digital operator
	1: Operated by external terminals, Stop on keypad is disabled
	2: Communication port RS-485 is activated and Stop on keypad is
	disabled

Set Pr. 01-35 of the Hybrid servo motor

Delta Hybrid Servo Motor ID			
0	Disabled		
16	ECMA-ER181BP3	11kW, 220V motor	
17	ECMA-KR181BP3	11kW, 380V motor	
18	ECMA-ER221FPS	15kW, 220V motor	
19	ECMA-KR221FPS	15kW, 380V motor	
20	ECMA-ER222APS	20kW, 220V motor	
21	ECMA-KR222APS	20kW,380V motor	
125	MSJ-KR133AE48B	30kW, 380V motor	
215	MSJ-IR2070E42C	7kW, 380V motor	
216	MSJ-DR201AE42C	10.4kW, 220V motor	
217	MSJ-IR201AE42C	10.3kW, 380V motor	
218	MSJ-DR201EE43C	14.6kW, 380V motor	
219	MSJ-IR201EE42C	14.2kW, 380V motor	
220	MSJ-DR201IE42C	18.4kW, 220V motor	
221	MSJ-IR201IE42C	18.3kW, 380V motor	
222	MSJ-GR202DE42C	23.1kW, 220V motor	
223	MSJ-OR202DE42C	23kW380V motor	
224	MSJ-DR202HE42C	27.6kW, 220V motor	
225	MSJ-LR202FE42C	25kW, 380V motor	
227	MSJ-IR203CE42C	32kW, 380V motor	
229	MSJ-OR264FE48C	45.2kW, 380V motor	
231	MSJ-IR265CE48C	52.5kW, 380V motor	
233	MSJ-IR266IE48	68kW, 380V motor	

Ī	245	MSJ-IR202HE42	27kW, 380V motor
ı	245	MSJ-1R202HE42	27 KVV, 380 V MOLOT

^{*} For firmware version 2.04 and above

Step 2. Entry HES ID code*

- Do not connect the external terminals SON-COM and EMG-COM for the time being.
- Restore the factory default values by setting the Parameter 00-02 = 10

Parameter reset

 Please make sure if the command source has been restored to the factory default (operation by external terminals)

When you use KPVJ-LE01/KPV-CE01, set Pr. 01-01=0.

When you use VFD-Explorer, set Pr01-01=2.

Source of Run Command

Pr. 01-01	0: Operated by digital operator
	1: Operated by external terminals, Stop on keypad is disabled
	2: Communication port RS-485 is activated and Stop on keypad is
	disabled

Source of Run Command

Pr. 01-01	0: Operated by digital operator
	1: Operated by external terminals, Stop on keypad is disabled
	2: Communication port RS-485 is activated and Stop on keypad is
	disabled

■ Set Pr. 01-37 of HES ID#

HES160H23A

HES200G23A

6120

7020

Model	HES ID#	Model	HES ID#	Model	HES ID#
-	-	-	-	HES063H43C	2142
-	-	HES063G43A	2040	HES080H43C	3142
HES063H23C	2122	HES063H43A	2140	HES100H43C	4142
HES080H23C	3122	HES080G43A	3040	HES125H43C	5142
HES100H23C	4122	HES080H43A	3140	HES160H43C	6142
HES125H23C	5122	HES100G43A	4040	HES063M43C	2342
HES160H23C	6122	HES100H43A	4140	HES080M43C	3342
HES200H23C	7122	HES100Z43A	4240	HES100M43C	4342
HES250G23C	8022	HES125G43A	5040	HES125M43C	5342
HES063H23A	2120	HES125H43A	5140	HES160M43C	6342
HES080G23A	3020	HES160G43A	6040	HES200M43C	7342
HES080H23A	3120	HES160H43A	6140	HES200H43C	7142
HES100G23A	4020	HES200G43A	7040	HES250M43C	8342
HES100H23A	4120			HES320M43C	9342
HES100Z23A	4220				
HES125G23A	5020				
HES125H23A	5120				
HES160G23A	6020				

■ Verify if the setting value of Pr01-18 (Rated power of the synchronous motor) is the rated power (kW) of the corresponding motor. Verify also if the setting value of Pr00-07(Maximum value for the pressure command (bar)) fits version G, H, Z, and M.

Step 3.Check Pressure Feedback Signal

■ Firs, set input voltage Pr. 00-04 = 11 PO

Selection of Display Mode

Pr. 00-04 11: Display the signal of PO analog input terminal, with 0~10V corresponding to 0~100%.

Set Pr. 00-08=corresponding pressure settings of the 10V pressure sensor

Maximum value of pressure feedback

Pr. 00-08 0~250Bar

 Set speed command to 10rpm and press [RUN]. Check the pressure value is >0 on the pressure gauge.

When the pressure value is ≤0,

- ☑ Gradually increase the rotation speed.
- ☑ Check that each directional valve is closed.

When the pressure value is >0

☑ Check that the voltage reading displayed on the operation panel is consistent with the pressure reading on the pressure gauge.

Example: 10V on the pressure sensor corresponds to 250bar. When the pressure gauge reading is 50 bar, the output voltage on the pressure sensor should be approximately 50/250*10=2V. So the voltage displayed on the operation panel will be 20.0(%).

■ Meanwhile, observe if there is any oil leak.

Step 4. Check Pressure and Flow Commands

- This action does not need to start the servo oil pump.
- For the firmware version is 2.04 and above, theoretical values of three-point calibration of pressure and flow commands are auto-imported after entering HES ID code. Afterward, carry on the detailed adjustment with the following methods.
- Pr. 00-09 = 1 refers to the pressure control mode

Pressure Control Mode

Pr. 00-09 0: Speed control
1: Pressure control

■ Pr. 00-04 = 12 sets the PI input voltage

Selection of Display Mode

Pr. 00-04

12: Display the signal value of the PI analog input terminal, with 0~10V corresponding to 0~100%.

■ Pr. 00-07 = corresponding pressure value with 10V on the pressure controller command Maximum pressure command

Pr. 00-07 0~250Bar

- With the maximum pressure set by the controller, observe the associated value displayed on the operation panel and set it to 00-14.
- With the controller setting at half the maximum pressure, observe the associated value displayed on the operation panel and set it to 00-15.
- With the controller setting at the lowest pressure, observe the associated value displayed on the operation panel and set it to 00-16.

Example: 10V on the pressure sensor corresponds to 250bar. If the maximum pressure on the controller is 140bar and corresponds to 10V, the Pr. 00-07=140. Set 140bar through the controller and the voltage reading displayed on the operation panel is approximately 56.0(140/250*100%). Enter this value to Pr. 00-14. Next, set 70bar through the controller and the voltage reading displayed on the operation panel is approximately 28.0 (70/250*100%). Enter this value to Pr. 00-15. Lastly, set 0bar through the controller and the voltage reading displayed on the operation panel is approximately 0.0(0/250*100%). Enter this value to Pr. 00-16.

Example: 10V on the pressure sensor corresponds to 250bar. However, the maximum pressure on the controller is 140bar and corresponds to 7V. As a result, Pr. 00-07= 140/7*10=200. The following steps are the same as described in the previous example. Set 200bar through the controller first, followed by setting 100bar, and 0bar in the last step. Enter the corresponding values to the associated parameters.

■ Pr. 00-04 = 25 refers to the QI input voltage

Selection of Display Mode

Pr. 00-04	25: Displays the signal value of the QI analog input terminal, with
	0~10V corresponding to 0~100%.

- Set 100% flow rate through the controller, observe the reading displayed on the operation panel and enter it to 00-17
- Set 50% flow rate through the controller, observe the reading displayed on the operation panel and enter it to 00-18
- Set 0% flow rate through the controller, observe the reading displayed on the operation panel and enter it to 00-19

Step 5. Send Run Command via Controller

Check that Pr. 00-09 is 1 (pressure control mode)

Pressure Control Modes

Parameter00-09 0: Speed Control Settings 1: Pressure Control

■ Pr. 01-01=1

Source of Run Command

Pr. 01-01	0: Operated by digital operator
	1: Operated by external terminals, Stop on keypad is disabled
	2: Communication port RS-485 is activated and Stop on keypad is
	disabled

■ In case of power outage, connect SON-COM and turn on the power supply.

Step 6.Bleed the circuit and make sure if there is any plastic material in the barrel. The machine can start operation only when there are no plastic materials inside the barrel.

- For low-pressure and low-speed conditions (within 30% of the rated values), use the "manual operation" through the controller for the operation of each cylinder. During the operation, check the pipe connection for leaks or strange noise in the pump.
- When the air is bleeding completely, if there is any pressure fluctuation during operation, please adjust the pressure control Parameter PI in accordance with the method described in the "Description of Parameters".

Step 7. Adjustment for injection/pressure holding


- Heat up the barrel to the required temperature and set the controller in manual control mode.
- Set the Ki value of the three-stage PI to 0 (Pr. 00-21, 00-23, and 00-25) and the three-stage Kp value to be small (≤50.0)≤
- Execute the injection, with "Preset Target" set at low pressure (<50Bar) and low flow rate (<30%)
- Press "Injection" on the controller and the injection will be started or the system will directly enter the pressure holding operation (depending on the location of the oil cylinder)
- In the hold up state, Increase the speed bandwidth to the maximum value of 40Hz (Pr. 00-10) while causing no vibration to the hybrid servo motor.
- In the pressure holding state, when the pressure gauge needle or the monitored waveform shows no signs of vibration, the pressure feedback is stabilizing. Now the three sets of Kp values can be increased.
- When the pressure feedback becomes unstable, lower the three sets of Kp values by 20% (Example: lower the preset values of the three sets of Kp values from 100% to 80%), followed by adjusting the three sets of Ki values to eliminate the steady-state error and speed up the system response.
- Upon completion of the above steps, increase the pressure command of "Preset Target".
- Observe if the pressure feedback becomes stable. Proceed with troubleshooting in case of any anomaly, as described below:

Unstable pressure over the entire section

- **1.** Set Pr. 00-09 = 0 for speed control
- 2. With the oil line in the closed state, send the low speed rotation command to make the pressure feedback 40~50% of the pressure command value (Pr. 00-07)
- **3.** Check if the pressure waveform shows any jitters through the monitoring software.
 - Jitter in Pressure Waveform

The possible cause is interference from ground. If the motor or the three-phase power supply is grounded, disconnect the ground wire. If the motor or the three-phase power supply is not grounded, add the ground wire for interference protection.

The other possibility is the ground issue of the shielding mesh (as illustrated by the bold red lines in the figure below). If the shielding mesh is grounded, disconnect the ground wire. If the shielding mesh is not grounded, add the ground wire for interference protection.



4. Please contact the original manufacturer if the anomaly still cannot be resolved after resorting to the methods described above.

Step 8. Adjustment of System Transient Response

- Reduce the pressure ramp up time by increasing Kp1 (Pr. 00-20) and reducing Ki1 (Pr. 00-21) times
- When the pressure is over-adjusted, increase Kp3 (Pr. 00-24) and reduce Ki3 (Pr. 00-25) times

Confluence Machine Tuning Procedure

Follow the associated descriptions in Chapter 2 to lay out the wiring.

Follow steps 1 and 2 described above to enter the electrical codes for the master/slave machines. Then proceed with the steps below.

Master setting

Set the Parameter 03-06 = 1
 Multifunction Output 2 (MO1)

Setting value of Pr. 03-06 1: Operation indication

- Connect the Master's MO1 output terminal to the Slave's SON terminal and Master's MCM terminal to the Salve's COM terminal.
- For the firmware version 2.03 and above, it is not necessary to perform the two steps described above
- Set the Parameter 03-13 = 1

Confluence Master/Slave Selection

Setting value 0: No function
of Pr. 03-13 1: Master 1
2: Slave/Master 2
3: Slave/Master 3

■ Set the Parameter 03-14

Slave's proportion of the Master's flow

Setting value 0.0~6553.5% of Pr. 03-14

 For firmware version 2.03 and above, the Parameter 03-17 can be configured to determine the activation level for the Slave

Slave's activation level

Setting value 0~100% of Pr. 03-17

Slave setting

■ Parameter 01-01=1

Source of operation command

Setting value 0: Operation by using the digital keypad
of Pr. 01-01 1: Operation by using the external terminals. The Stop button on the keypad is disabled.
2: Communication using RS-485. The Stop button on the keypad is disabled

For firmware version 2.03 and above, set the Parameter 01-01=2 Source of operation command

O: Operation by using the digital keypad
of Pr. 01-01
1: Operation by using the external terminals. The Stop button on the keypad is disabled.
2: Communication using RS-485. The Stop button on the keypad is disabled

■ Set the Parameter 03-15 = 1

Source of Frequency Command

Setting value 0: Digital Operation Panel
of Pr. 03-15 1: RS485 Communication
2~5: reserved

Shut down the power and then supply the power again

Set an arbitrary value of the frequency command at the Master to check if the Slave has the same value of the frequency command

Set 10rpm at the Master and then press RUN to see if the Slave is also running. If not, check the wiring or the parameter setting for any problem

■ Set the Slave Parameter 03-13 = 2

Confluence Master/Slave Selection

Setting value 0: No function
of Pr. 03-13 1: Master 1
2: Slave/Master 2

3: Slave/Master 3

For firmware version 2.03 and above, the Parameter 03-21 can be set at the Slave to decide if the Salve is performing the reversed operation for depressurization.

Note: If it is required to reverse the operation for depressurization at the Slave, it is necessary to make sure that the pump outlet port is not installed with a check valve and the Parameter 03-16 should be set as 500%

Slave reverse operation for depressurization

Setting value 0: Disable of Pr.03-21 1: Enable

Limit for the Slave reverse depressurization torque

Setting value 0~500% of Pr. 03-16

Shut off the power and the re-supply power for the Slave, and then set the Slave in the speed control mode

Speed Control Mode

Setting value	0: Speed control
of Pr. 00-09	1: Pressure control

In this case, the Master can be tuned according to the Step 3 – Step 6 described above

Confluence/Diversion Mode Adjustment Procedure

Follow the associated descriptions in Chapter 2 to lay out the wiring.

In the diversion state, follow steps 1-8 described above to individually adjust the parameters of each driver.

In a confluence condition, please refer to the machine adjustment procedure for the confluence operation

Complete the above steps.

Set the Master for pressure control mode

Parameter 00-09 = 1 for pressure control mode

Pressure control mode

Setting value	0: Speed control
of Pr. 00-09	1: Pressure control

Set the Slave for speed control mode

■ Parameter 00-09 = 0 for speed control mode

Speed Control Mode

Setting value	0: Speed control
of Pr.00-09	1: Pressure control

Respectively set the master/slave multi-function input state. For the firmware version 2.03 and above, it is necessary to set these parameters for the Slave only

■ Parameter 03-00~03-02 = 45 confluence/diversion signal input

Multi-function Input

Setting values	0: No function
of Pr. 03-00~03-02	l45: Confluence / Diversion signal input

■ Through the controller, perform the entire confluence/diversion operation.

Chapter 4 Parameters

- 4-1 Summary of Parameter Settings
- 4-2 Detailed Description of Parameters

4-1 Summary of Parameter Settings

00 System Parameters

N	You	can	set this	parameter	during	operation
/	1 O U	Gan	361 11113	parameter	uuiiig	operation

Parameter code	Function of the parameter	Settings	Default value	VF	FOCPG	FOCPM
00-00	Hybrid Servo Controller model code ID	12: 230V, 7.5HP 13: 460 V, 7.5HP 14: 230V, 10HP 15: 460V, 10HP 16: 230V, 15HP 17: 460V, 15HP 18: 230V, 20HP 19: 460V, 20HP 20: 230V, 25HP 21: 460V, 25HP 22: 230V, 30HP 23: 460V, 30HP 24: 230V, 40HP 25: 460V, 40HP 26: 230V, 50HP 27: 460V, 50HP 29: 460V, 50HP 31: 460V, 75HP 33: 460V, 100HP	Read only	0	0	0
00-01	Display of rated current of the Hybrid Servo Controller	Display by models	Read only	0	0	
00-02	Reset parameter settings	0: No function 1: Parameter locked 5: Rest the kWh when the motor drive stops 10: Reset parameter values	0	0	0	0
00-03	Software version	Read only	Read only	0	0	0

	Parameter code	Function of the parameter	Settings	Default value	ΥF	FOCPG	FOCPM
*	00-04	Selection of multi-function display	 Display the output current (A) Reserved Display the actual output frequency (H) Display the DC-BUS voltage (U) Display the output voltage (E) Display the output power angle (n) Display the output power in kW (P) Display the actual motor speed rpm (r) Display the estimated output torque (%) Display the FG feedback (G) Reserved Display the signal value of the analog input terminal PO % Display the signal value of the analog input terminal AUI % Display temperature of the heat sink in °C (t.) Display temperature of IGBT in °C (T) The status of digital input (ON/OFF) (i) The status of digital output (ON/OFF) (o) Reserved The corresponding CPU pin status of the digital input (i.) The corresponding CPU pin status of the digital output (o.) Al-24: Reserved Display the signal value of the analog input terminal QI % (5.) Display the actual pressure value (Bar) (b.) Display the motor temperature (support KTY84 only) (T.) Over load rate of motor drive Over load rate of motor HES-A models 	0		0	0
×	00-05	Analog output function selection	0: Output frequency (Hz)	0	0	0	0
			1: Frequency command (Hz) 2: Motor speed (Hz) 3: Output current (A) 4: Output voltage 5: DC Bus voltage 6: Power factor		0 0 0 0	0 0 0 0 0	0 0 0 0 0
			7: Power 8: Output torque 9: PO 10: PI 11: AUI		0 0 0 0	0 0 0 0 0	00000
	00-06	Display the speed (rpm) defined by the user	12~20: Reserved 0~39999 rpm	2500	0	0	0
×	00-07	Maximum value for the pressure command	0~400Bar	140	0	0	0
×	00-08	Maximum pressure feedback value	0~400 Bar	250	0	0	0
	00-09	Pressure control mode	Speed control Pressure control	0	0	0	0
	00-10	Speed bandwidth	0~40Hz	20		0	0
×	00-11	Pressure feedback filtering time PO	0.000~1.000 second	0.000	0	0	0
×	00-12	Pressure command filtering time PI	0.000~1.000 second	0.000	0	0	0

Parameter code	Function of the parameter	Settings	Default value	VF	FOCPG	FOCPM
00-13	Flow command filtering time QI	0.000~1.000 second	0.000	0	0	0
00-14	Percentage of the pressure command value (Max)	0.0~100.0%	56.0	0	0	0
00-15	Percentage of the pressure command value (Mid)	0.0~100.0%	28.0	0	0	0
00-16	Percentage of the pressure command value (Min)	0.0~100.0%	0.0	0	0	0
00-17	Percentage of the flow command value (Max)	0.0~100.0%	100.0	0	0	0
00-18	Percentage of the flow command value (Mid)	0.0~100.0%	50.0	0	0	0
00-19	Percentage of the flow command value (Min)	0.0~100.0%	0.0	0	0	0
00-20	P gain 1	0.0~1000.0	50.0	0	0	0
00-21	I integration time 1	0.00~500.00 seconds	2.00	0	0	0
00-22	P gain 2	0.0~1000.0	50.0	0	0	0
00-23	I integration time 2	0.00~500.00 seconds	2.00	0	0	0
00-24	P gain 3	0.0~1000.0	50.0	0	0	
00-25	I integration time 3	0.00~500.00 seconds	2.00	0	0	0
00-26	Pressure stable region	0~100%	25	0	0	0
00-27	Base pressure	0.0~100.0%	0.1	0	0	0
00-28	Depressurization speed	0~100%	25	0	0	Ō
00-29	Ramp up rate of pressure command	0~1000ms	0	0	0	0
00-30	Ramp down rate of pressure command	0~1000ms	100	0	0	0
00-31	Ramp up rate of flow command	0~1000 ms	80	0	0	0
00-32	Ramp down rate of flow command	0~1000 ms	80	0	0	0
00-33	Valve opening delay time	0~200 ms	0	0	0	
00-34	Reserved					
00-35	Over-pressure detection level	0~400Bar	230	0	0	0
00-36	Detection of disconnection of pressure feedback	0 : No function 1: Enable (only for the pressure feedback output signal within 1~5V)	0	0	0	0
00-37	Differential gain	0.0~100.0 %	0.0	0	0	0
00-38	Pressure/flow control function selection	Bit 0: 0: Switch the PI Gain according to the pressure feedback level 1: Switch the PI Gain according to the multi-function input terminal Bit 1: 0: No pressure/flow control switch 1: Switch between the pressure and flow control	0	0	0	0
		in Children between the procedure and her control		_		
00-39	I gain of pressure overshoot	0.00~500.00 seconds	0.2	0	0	
00-40	differential gain 2	0.0~100%	0.0	0	0	
00-40 00-41	differential gain 2	0.0~100% 0.0~100%	0.0 0.0			
00-40 00-41 00-42	1 differential gain 2 differential gain 3 Pressure overshoot level	0.0~100%	0.0	0	0	
00-40 00-41 00-42 00-43	differential gain 2 differential gain 3 Pressure overshoot level Percentage of maximum flow	0.0~100% 0.0~100% 0~100% 0~100%	0.0 0.0 2 100	0	0	C
00-40 00-41 00-42 00-43	differential gain 2 differential gain 3 Pressure overshoot level Percentage of maximum flow Pressure command	0.0~100% 0.0~100% 0~100%	0.0 0.0 2	0	0	0
00-40 00-41 00-42 00-43 00-44 00-45	differential gain 2 differential gain 3 Pressure overshoot level Percentage of maximum flow Pressure command Percentage of flow command	0.0~100% 0.0~100% 0~100% 0~100% 0~400 bar 0~100%	0.0 0.0 2 100 0	0 0	0 0 0	0 0
00-40 00-41 00-42 00-43	1 differential gain 2 differential gain 3 Pressure overshoot level Percentage of maximum flow Pressure command Percentage of flow command Pressure reference S1 time	0.0~100% 0.0~100% 0~100% 0~100% 0~400 bar	0.0 0.0 2 100	0	0	0

Chapter 4 Parameter Functions | HES Series

ï	Parameter code	Function of the parameter	Settings	Default value	VF	FOCPG	FOCPM
×	00-49	Flow reference S2 time	0~1000ms	0	0	0	0
×	00-50	Speed bandwidth 2	0~40Hz	20	0	0	0
×	00-51	Speed bandwidth 3	0~40Hz	20	0	0	0
×	00-52	Overpressure detection time	0.000~1.000sec	0.01	0	0	0
/	00-53	Oil shortage detection time	0.0~60.0sec	0.0	0	0	0
*		Pump running reversely detection time	0.0~60.0sec	0.0	0	0	0
	00-55						
	~	Reserved					
	00-58						

01 Motor Parameters

✓ You can set this parameter during operation.

			/ Tod can set this parameter	uug .	J P C .		
	Parameter code	Function of the parameter	Settings	Default value	ΛF	FOCPG	FOCPM
	01-00	Control mode	0: VF 1: Reserved 2: Reserved 3: FOCPG 4: Reserved 5: FOCPM 6: Reserved	5	0	0	0
×	01-01	Source of operation Command	 0: Operation by using the digital keypad 1: Operation by using the external terminals. The Stop button on the keypad is disabled. 2: Communication using RS-485. The Stop button on the keypad is disabled 	1	0	0	0
	01-02	Motor's maximum operating Frequency	50.00~600.00Hz	166.67	0	0	0
	01-03	Motor's rated frequency	0.00~600.00Hz	113.33	0	0	
	01-04	Motor's rated voltage	230V Series: 0.1V~255.0V 460V Series: 0.1V~510.0V	220.0 440.0	0	0	
N	01-05	Acceleration time setting	0.00~600.00 seconds	0.00	0	0	0
N	01-06	Deceleration time setting	0.00~600.00 seconds	0.00	Ö	Ö	Ŏ
<i>'</i>	01-07	Deceleration time setting	0: No function	0	0	Ö	\vdash
	0107		1: Rolling test for induction motor(IM) (Rs, Rr, Lm, Lx, no-load current)		0	0	
		Motor Parameter Auto Tuning	2: Static test for induction motor(IM)		0	0	
			3: Reserved		0	0	
			4: Auto measure the angle between magnetic pole and PG origin				
			5: Rolling test for PM motor				0
	01-08	Rated current of the induction motor (A)	40~120% of the drive's rated current	#.##		0	
×	01-09	Rated power of the induction motor	0~655.35kW	#.##		0	
×	01-10	Rated speed of the induction motor	0~65535rpm 1710 (60Hz 4-pole); 1410 (50Hz 4-pole)	1710		0	
	01-11	Number of poles of the induction motor	2~20	4		0	
	01-12	No-load current of the induction motor (A)	0~Default value of Parameter 01-08	#.##		0	
	01-13	Stator resistance (Rs) of the induction Motor	0~65.535Ω	#.###		0	
	01-14	Rotor resistance (Rr) of the induction Motor	0~65.535Ω	#.###		0	
	01-15	Magnetizing inductance (Lm) of the induction Motor	0.0~6553.5mH	#.#		0	
	01-16	Total leakage inductance (Lx) of the induction motor	0.0~6553.5mH	#.#		0	
	01-17	Rated current of the synchronous motor	0~655.35 Amps	0.00			0
	01-18	Rated power of the synchronous motor	0.00 – 655.35kW	0.00			0
	01-19	Rated speed of the synchronous motor	0~65535rpm	1700			

Parameter code	Function of the parameter	Settings	Default value	N N	FOCPG	FOCPM
01-20	Number of poles of the synchronous motor	2~20	8			0
01-21	Inertia of the synchronous motor's rotor	0.0~6553.5 *10 ⁻⁴ kg.m ²	0.0			0
01-22	Stator's phase resistance (Rs) of the synchronous motor	0.000~65.535Ω	0.000			0
01-23	Stator's phase inductance (Ld) of the synchronous motor	0.00.0~655.35mH	0.00			0
01-24	Stator's phase inductance (Lq) of the synchronous motor	0.00.0~655.35mH	0.00			0
01-25	Back EMF of the synchronous motor	0~65535 V/ krpm	0			0
01-26	Encode type	0: ABZ 1: ABZ+HALL (only used for Delta's servo motors) 2: ABZ+HALL 3: Resolver	3			0
01-27	PG Offset angle of synchronous motor	0.0~360.0°	0.0			0
01-28	Number of poles of the resolver	1~5	1			0
01-29	Encoder pulse	1~20000	1024		0	0
01-30	Encoder's input type setting	 No function Phase A leads in a forward run command and phase B leads in a reverse run command Phase B leads in a forward run command and phase A leads in a reverse run command Phase A is a pulse input and phase B is a direction input. (low input=reverse direction, high input=forward direction) Phase A is a pulse input and phase B is a direction input. (low input=forward direction, high input=reverse direction) Single-phase input 	1			0
01-31	System control	No function ASR automatic tuning Estimation of inertia	1		0	0
01-32	Unity value of the system inertia	1~65535 (256 = 1 per unit)	260		0	0
01-33	Carrier frequency	5KHz; 10KHz	5	0	0	0
01-34	Reserved Motor ID	0 : Disabled See 4-2 Description of Parameter Settings for more information	0	0	0	0
01-36	Change the rotation direction	 When the driver runs forward, the motor rotates counterclockwise. When the driver runs reverse, the motor rotates clockwise. When the driver runs forward, the motor rotates clockwise. When the driver runs reverse, the motor rotates counterclockwise. 	0	0	0	0
01-37	HES ID#	0: Disabled See 4-2 Description of Parameter Settings for more information	0	0	0	0

Chapter 4 Parameter Functions | HES Series

	Parameter code	Function of the parameter	Settings	Default value	VF	FOCPG	FOCPM
N	01-30	Flux-Weakening voltage level	0~100V	10V	0	0	0

02 Parameters for Protection

✓ You can set this parameter during operation.

	Parameter code	Function of the parameter	Settings	Default value	VF	FOCPG	FOCPM
~	02-00	Software brake level	230V series: 350.0~450.0V _{DC} 460V series: 700.0~900.0V _{DC}	380.0 760.0	0	0	0
	02-01	Present fault record	0: No error record	0	0	0	
	02-02	Second most recent fault record	1: Over-current during acceleration (ocA)	0	0	0	0
	02-03	Third most recent fault record	2: Over-current during deceleration (ocd)	0	0	0	0
	02-04	Fourth most recent fault record	3: Over-current during constant speed (ocn)	0	0	0	0
	02-05	Fifth most recent fault record	4: Ground fault (GFF)	0	0	0	0
	02-06	Sixth most recent fault record	5: IGBT short-circuit (occ)	0	0	0	0
			6: Over-current at stop (ocS)		0	0	
			7: Over-voltage during acceleration (ovA)		0	0	0
			8: Over-voltage during deceleration (ovd)		0	0	0
			9: Over-voltage during constant speed (ovn)		0	0	
			10: Over-voltage at stop (ovS)		Ŏ	Ŏ	Ō
			11: Low-voltage during acceleration (LvA)		Ŏ	Ŏ	Ŏ
			12: Low-voltage during deceleration (LvA)			0	
					0	0	
			13: Low-voltage during constant speed (Lvn)			0	
			14: Low-voltage at stop (LvS)				
			15: Phase loss protection (PHL)		0	0	0
			16: IGBT over-heat (oH1)		0	0	0
			17: Heat sink over-heat for 40HP and above (oH2)		0	0	0
			18: TH1 open: IGBT over-heat protection circuit error (tH1o)		0	0	
			19: TH2 open: heat sink over-heat protection circuit error (tH2o)		0	0	
			20: IGBT over heated and unusual fan function (oHF)			0	
			21: Hybrid Servo Controller overload (oL)			0	
			· · · · · · · · · · · · · · · · · · ·			_	
			22: Motor over-load (EoL1)			0	
			23: Reserved				
			24: Motor over-heat, detect by PTC (oH3) 25: Reserved		0	0	0
			26: Over-torque 1 (ot1)			0	
			27: Over-torque 2 (ot2)		0	0	
			28: Reserved		0	0	
			29: Reserved		0	0	
			30: Memory write error (cF1)		0	0	
			31: Memory read error (cF2)		0	0	
			32: Isum current detection error (cd0)			0	
			33: U-phase current detection error (cd1)		Ō	Ŏ	Ŏ
			34: V-phase current detection error (cd2)		Ö	Ŏ	Ŏ
			35: W-phase current detection error (cd3)		0	Ö	
			36: Clamp current detection error (Hd0)			0	
					0	0	
			37: Over-current detection error (Hd1)			0	$\overline{}$
			38: Over-voltage detection error (Hd2)				
			39: Ground current detection error (Hd3)		0	0	
			40: Auto tuning error (AuE)		<u> </u>	0	
			41: Reserved			0	0
			42: PG feedback error (PGF1)			0	0
			43: PG feedback loss (PGF2)			0	
			44: PG feedback stall (PGF3)				

Parameter code	Function of the parameter	Settings Default value	∀	FOCPG	
		45: PG slip error (PGF4)			T
		46: Reserved	0	0	T
		47: Reserved	O	0	Ť
		48: Reserved			Ť
		49: External fault input (EF)			$^{+}$
		50: Emergency stop (EF1)		10	†
		51: Reserved			+
		52: Password error(PcodE)		0	+
		53: Reserved			+
					+
		54: Communication error (cE1)			+
		55: Communication error (cE2)	0	0	+
		56: Communication error (cE3)	0	0	4
		57: Communication error (cE4)	0	0	1
		58: Communication time out (cE10)	0	0	1
		59: PU time out (cP10)	0	0	
		60: Braking transistor error (bF)	0	0	
		61~6: Reserved	0	0	Ī
			0	0	Ť
		65: PG card information error (PGF5)			t
		66: Over pressure (ovP)			+
		67: Pressure feedback fault (PfbF)		10	+
		68: Oil pump runs reversely (Prev)	+		+
		69: Oil shortage warning (noil)			+
					+
		70: Reserved			+
02-07	Low voltage level	160.0~220.0V _{DC} 180.0 320.0.0~440.0V _{DC} 360.0			
	-	020.0.0 440.0 ()00			+
00.00		0: Warn and keep operation			
02-08	PTC action selection	1: Warn and ramp to stop			
		2: Warn and coast to stop			4
02-09	PTC level	0.0~150.0%			
		0.0~150.0°C			4
02-10	PTC detection filtering time		0		4
02-11	PTC type	0: Not assigned 0			
	. 10 350	1: KTY84			4
02-12	Motor fan activation level	0.0~100.0%			
	Motor fair activation level	0.0~150.0°C		\perp	
	Electronic thermal relay	0: Inverter motor			
02-13	selection 1	1: Standard motor 2			
	JOICOHOTT I	2: Disable			1
02-14	Electronic thermal	30.0~600.0 seconds 60.0			
0 <u> 1</u> 1 7	characteristic for motor	00.0 000.0 seconds			1
02-15	Output frequency at malfunction	0.00~655.35 Hz Read on	y O	0	
02-16	Output voltage at malfunction	0.0~6553.5 V Read on	ly O	0	
02-17	DC voltage at malfunction	0.0~6553.5 V Read on	ly O	0	Ť
02-18	Output current at malfunction	0~655.35 Amps Read on	_	0	
02-19	IGBT temperature at malfunction	0.0~6553.5 °C Read on	ly O	0	
02-20	Clear errors	0: Disable, 1: Enable 0			+
00.01	automatically(LvX)	,		1	4
02-21	Input the parameter protection password	1 ~ 9998			
02-22	Set up a parameter protection password	1~9988, 10000 ~ 65535			Ī

03 Digital/Analog Input/Output Parameters

✓ You can set this parameter during operation.

Parameter code	Function of the parameter	Settings	Default value	Ϋ́	FOCPG	
03-00	Multi-function input command 3 (MI3)	0: No function 44: Injection signal input	0	0	0	
03-01	Multi-function input command 4 (MI4)	45: Confluence/Diversion signal input 46: Reserved	0	0	0	
03-02	Multi-function input command 5 (MI5)	47: Multi-level pressure PI command 1 48: Multi-level pressure PI command 2 51: flow command	0	0	0	
03-03	Digital input response time	0.001~ 30.000 sec	0.005	0	0	
03-04	Digital input operation direction	0~65535	0	0	0	
03-05	Multi-function output 1 (Relay 1)	No function Operation indication	11	0	0	
03-06	Multi-function Output 2 (MO1)	9: Hybrid Servo Controller is ready 11: Error indication	0	0	0	
03-07	Multi-function Output 3 (MO2)	14: MO1 software brake output44: Displacement switch signal45: Motor fan control signal	0	0	0	
03-08	Multi-function output direction	0~65535	0		0	
03-09	Low-pass filter time of keypad display	0.001~65.535 seconds	0.100	0	0	
03-10	Maximum output voltage for pressure feedback	5.0~10.0 V	10.0	0	0	
03-11	Minimum output voltage for pressure feedback	0.0~2.0 V	0.0	0	0	
03-12	Type of Pressure Feedback Selection	0: Current 1: Voltage	1			
03-13	Confluence Master/Slave Selection	0: No function1: Master 12: Slave/Master 23: Slave/Master 3	0	0	0	
03-14	Slave's proportion of the Master's flow	0.0~65535.5 %	100.0	0	0	
03-15	Source of frequency command	0: Digital keypad 1: RS485 Communication 2~5: Reserved	0	0	0	
03-16	Limit for the Slave reverse depressurization torque	0~500%	20	0	0	
03-17	Slave's activation level	0.0~100.0%	50.0	0	0	
03-18	Communication error treatment	0: Warn and keep operation1: Warn and ramp to stop2: Warn and coast to stop3: No action and no display	3	0	0	
03-19	Time-out detection	0.0~100.0 seconds	0.100	0	0	(
03-20	Start-up display selection	0: F (frequency command) 1: H (actual frequency) 2: Multi-function display (user-defined 00-04) 3: A (Output current)	0	0	0	(
03-21	Slave reverse operation for depressurization	0: Disabled 1: Enabled	0	0	0	(
03-22	Slave closing level	0 ~ 400	400		6	

4-2 Description of Parameter Settings

00 System Parameters

✓ You can set this parameter during operation

- ## Hybrid Servo Controller model code ID

Read only

Control mode VF FOCPG FOCPM

Factory default: Read only

Settings Read only

??? - ?? : Display of rated current of the Hybrid Servo Controller

Control mode VF FOCPG FOCPM

Settings

Factory default: Read only

Parameter 00-00 is used to determine the capacity of the Hybrid servo motor which has been configured in this parameter in factory. In addition, the current value of Parameter (00-01) can be read out to check if it is the rated current of the corresponding model. Display value of the current value of Parameter 00-01 for the related Parameter 00-00.

	230V Series								
Power (KW)	11	15	18.5	22	30	37			
Horse Power (HP)	7.5	10	15	20	25	30	40	50	
Model ID	12	14	16	18	20	22	24	26	

460V Series											
Power (KW)	5.5	7.5	11	15	18.5	22	30	37	45	55	75
Horse Power (HP)	7.5	10	15	20	25	30	40	50	60	75	100
Model ID	13	15	17	19	21	23	25	27	29	31	33

Reset parameter settings

Control mode VF FOCPG FOCPM

Factory default: 0

Settings

Settings

0: No function

1: Parameter locked

5: Rest the kWh at drive stop

10: Reset parameter values

If it is necessary to restore the parameters to factory default, just set this parameter to "10".

00-03

Software version

Control mode

Control mode

VF FOCPG FOCPM

Factory default: #.##

Selection of multi-function display

Settings 0: Display the output current (A)

Read only

FOCPG FOCPM

1: Reserved

2: Display the actual output frequency (H)

Display the DC-BUS voltage (U)

4: Display the output voltage (E)

5: Display the output power angle (n)

6: Display the output power in kW (P)

Factory default: 0

[65503]

"n 00

, P0.000

Factory default: 0

- 7: Display the actual motor speed(r 00: forward speed; 00: negative speed) 8: Display the estimated output torque (%) (t 0.0: positive torque; - 0.0: negative torque) (%) 9: Display the PG feedback (G) 10: Reserved 11: Display the signal value of the analog input terminal PO with $0\sim10V$ mapped to $0\sim100\%$ 12: Display the signal value of the analog input terminal PI with 0~10V mapped to 0~100% 13: Display the signal value of the analog input terminal PI with -10~10V mapped to 0~100% 14: Display temperature of the heat sink in °C (t.) 15: Display temperature of the IGBT power module °C 16: The status of digital input (ON/OFF) 17: The status of digital output (ON/OFF) 18: Reserved 19: The corresponding CPU pin status of the digital input 20: The corresponding CPU pin status of the digital output 21~24: Reserved 25: Display the signal value of the analog input terminal OI with 0~10V mapped to 0~100% 26: Display the actual pressure value (Bar) 27: Display the kWh value 28: Display the motor temperature (currently only support KTY84) 29: Over load rate of motor drive (OL occurred when reaching 100%) 30: Over load rate of motor with last digit A of HES (EOL1 occurred when reaching 100%)
- This parameter defines the contents to be displayed in the U page of the digital keypad KPV-CE01 (as shown in the figure).

Analog output function selection

Control mode VF FOCPG FOCPI Settings 0~20

FOCPG FOCPM

Summary of functions

Setting Value	Function	Description		
0	Output frequency (Hz)	The maximum frequency is 100%		
1	Frequency command (Hz)	The maximum frequency is 100%		
2	Motor speed (Hz)	600Hz is used as 100%		
3	Output current (A)	2.5 times of the rated current of the Hybrid Servo		
		Controller is used as 100%		
4	Output voltage	2 times of the rated current of the Hybrid Servo		
		Controller is used as 100%		
5	DC BUS voltage	450V (900V) =100%		

stable.

6	Power factor	-1.000~1.000=100%
7	Power	Rated power of the drive =100%
8	Output torque	Rated torque =100%
9	PO	(0~10V=0~100%)
10	PI	(0~10V=0~100%)
11	AUI	(-10~10V=0~100%)
12~20	Reserved	

	88] - {} { Display the speed (rpm) defined by th	ne user
	Con	ntrol mode VF FOCPG FOCPM Settings 0~39999 rpm	Factory default: 0
		Set the maximum speed of the motor corresponding	g to the 100% flow.
		When the control mode is FOCPM(Pr01-00=5), Pro	00-06 will follow the setting at Pr01-20
		<number motor="" of="" poles="" synchronous="" the=""> to m</number>	odify Pr01-02 <motor's maximum="" operating<="" td=""></motor's>
		frequency>. frequency = rpm*Pole/120	
~	80	├ - [] 	nmand
	Con	ntrol mode VF FOCPG FOCPM Settings 0~400Bar	Factory default: 250
		The 0~10V for the pressure command on the contr parameter.	oller is mapped to 0~the value of this
		Firmware version 2.04 and above, maximum value allowed value is 250Bar.	400Bar, the previous version's maximum
		When setting up Pr00-07 and Pr00-08, Pr00-14 <pe (max)="" and="" be="" bigger="" command="" for="" is="" pr00-15<percentage="" pressure="" set="" th="" the="" up.<=""><th>ommand value (Mid) will also be modified.</th></pe>	ommand value (Mid) will also be modified.
		Pr00-07 can be set up while the motor drive is runr Pr00-08.	ning, but Pr00-07 has to be smaller than
✓	80	3 - 38 Maximum pressure feedback value	
	Con	ntrol mode VF FOCPG FOCPM Settings 0~400Bar	Factory default: 250
		The 0~10V for the pressure sensor is mapped to 0	~the value of this parameter.
	88	? - [] ? Pressure control mode	
	Con	ntrol mode VF FOCPG FOCPM Settings 0: Speed control 1: Pressure control	Factory default: 0
		This parameter determines the control mode of the I	Hybrid Servo Controller. It is recommended
	,	to use the speed control at the initial start up. After t	he motor, pump, pressure sensor, and the
		entire system are checked without any error, switch	to the pressure control mode to enter the
		process control.	

When under Pr00-09<Pressure control mode>, Pr01-05<Acceleration time setting> and


Pr01-06<Deceleration time setting> have to be set as 0 to make the pressure control mode

	☐ ☐ - ☐ Control mode	-	oandwidth Focpg Focpm 0~40Hz			Factory default: 20
	Set the	e speed re	sponse. The lar	ger value indicates	the faster respo	onse.
N	88-11	Pressur	e feedback fil	Itering time PO		
N	00 - 12	Pressur	re Command	Filter Time PI		
×	Control mode		re Command FOCPG FOCPM	Filter Time QI		F
	Control mode	Settings	0.000~1.00	00 seconds		Factory default: 0.000
	Noises r	may reside	e in the analog in	nput signals of the	control terminals	PO, PI, and QI. The noise
	may affe	ect the cor	าtrol stability. Us	e an input filter to e	eliminate such no	oise.
					•	rer control response. If it is
			-		-	timal setting is not known,
	adjust it	properly a	according to the	instability or respo	nse delay.	
N	00	Doroont	taga of the pr	accura common	d valua (MAV)	1
<i>,</i> ,	Control mode		age of the pre	essure comman	u value (IVIAA)) Factory default: 56.0
	Control mode	Settings	0.0 ~ 100.0%			r actory default. 50.0
N	00-15		•	essure comman	d value (Mid)	
	Control mode		FOCPG FOCPM			Factory default: 28.0
N	00 10	Settings	0.0 ~ 100.0%	accura comman	d value (Min)	
<i>,</i> .	Control mode		TOCPG FOCPM	essure comman	u value (IVIIII)	Factory default: 0.0
	Control mode	Settings				r dotory deladit. 0.0
	When se	etting up F	²r00-07 <max. th="" va<=""><th>alue for the pressur</th><th>re command> an</th><th>nd Pr00-08<max. pressure<="" th=""></max.></th></max.>	alue for the pressur	re command> an	nd Pr00-08 <max. pressure<="" th=""></max.>
	feedbac	k value>,	Pr00-14 and Pr	00-15 will also be n	nodified. Howeve	er when the pressure
	commar	nd is bigge	er than the press	sure feedback, Pr00	0-07 cannot be s	et up.
	Pr00-07 Pr00-08		et up while the n	notor drive is runnir	ng, but Pr00-07 h	nas to be smaller than
			meters. it is nec	essary to set Parar	meter 00-09 as 1	
		=	= 12 for PI inpu	-		
	Send th	ne maximu	ım pressure con	nmand through the	controller and th	nen check the
	multi-fu	nction disp	play page to ent	er this value into 00	0-14	
			sure command the value into 00-1		er and then chec	k the multi-function display


Send the minimum pressure command through the controller and then check the multi-function display page to enter this value into 00-16

Example: If the pressure sensor indicates 250bar at 10V. If the controller's maximum pressure of 140bar corresponds to 10V, then Parameter 00-07=140. Set the pressure as 140bar by using the controller, the voltage value shown on the display is about 56.0 (140/250 * 100%). Enter this value into the Parameter 00-14. Then set the pressure as 70bar on the controller, and now the value displayed on the keypad is about 28.0 (70/250 * 100%). Enter this value to the Parameter 00-15. Then set the pressure as 0 bar on controller, and the voltage value shown on the keypad is about 0.0 (0/250 * 100%). Enter this value in the Parameter 00-16.

N	Percentage of the flow command value (Max)	
	Control mode VF FOCPG FOCPM	Factory default: 100.0
	Settings 0.0~100.0%	
N	Percentage of the flow command value (Mid)	
	Control mode VF FOCPG FOCPM	Factory default: 50.0
	Settings 0.0~100.0%	
N	Percentage of the flow command value (Min)	
	Control mode VF FOCPG FOCPM	Factory default: 0.0
	Settings 0.0~100.0%	
	☐ To set these parameters, it is necessary to set Parameter 00-09 a	s 1
	Parameter 00-04 = 25 for QI input voltage	
	Send the 100% flow rate through the controller and then check the	e multi-function display page
	to enter this value into 00-17	nee e e i
	Send the 50% flow rate through the controller and then check the enter this value into 00-18	multi-function display page to
	Send the 0% flow rate through the controller and then check the r	nulti-function display page to
	enter this value into 00-19	nati ranotion display page to
,		
N	## - 2 ## P gain 1	
N	## - 2 ≥ P gain 2	
N	00-24 P gain 3	
	Control mode VF FOCPG FOCPM	Factory default: 50.0
	Settings 0.0∼1000.0	radiory default. Colo
×	∏ - ≥ † I integration time 1	
N	☐☐ - 2 3 I integration time 2	
N	## - ≥ 5 I integration time 3	
,	Control mode VF FOCPG FOCPM	Footomy defaults 2.00
	Settings 0.00~500.00 seconds	Factory default: 2.00
	County Clob Cooled Cooled	
*	⊕ ⊕	
N	### Differential gain 2	
×	Differential gain 3	
	Control mode VF FOCPG FOCPM	Factory setting: 0.0
	Settings 0.0~100.0 %	
	This parameter is functional only when Bit0 and Bit2 = 1 at Pr00-3	8.
M	00 10 Draggura stable region	
7*	Pressure stable region	
	Control mode VF FOCPG FOCPM	Factory default: 25
	Settings 0~100%	



Adjust the Kp value to a proper level first, and then adjust the Ki value (time). If the pressure has overshoot, adjust the kd value.



Base pressure

Control mode **VF FOCPG FOCPM**Settings 0.0~100.0%

Factory default: 0.1

- Set the minimum pressure value 100% corresponding to Parameter 00-08
- Typically, it is necessary to maintain a certain base pressure to ensure that the oil pipe is in fully filled condition so as to avoid the activation delay of the cylinder when a pressure/flow command is activated.

Control mode VF FOCPG FOCPM

Settings 0~100%

Factory default: 25

Set the highest rotation speed at depressurization. The 100% value is mapped to Parameter 01-02 (the maximum rotation speed of the motor)

Ramp up rate of pressure command

Control mode VF FOCPG FOCPM Factory default: 0

Settings 0~1000ms

Ramp down rate of pressure command


Control mode VF FOCPG FOCPM Factory default: 100

Settings 0~1000ms

Ramp the pressure value for the pressure command so as to reduce the vibration of the

Ramp the pressure value for the pressure command so as to reduce the vibration of the machine.

Set the time required for ramping the pressure from 0~the maximum pressure (00-08).




Ramp up rate of flow command
Ramp down rate of flow command

Control mode VF FOCPG FOCPM
Settings 0~1000ms

Factory default: 80

Ramp the flow value for the flow command so as to reduce the vibration of the machine.

☐ Set the time required for ramping the flow from 0~the maximum flow (01-02).




✓ ☐☐ - 3 3 Valve opening delay time

Control mode VF FOCPG FOCPM Settings 0~200ms

Factory default: 0

When both the pressure command and flow command activate the machine to start from idle, the flow starts to output. However, due to the slower response of the valve in the hydraulic circuit, the sudden surge of the pressure may occur. The pressure may recover to normal till the valve is fully opened. To avoid the aforementioned effect, set this parameter to increase time for the flow output delay.



Factory default: 0

Reserved

Overpressure detection level

FOCPG FOCPM Control mode Factory default: 230

> 0~400 Bar Settings

When the pressure feedback exceeds this parameter setting, an "ovP over pressure" error message may occur.

Firmware version 2.04 and above, maximum value 400Bar, the previous version's maximum allowed value is 250Bar.

Overpressure Detection Time

Settings

VF FOCPG FOCPM Control mode Factory defualt: 0.01

Settings 0.0000~ 1.0000 sec

Detection of disconnection of pressure feedback

0: No function

188 - 361

FOCPG FOCPM Control mode

1: Enable (only for the pressure feedback output signal within 1~5V and

4~20mA)

When this parameter is set as 1 and if the pressure feedback signal is below 1V or 4mA, an "Pfbf pressure feedback fault" error message may occur.

Pressure/flow control function selection

FOCPG FOCPM Control mode Factory default: 0

Bit 0:

Settings 0: Switch the PI Gain according to the pressure feedback level

1: Switch the PI Gain according to the multi-function input terminal

0: No pressure/flow control switch

1: Switch between the pressure and flow control

When the Bit 0 of this parameter is set as 1, the PI Gain for the pressure can be switched in conjunction with the multi-function input terminal

Pr. 03-00~03-02 d= 47	Pr. 03-00~03-02 d= 48	
OFF	OFF	PI1(Parameters 00-20 & 00-21)
ON	OFF	PI2(Parameters 00-22 & 00-23)
OFF	ON	PI3(Parameters 00-24 & 00-25)

When the Bit 1 of this parameter is set as 1, the pressure feedback is lower than the pressure stable region (please refer to the description of Parameter 00-26) so the flow control will be performed. When it enters the pressure stable region, the pressure control will be performed.

Integration Time – Pressure Overshoot 1

FOCPG FOCPM Control mode Factory default: 0.2

Settings 0.00~500.00 seconds


Level of the pressure overshoot

FOCPG FOCPM Control mode Factory default: 2 Settings 0~100%


By using the factory setting 250 bar of the Pr00-08 Maximum Pressure Feedback, when the pressure is over 5 bar (250*2%=5 bar), another integral time of Pr00-39 will do overshoot protection.

When Pr00-38=1 and Pr00-39=0, Pr00-42 is disable.





Set Pr00-42≠0



Percentage of the maximum flow

FOCPG FOCPM Control mode

Settings 0~100%

Set up this parameter to adjust the maximum rotation frequency (maximum flow rate). It is not necessary to stop the motor drive to set up this parameter. When this parameter is set to be 100%, it corresponds to the maximum rotation frequency of Pr01-02.

Pressure Command

FOCPG FOCPM Control mode

Factory default: 0

Factory default: 100

Settings 0~400bar

88-451 Percentage of Flow command

FOCPG FOCPM VF Control mode

Factory default: 0

0~100% Settings

- When Pr00-44 \neq 0, Pressure Command will not be given by the analog signal but input by Pr00-44.
- When Pr00-45 \neq 0, Flow Command will not be given by the analog signal but input by Pr00-45.
- Pr00-44 & Pr00-45 can be applied in an environment without input of analog signal to do simple test.



Pressure Command Rising/ Descending S1 curve

VF FOCPG FOCPM Settings 0~1000ms

Factory default: 0




Pressure Command Rising/ Descending S2 Curve

Control mode VF FOCPG FOCPM Settings 0~1000ms

Factory default: 0

To increase the smoothness at start or stop while increasing or decreasing the percentage of the pressure command. The longer the pressure reference time, the smoother it will be.





Pressure Command Rising/ Descending S1 Curve

ontrol mode VF FOCPG FOCPM
Settings 0~1000ms

Factory default : 0




Flow Command Rising/. Descending S2 Curve

Control mode VF FOCPG FOCPM

Factory default : 0

Settings 0~1000ms

To increase the smoothness at start or stop while increasing or decreasing the percentage of the flow command. The longer the flow reference time, the smoother it will be.



N	88-58	Speed bandwidth 2		
	Control mode	FOCPG FOCP	M	Factory default : 20
	Common mode	Settings 0 ~ 40Hz	•••	r dotory doladit . 20
₩	00 6 1	Speed bandwidth 3		
^	<u> </u>	Speed bandwidth 3		
	Control mode	FOCPG FOCP	М	Factory default : 20
		Settings 0~40Hz		
	To set	ıp the response speed,	the larger the value, the faster	the reponse.
~	בכ-טט	Oil shortage detection t	ime	
	Control mode	VF FOCPG FOCP		Factory default : 0.0
		Settings 0.0 ~60.0 se		(D.00.07)
		<u>•</u>	wer than the minimum pressure rtage warning will pop up on the	,
		•	nly when Pr00-09 (Pressure cor	y •
	•	his parameter is set to		
./	00 511	0:1	a de da da de	
/	86-99	Oil pump running revers	sely detection time	
	Control mode	VF FOCPG FOCP		Factory default : 0.0
		Settings 0.0 ~60.0 sec		
			sely and exceeds the time set a	t Pr00-54, a reverse running
	pops u		O it is disabled	
	www vviieli	his parameter is set to	ว, เเาอ นเอสมเซน.	
	00-55			
	~	Reserved		
	00-58			

01 Motor Parameters

✓ You can set this parameter during operation.

! - ## Control mode

Control mode VF FOCPG FOCPM Factory default: 5

0:V/F

1: Reserved 2: Reserved

3: FOCPG

Settings

4: Reserved

5: FOCPM 6: Reserved

This parameter determines the control mode of this AC motor.

0: V/F control, the user can design the required V/F ratio. It is used for induction motors.

- 1: Reserved
- 2: Reserved
- 3: FOC vector control + Encoder. It is used for induction motors.
- 4: Reserved
- 5: FOC vector control + Encoder. It is used for synchronous motors.

 When the control mode is FOCPM (Pr01-00=5), Pr00-06 will follow the setting at Pr01-20

 <Number of poles of the synchronous motor> to modify Pr01-02<Motor's maximum operating frequency>. Frequency = rpm*Pole/120
- 6: Reserved

Source of operation command

Control mode VF FOCPG FOCPM

Factory default: 1

Settings 0: Th

0: The operation command is controlled by the digital keypad1: The operation command is controlled by the external terminals.

The STOP button on the keypad panel is disabled

The operation command is controlled by RS4845.The STOP button on the keypad panel is disabled

For the operation command, press the PU button to allow the "PU" indicator to be lit. In this case, the RUN, JOG, and STOP button are enabled.

☐ : - ☐ ☐ Motor's maximum operating frequency

Control mode VF FOCPG FOCPM Factory default: 166.67

Settings 50.00~600.00Hz

Set the maximum operation frequency range of the motor. This setting is corresponding to the maximum flow for the system.

When the control mode is FOCPM (Pr01-00=5), Pr00-06 will follow the setting at Pr01-20 <Number of poles of the synchronous motor> to modify Pr01-02<Motor's maximum operating frequency>. frequency = rpm*Pole/120

Control mode VF FOCPG FOCPM Factory default: 113.33 Settings 0.00~600.00Hz

Typically, this setting is configured according to the rated voltage and frequency listed in the specifications on the motor's nameplate. If the motor is intended for 60Hz, set this value as 60Hz; if the motor is intended for 50Hz, set this value as 50Hz.

☐ The motor's rated frequency will be different as Rated speed of the synchronous motor

(Pr01-19) and Number of poles of the synchronous motor (Pr.01-20) change.

₩ - ₩ Motor's rated voltage

FOCPG Control mode **VF** Factory default: 220.0/440.0

> Settings 230V series: 0.1~255.0V 460V series: 0.1~510.0V

Typically, this setting is configured according to the rated operation voltage shown on the motor's nameplate. If the motor is intended for 220V, set this value as 220.0V; if the motor is intended for 200V, set this value as 200.0V.

Acceleration time setting

VF **FOCPG FOCPM** Control mode Factory default: 0.00

Settings 0.00~600.00 seconds

Deceleration time setting

FOCPG FOCPM **VF** Control mode Factory default: 0.00 0.00~600.00 seconds Settings

The acceleration time determines the time required for the Hybrid servo motor to accelerate from 0.0Hz to [the motor's maximum frequency] (Pr01-02). The deceleration time determines the time required for the Hybrid servo motor to decelerate from [the motor's maximum frequency] (Pr01-02) to 0.0Hz.


When the control mode is FOCPM (Pr01-00=5), Pr00-06 will follow the setting at Pr01-20 <Number of poles of the synchronous motor> to modify Pr01-02<Motor's maximum operating frequency>. frequency = rpm*Pole/120

Factory default: 0 FOCPG FOCPM Control mode VF Settings 0: No function 1: Rolling test for induction motor(IM) (Rs, Rr, Lm, 0 Lx, no-load current) 2: Static test for induction motor(IM) 3: Reserved 4: Auto measure the angle between magnetic pole 0 and PG origin 5: Rolling test for PM motor

If the parameter is set as 1~2, it will perform the parameter automatic tuning for the Induction motor. In this case, press the [Run] button to perform the automatic measurement operation immediately. After the measurement is complete, the values are filled into Parameters 01-13~16 (no-load current, Rs, Rr, Lm, and Lx), respectively. Induction motor AUTO-Tuning procedure: (Rolling test)

- All parameters of the Hybrid Servo Controller are set to factory settings and the motor is connected correctly.
- 2. Users are strongly advised to disconnect the motor from any load before tuning. That is to say, the motor contains only the output shaft and connects to neither a belt nor a decelerator. Otherwise, it will be impossible to disconnect the motor from any loads. Static tuning is advised.
- Set the rated voltage 01-04, rated frequency 01-03, rated current 01-08, rated power 01-09, 3. rated speed 01-10, and number of poles 01-11 of the motor with correct values, respectively. For the acceleration/deceleration time, please set the correct values.

- 4. Set Pr01-07 as 1 and then press the RUN button on the keypad. The auto tuning process for the motor is carried out immediately. (Note: the motor starts running).
- 5. After the process is finished, check if the motor's parameters (Pr01-13 ~Pr01-16) have been automatically entered with the measurement data.
- 6. Equivalent circuit of the motor





* When the static tuning (Pr01-07 = 2) is used, you must enter the no-load current to the motor. It is generally 20 to 50% of the rated current.

If the parameter is set as 5, it will perform the parameter automatic tuning for the synchronous motor. In this case, press the [Run] button to perform the automatic measurement operation immediately. After the measurement is complete, the values are filled into Parameters 01-22 (Rs), 01-23 & 24 (Ld & Lq), 01-25 (Back EMF of the synchronous motor), respectively.

Synchronous motor *AUTO-Tuning procedure:* (static measurement)

- 1. All parameters of the Hybrid Servo Controller are set to factory settings and the motor is connected correctly.
- 2. Set the rated current 01-17, rated power 01-18, rated speed 01-19, and number of poles 01-20 of the motor with correct values, respectively. For the acceleration/deceleration time, set the values according to the motor's capacity.
- Set Parameter 01-07 as 5 and then press the RUN button. The auto tuning process for the motor is carried out immediately. (Note: the motor starts running slightly).
- 4. After the process is finished, check if the motor's parameters (parameters 01-22 ~ 01-25) have been automatically entered with the measurement data.
- If the Parameter is set as 4, the automatic measurement of the angle between magnetic pole and the PG origin for the synchronous motor is performed. In this case, press the [Run] button to immediately perform automatic measurement. The measured data will be entered into Parameter 01 -27.

Auto-Tuning process for Synchronous Motor of the Angle between Magnetic Poles and PG Origin:

- 1. Set Pr01-07 as 5 <Rolling test for PM motor> and run this setting. Or input the correct vales to Pr01-03, Pr01-17 to Pr01-25.
- 2. Before tuning, it is recommended to separate the motor and the load.
- 3. Set Pr01-07 as 4 and then press the RUN button on the keypad. The auto tuning process for the motor is carried out immediately. (Note: the motor starts running).
- 4. After the process is complete, check if the values for the angle between magnetic poles and PG origin have been automatically entered in Pr01-27.

Rated current of the induction motor (A) Unit: Ampere Control mode **FOCPG** Factory default: #.## Settings 40~120% of the rated driving current To set this parameter, the user can set the rated motor current range shown on the motor's nameplate. The factory default is 90% of the rated current of the Hybrid Servo Controller. For example: For the 7.5HP (5.5kW) motor, the rated current is 25, the factory settings: 22.5A. The customers can set the parameter within the range $10 \sim 30$ A. 25*40%=10 25*120%=30 Rated power of the induction motor **FOCPG** Control mode Factory default: #.## 0 - 655.35kW Settings Set the motor's rated power. The factory default value is the power of the Hybrid Servo Controller. Rated speed of the induction motor Factory default: **FOCPG** 1710 (60Hz 4-pole) Control mode 1410 (50Hz 4-pole) Settings 0~65535 This parameter sets the rated speed of the motor. It is necessary to refer to the specifications shown on the motor's nameplate. **FOCPG** Control mode Factory default: 4 Settings 2~20 This parameter sets the number of motor number of poles (odd number is not allowed). No-load current of the induction motor (A) Unit: Ampere Control mode **FOCPG** Factory default: 40 Settings 0~ Default value of Parameter 01-08 The factory default is 40% of the rated current of the Hybrid Servo Controller. **FIGURE 13** Stator resistance (Rs) of the induction motor Control mode Factory default: #.## # { - } Rotor resistance (Rr) of the induction motor Control mode **FOCPG** Factory default: #.## Settings $0 \sim 65.535 \Omega$ Magnetizing inductance (Lm) of the induction motor Control mode Factory default: #.## Total leakage inductance (Lx) of the induction motor 1- 15 Control mode **FOCPG** Factory default: #.## Settings 0.0~6553.5mH Rated current of the synchronous motor | - | Control mode **FOCPM** Factory default: 0.00 0~655.35 Amps Settings The user can set the rated current shown on the synchronous motor's nameplate.

Rated power of the synchronous motor

Control mode FOCPM Factory default: 0.00

Settings 0.00 – 655.35kW

☐ This Parameter sets the rated power of the synchronous motor.

Rated speed of the synchronous motor

Control mode FOCPM Factory default: 1700

Settings 0~65535

This parameter sets the rated speed of the synchronous motor. It is necessary to refer to the specifications shown on the motor's nameplate.

Control mode FOCPM Factory default: 8

Settings 2~20

This parameter sets the number of the synchronous motor's number of poles (odd number is not allowed).

! ! - ? ! Inertia of the synchronous motor's rotor

Control mode FOCPM Factory default: 0.0

Settings 0.0~6553.5 *10⁻⁴ kg.m2

☐ : - ? ? Stator's phase resistance (Rs) oth the synchronous motor

Control mode FOCPM Factory default: 0

Settings $0\sim65.535\Omega$

Enter the phase resistance of the synchronous motor.

:- 2 3 stator's phase inductance(Ld) of the synchronous motor # :- 2 4 stator's phase inductance(Lq) of the synchronous motor

Control mode FOCPM Factory default: 0.00

Settings 0.0~655.35mH

Enter the synchronous motor's phase inductance. For surface type magnets (SPM), Ld = Lq; for built-in magnets (IPM), Ld \neq Lq.

Back EMF of the synchronous motor

Control mode FOCPM Factory default: 0

Settings 0~65535 V/krpm

Enter the back EMF of the synchronous motor.

:- ₽# Encoder type selection

Control mode FOCPM Factory default: 3

Settings 0: ABZ

1: ABZ+HALL (only used for Delta's servo motors)

2: ABZ+HALL 3: Resolver

Look up table for Encoders & PG cards

Parameter Setting	Encoder Type	Applicable PG Card	
01-26=0	A, B, Z EMVJ-PG0		
01-26=1,2	A, B, Z+U, V, W	EMVJ-PG01U	
01-26=3	Resolver	EMVJ-PG01/02R	

☐ ! - ≥ ? PG Offset angle of synchronous motor

Control mode FOCPM Factory default: 0.0

Settings $0.0\sim360.0^{\circ}$

Offset angle of the PG origin for the synchronous motor.

Control mode FOCPM Factory default: 1

Settings 1~5

! - 23 Encoder Pulse

Control mode FOCPG FOCPM Factory default: 1024


Settings 1~20000

This parameter can be set the encoder's number of pulses per revolution (PPR).


Control mode FOCPG FOCPM Factory default: 1

Settings 0: No function


1: Phase A leads in a forward run command and phase B leads in a reverse run command.




2: Phase B leads in a forward run command and phase A leads in a reverse run command.




3: Phase A is a pulse input and phase B is a direction input. (low input=reverse direction, high input=forward direction).



4: Phase A is a pulse input and phase B is a direction input. (low input=forward direction, high input=reverse direction).



5: Single-phase input



Enter the correct setting for the pulse type is helpful in controlling the stability.

😗 ; - 🖁 🕴 System control

Control mode FOCPG FOCPM Factory default: 1

Settings 0: No function

1: ASR automatic tuning2: Estimation of inertia

If the setting value is 1: The speed control gain is determined by Parameters 00-10
If the setting value is 2: The system inertia is estimated. Please refer to descriptions in Chapter 3

Factory default: 260



3.2 Unity value of the system inertia

 $1\sim65535$ (256 = 1 per unit) Settings

FOCPG FOCPM

☐ ; -]] Carrier frequency

FOCPG FOCPM Control mode Factory default: 5

5 kHz; 10kHz Settings

When this parameter is configured, please re-start the Hybrid Servo Controller.

The carrier frequency of the PWM output has a significant influence on the electromagnetic noise of the motor. The heat dissipation of the Hybrid Servo Controller and the interference from the environment may also affect the noise. Therefore, if the ambient noise is greater than the motor noise, reducing the carrier frequency of the drive may have the benefits of reducing a temperature rise; if the carrier frequency is high, even if a quiet operation is obtained, the overall wiring and interference control should be taken into consideration.

! - ₹¥ Reserved

Motor ID

FOCPG FOCPM Control mode Factory default: 0

Settings

Delta Hybrid Servo Motor ID		
0	Disabled	
16	ECMA-ER181BP3	11kW220V motor
17	ECMA-KR181BP3	11kW380V motor
18	ECMA-ER221FPS	15kW220V motor
19	ECMA-KR221FPS	15kW380V motor
20	ECMA-ER222APS	20kW220V motor
21	ECMA-ER222APS	20kW380V motor
125	MSJ-KR133AE48B	30kW380V motor
216	MSJ-DR201AE42C	10.4kW220V motor
217	MSJ-IR201AE42C	10.3kW380V motor
218	MSJ-DR201EE43C	14.6kW380V motor
219	MSJ-IR201EE42C	14.2kW380V motor
220	MSJ-DR201IE42C	18.4kW220V motor
221	MSJ-IR201IE42C	18.3kW380V motor
222	MSJ-GR202DE42C	23.1kW220V motor
223	MSJ-OR202DE42C	23kW380V motor
224	MSJ-DR202HE42C	27.6kW220V motor
225	MSJ-LR202FE42C	25kW380V motor
227	MSJ-IR203CE42C	32kW/380V motor
229	MSJ-OR264FE48C	45.2kW380V motor
231	MSJ-IR265CE48C	52.5kW380V motor
233	MSJ-IR266IE48	68kW, 380V motor
245	MSJ-IR202HE42	27kW, 380V motor

8 1-38 Cha

Change the rotation direction

Control mode

FOCPG FOC

Factory default: 0

Settings

- 0: When the driver runs forward, the motor rotates counterclockwise. When the driver runs reverse, the motor rotates clockwise.
- 1: When the driver runs forward, the motor rotates clockwise. When the driver runs reverse, the motor rotates counterclockwise.
- This parameter can be modified only when the machine is shut down. For an induction motor after the parameters are configured completely, it will change the running direction. For a synchronous motor, it is necessary to perform the magnetic pole detection and re-start the drive.
- When applying Pr01-36 on a synchronous motor, the motor drives which use firmware v2.04(included) and earlier version needs to have its magnetic pole redetected and be rebooted. But the motor drives which use firmware v2.05 (included) and later version don't need to have its magnetic pole redetected or be rebooted.

0:-37

HES ID#

Control mode

FOCPG FOCPM

Factory default: 0

Settings 0: Disabled

Model	HES ID#
-	-
-	-
HES063H23C	2122
HES080H23C	3122
HES100H23C	4122
HES125H23C	5122
HES160H23C	6122
HES200H23C	7122
HES250G23C	8022
HES063H23A	2120
HES080G23A	3020
HES080H23A	3120
HES100G23A	4020
HES100H23A	4120
HES100Z23A	4220
HES125G23A	5020
HES125H23A	5120
HES160G23A	6020
HES160H23A	6120
HES200G23A	7020

Model	HES ID#	Model	HES ID#
-	-	HES063H43C	2142
HES063G43A	2040	HES080H43C	3142
HES063H43A	2140	HES100H43C	4142
HES080G43A	3040	HES125H43C	5142
HES080H43A	3140	HES160H43C	6142
HES100G43A	4040	HES063M43C	2342
HES100H43A	4140	HES080M43C	3342
HES100Z43A	4240	HES100M43C	4342
HES125G43A	5040	HES125M43C	5342
HES125H43A	5140	HES160M43C	6342
HES160G43A	6040	HES200M43C	7342
HES160H43A	6140	HES200H43C	7142
HES200G43A	7040	HES250M43C	8342
		HES320M43C	9342

N	## Flux-W	leakening Voltage Level	
	Control mode	FOCPG FOCPM	Factory default: 10V
	Settings	0 ~100V	•
	The function of F	Pr01-38 is to adjust the flux-wea	kening voltage level.
	Adjust this param	neter to use the voltage to lowe	r the motor's current when necessary. If you
	make the current	t too low, there's a current disto	rtion.
	The maximum D	C BUS output voltage is the high	phest setting value of Pr01-38.

02 Parameters for Protection

✓ You can set this parameter during operation.

Software brake level

Control mode VF FOCPG FOCPM Factory default: 380.0/760.0

Settings 230V series: 350.0~450.0Vdc 460V series: 700.0~900.0Vdc

Sets the reference point of software brake. The reference value is the DC bus voltage.

02-01	Present fault record
88-88	Second most recent fault record
02-03	Third most recent fault record
82-84	Fourth most recent fault record
02-05	Fifth most recent fault record
88-88	Sixth most recent fault record

Cattings Control made	VF	FOCPG	FOCPM
Settings Control mode 0: No error record	0	0	· •
1: Over-current during acceleration (ocA)	0	0	0
2: Over-current during acceleration (oca)	0	0	0
3: Over-current during deceleration (ocu)	0	0	0
4: Ground fault (GFF)	0	0	0
5: IGBT short-circuit (occ)	0	0	0
6: Over-current at stop (ocS)	0	0	0
7: Over-current at stop (003) 7: Over-voltage during acceleration (ovA)	0	0	0
8: Over-voltage during deceleration (ovd)	0	0	0
9: Over-voltage during deceleration (ovd)	0	0	0
10: Over-voltage at stop (ovS)	0	0	0
11: Low-voltage during acceleration (LvA)	0	0	0
12: Low-voltage during deceleration (LvA)	0	0	0
13: Low-voltage during deceleration (Lvd) 13: Low-voltage during constant speed (Lvn)	0	0	0
14: Low-voltage at stop (LvS)	0	0	0
15: Phase loss protection (PHL)	0	0	0
	0	0	0
16: IGBT over-heat (oH1) 17: Heat sink over-heat for 40HP and above (oH2)	0	0	0
18: TH1 open: IGBT over-heat protection circuit error (tH1o)	0	0	0
19: TH2 open: heat sink over-heat protection circuit error	0	0	0
(tH2o)	Ü	O	ŭ
20: IGBT over heated and unusual fan function (oHF)	0	0	0
21: Hybrid Servo Controller overload (oL)	0	0	0
22: Motor 1 overload (EoL1)	0	0	0
23: Reserved			
24: Motor over-heat, detect by PTC (oH3)	0	0	0
25: Reserved			
26: Over-torque 1 (ot1)	0	0	0
27: Over-torque 2 (ot2)	0	0	0
28: Reserved			
29: Reserved			
30: Memory write error (cF1)	0	0	0
31: Memory read error (cF2)	0	0	0
32: Isum current detection error (cd0)	0	0	0
33: U-phase current detection error (cd1)	0	0	0
34: V-phase current detection error (cd2)	0	0	0
35: W-phase current detection error (cd3)	0	0	0
36: Clamp current detection error (Hd0)	0	0	0
37: Over-current detection error (Hd1)	0	0	0
38: Over-voltage current detection error (Hd2)	0	0	0
39: Ground current detection error (Hd3)	0	0	0
40: Auto tuning error (AuE)			0

Factory default: 180/360

41: Reserved	0	0	0
42: PG feedback error (PGF1)		0	0
43: PG feedback loss (PGF2)		0	0
44: PG feedback stall (PGF3)		0	0
45: PG feedback slip (PGF4)		0	0
46: Reserved	0	0	0
47: Reserved	0	0	0
48: Reserved			
49: External fault input (EF)	0	0	0
50: Emergency stop (EF1)	0	0	0
51: Reserved			
52: Password error (PcodE)	0	0	0
53: Reserved			
54: Communication error (cE1)	0	0	0
55: Communication error (cE2)	0	0	0
56: Communication error (cE3)	0	0	0
57: Communication error (cE4)	0	0	0
58: Communication time out (cE10)	0	0	0
59: PU time out (cP10)	0	0	0
60: Braking transistor error (bF)	0	0	0
61~63: Reserved	0	0	0
64: Safety relay Error (SRY)	0	0	0
65: PG card information error (PGF5)			0
66: Over pressure (ovP)	0	0	0
67: Pressure feedback fault (PfbF)	0	0	0
			-


As a fault occurs and the machine is forced shutting down, the event will be recorded. During shutting down, the LvS is not recorded.

✓ # Paragraph ✓ Margaration ✓ Low voltage level

Control mode VF FOCPG FOCPM

Settings 230V Series: 160 – 220V 460V Series: 320 – 440V

This parameter is used to set the LV discrimination level.



PTC action selection

Control mode VF FOCPG FOCPM Factory default: 1

Settings 0: Warn and keep operation

Warn and ramp to stop
 Warn and coast to stop

Parameter 02-08 is used to define the operation mode of the drive after the PTC is activated.

M A PTC level

Control mode VF FOCPG FOCPM Factory default: 50.0

Settings 0.0~150.0% 0.0~150.0°C

Chapter 4 Parameter Functions | HES Series

This parameter defines the maximum value of the analog input for 100% of the activation level of the PTC.

PTC detection filtering time

Control mode VF FOCPG FOCPM

VF FOCPG FOCPM Factory default: 0.20

Settings 0.00 - 10.00 seconds

PTC type

Control mode VF FOCPG FOCPM Factory default: 0

Settings 0: Not assigned 1: KTY84

When this parameter is set as 1, the unit for Pr02-09 and 02-12 will be changed from % to °C.

When this parameter is set as 1, the default setting of Pr02-09 will change from 50% to 140°C.

There are two types of temperature rising protection: KTY84 and PTC.

When you use one of them, wrap the final wires of another type to avoid short-circuiting by touching the wires.

1) When you use KTY84:

Connect the Red/White wire to the AUI connector of I/O terminal on the control board.

Then connect the Black/ White wire to the ACM connector.

And then switch Jumper (J7) to the position of KTY84

2) When you use PTC:

Connect the Yellow wire on encoder to the AUI connector of I/O terminal on the control board.

Then connect the Yellow/Black wire to the ACM connector. .

And then switch the Jumper(J7) to the position of OFF

The temperature rising protection by PTC needs to go with the setting at Pr02-11 = 0 and Pr02-09 PTC level = 62.5%.

(This is a trip-out protection when the motor reaches 130°C)

Motor fan activation level

Control mode VF FOCPG FOCPM Factory default: 50.0

Settings 0.0~100.0% 0.0~150.0°C

When the Parameters 03-05 to 03-07 for the multi-function output terminal are set to 45, the motor fan will start or stop according to this parameter setting.

Fig. 2 - 13 Electronic thermal relay selection 1

Control mode VF FOCPG FOCPM Factory default: 2

Settings 0: Inverter motor

1: Standard motor

2: Disable

✓ Ω2 - !! Electronic thermal characteristic for motor

Control mode VF FOCPG FOCPM Factory default: 60.0

Settings 30.0~600.0 seconds

To prevent self-cooled motor from over heating at low speed operation, the user can set the electronic thermal relay to limit the allowed output power of the Hybrid Servo Controller.


	Chapter 4 Farameter Functions TIEO Genes
⊕2 - ∤5 Output frequency at malfunction	
Control mode VF FOCPG FOCPM	Factory default: Read only
Settings 0.00~655.35Hz	
## Output voltage at malfunction	
Control mode VF FOCPG FOCPM	Factory default: Read only
Settings 0.0~6553.5V	
## DC side voltage at malfunction	
Control mode VF FOCPG FOCPM	Factory default: Read only
Settings 0.0~6553.5V	
@2- #8 Output current at malfunction	
Control mode VF FOCPG FOCPM Settings 0.00~655.35Amp	Factory default: Read only
Settings 0.00~655.35Amp	
	Fraterio defeable Band and
Control mode VF FOCPG FOCPM Settings 0.0∼6553.5□	Factory default: Read only
Auto-reset LvX error	
Control mode VF FOCPG FOCPM	Footom, pottings 0
Settings 0: Disable	Factory setting: 0
1: Enable	
When this parameter is enabled and when there is RI	UN signal, the hybrid servo drive will
automatically restart after repowering on	
automatically restait alter repetitioning em	
Market Protection w A second of the parameter protection w A second of the param	ith the password
Control mode	Factory setting: 0
Settings 1~9998	d
Display 0~3 times of entering wrong passy	
Enter the password set at Pr02-21 into Pr02-22 to unl	ock the parameters to make
modifications.	
Write down the setting value after you set up this para	meter to avoid inconveniences.
☐ Use Pr02-21 and Pr02-22 to prevent any unauthorized	d personnel to modify/ delete parameters.
☐ If you forget the password, input 9999 and press ENT	ER, then repeat inputting 9999 and
pressing ENTER to complete the decoding procedure	(This procedure has to be done in 10
seconds, if you don't finish that in 10 seconds, repeat	
procedure in 10 sec.). Once you finish this decoding p	process, all the parameters will be back to
the factory settings.	
When setting up a password, all the parameters will b	e read as 0, except Pr02-22.
Set up a parameter protection pass	word
Set up a parameter protection pass	Factory setting: 0
Settings 1~ 9998, 10000~65535	i dotory setting, o
Display 0: No password set or password e 1: Parameters are locked	ntered successfully in Pr02-30.
This parameter is for setting up a password to protect	parameters. When you finish setting up a
password, keypad will display 1, which means the pa	ssword protection is now effective.
	•
\square Once you input the correct password into Pr02_21 the	e hybrid servo drive is temporarily
Once you input the correct password into Pr02-21, the unlocked. To cancel the parameter protection, set Pr0	


is cancelled, the hybrid servo drive is without password protection even after reboot.


Chapter 4 Parameter Functions | HES Series

Decode temporarily or cancel the password then you will be able to use keypad to copy parameters. But the password set at Pr02-22 will not be copied. When the parameters saved in the keypad are transferred to the hybrid servo drive, you will need to set up a password at Pr02-22 to enable parameter protection.









02-23 ~ 02-30 Reserved

03 Digital/Analog Input/Output Parameters

✓ You can set this parameter during operation. Multi-function input command 3 (MI3) Multi-function input command 4 (MI4) Multi-function input command 5 (MI5) VF FOCPG **FOCPM** Control mode Factory default: 0 Settings 0: No function 44: Injection signal input 45: Confluence/Diversion signal input 46: Reserved 47: Multi-level pressure PI command 1 48: Multi-level pressure PI command 2 51: flow command When the value of this parameter is set as 44, the pressure feedback is lower than the pressure stable region (please refer to the description of Parameter 00-26) so the flow control will be performed. When it enters the pressure stable region, the pressure control will be performed. If the setting value is 45, the confluence (OFF)/diversion (ON) function will be performed. For detailed operation, please refer to Chapter 2 for wiring and Chapter 3 for tuning. Please refer to the description Parameters 00-36 if the setting value is 47 and 48, When under the pressure control (Pr00-09=1) and the external terminal is ON, the speed command is the flow command. It is no longer necessary to learn what the flow command is through the calculation of PI pressure. Digital input response time Control mode **FOCPG FOCPM** Factory default: 0.005 0.001~30.000 sec Settings This parameter is used to delay and confirm the signal on the digital input terminal. Digital input operation direction **FOCPG FOCPM** Control mode Factory default: 0 Settings 0~65535 This parameter defines the activation level of the input signal. ☐ Bit 0 for the SON terminal, bit 2 for the EMG terminal, bit 3 for the RES terminal, bits 4~6 correspond to MI3~MI5, respectively. Multi-function output 1 (Relay 1) VF FOCPG FOCPM Control mode Factory default: 11 FOCPG FOCPM ۷F Control mode Factory default: 0 Multi-function Output 3 (MO2) FOCPG FOCPM Control mode ۷F Factory default: 0 Settings 0: No function 1: Operation indication 9: Hybrid Servo Controller is ready 11: Error indication 14: MO1 software brake output 44: Displacement switch signal 45: Motor fan control signal

Multi-function output direction

Control mode VF FOCPG FOCPM Factory default: 0

Settings 0~65535

This parameter is used for bit-wise setting. If the corresponding bit is 1, the multi-function output is set as reverse direction.

Control mode VF FOCPG FOCPM Factory default: 0.100

Settings 0.001~65.535 seconds

This parameter can be set to reduce the fluctuation of the readings on the keypad.

#77- ## Maximum output voltage for pressure feedback

Control mode VF FOCPG FOCPM Factory default: 10.0

Settings 5.0~10.0 V

☐ 3 - ; ; Minimum output voltage for pressure feedback

Control mode VF FOCPG FOCPM Factory default: 0.0

Settings 0.0~2.0V

This parameter defines the pressure feedback output voltage type.

If the pressure feedback has a bias, can adjust this parameter to eliminate the bias.

#3 - #2 Type of Pressure Feedback Selection

Control mode VF FOCPG FOCPM Factory default: 1

Settings 0: Current 1: Voltage


PO (Pressure Feedback) terminal: Add a current-fed pressure feedback (4~20mA)

The following are required when using it:

Switch the SW100 on the I/O board to "I".

Set Pr03-12 = 0 (4~20mA)

Set Pr00-36 =1 (Enable detection of the pressure feedback disconnection)



<u> </u>	? - ; ?	Confluence	ce Master/Slave	Selection	
Cor	ntrol mode	VF FOO	PG FOCPM		Factory default: 0
		Settings	0: No function		
			1: Master 1 2: Slave/Master 2		
			3: Slave/Master 3		
	In a sta	nd-alone sys	tem, this parameter	is set as 0	
	In a cor	nfluence syst	em, the parameter is	s set as 1 for the Maste	er and 2 for the Slave
	With mu	ulti-function i	nput terminal functio	n 45, the confluence/di	iversion can be configured. For
	detailed	d operation, p	lease refer to Chap	ter 2 for wiring and Cha	apter 3 for tuning.
	The diff	ference betw	een Master 2 and M	aster 3 is that the Mast	ter 3 can be configured as
	conflue	nt with other	Slaves during conflu	uence; however, the Ma	aster 2 can be configured for
	stand-a	lone operatio	on.		
	When F	Pr.03-13 is se	et as 2: Slave, at the	same time, Pr.01-01 w	vill be set as 2 and Pr.03-15 will
	be set a	as 1 automat	ically.		
83	} - 4	-	roportion of the	Master's flow	
Cor	ntrol mode				Factory default: 100.0
	This na	Settings	0.0~65535.5 %	or the Master but not no	eeded for the Slave
	-				eeded for the Slave. 's portion of the Master's flow.
	Examp Fo	le: Slave is 6 or confluence	0L/min and Master of more than 2 pum	is 40L/min, so the settings, the values for the s	ng is 60/40 * 100% = 150% slaves must be the same. For
	40		he two Slaves shoul		min, where the Master is ing of Parameter 03-14 should
Ω	3- 15	Source of	f frequency com	mand	
Co	ntrol mode		CPG FOCPM		Factory default: 0
		Settings			
			1: RS485 Commu 2~5: Reserved	inication	
	This pa	rameter is us	sed for EMVJ-MF01.	For detailed operation;	refer to Chapter 3 for tuning.
	In a cor	nfluence syst	em, if the Slave's fre	equency command is gi	iven through the RS485
	commu	nication, the	setting value should	l be 1.	
8	3- 18	Limit for	the Slave revers	e depressurization	n torque
Co	ntrol mode	e VF FO Settings	CPG FOCPM 0~500%		Factory default: 20
	Set the	torque limit	of the Slave when ru	unning reversely	
\cap)_ 17	Slave's ac	ctivation level		
Cor	ntrol mode				Factory default: 50
		Settings	0~100%		. actory doladit. oo
	This pa	rameter setti	ng is required only f	or the Master but not no	eeded for the Slave.
	This pa	rameter dete	rmines the activatio	n level for the Slave. A	100% value corresponds to the
	full flow	of the Maste	er.		

N	## Communication error treatment	
	Control mode VF FOCPG FOCPM Settings 0: Warn and keep operation 1: Warn and ramp to stop 2: Warn and coast to stop 3: No action and no display	Factory default: 0
	☐ This parameter is used to set the handling status of the drive when	a communication timeout
	error (such as disconnection) occurs.	
N	?? → ! Parameter Time-out detection	
	Control mode VF FOCPG FOCPM	Factory default: 0.0
	Settings 0.0~100.0 seconds	
	This parameter is used to set the time of the time-out event for the	communication and the
	keypad transmission.	
~	## Start-up display selection	
	Control mode VF FOCPG FOCPM Settings 0: F (frequency command) 1: H (actual frequency) 2: Multi-function display (user-defined 00-04) 3: A (Output current)	Factory default: 0
	This parameter is used to set the contents of the start-up screen. The	he content of the
	user-defined option is displayed in accordance with the setting valu	e of Parameter 00-04.
N	∰ 3 - 2 4 Slave reverse operation for depressurization	
	Control mode VF FOCPG FOCPM Settings 0: Disabled 1: Enabled	Factory default: 0
-	This parameter setting is required only for the Slave but not needed	for the Master.
	When the parameter is set as 1, it is necessary to make sure that the	e outlet end of the Slave is
	not installed with any one-way valve and the parameter 03-16 is set	as 500.
N	Slave closing level	
	Settings 0~ 400 Bar	Factory setting: 400
	Set up this parameter from a Master. The slave pump(s) will be shut	t down when the master
	pump detects the pressure higher than the setting value at this para	
	will resume to run after the hybrid servo drive goes into stand by	inicioi, The slave pullip(s)

Chapter 5 Methods of Anomaly Diagnosis

5-1 Unusual Signal

5-1-1 Indicator Display

5-1-2 Error Messages Displayed on Digital Operation Panel KPVJ-LE01

5-2 Over current (OC)

5-3 Ground fault (GFF)

5-4 Over voltage (OV)

5-5 Low voltage (Lv)

5-6 Overheat (OH1)

5-7 Overload (OL)

5-8 Phase loss in power supply (PHL)

5-9 Resolutions for electromagnetic noise and induction noise

5-10 Environment and facilities for installation


The Hybrid Servo Controller is capable of displaying warning messages such as over voltage, low voltage, and over current and equipped with the protection function. Once any malfunction occurs, the protection function will be activated and the Hybrid Servo Controller will stops its input, followed by the action of the anomaly connection point and stopping of the servo oil pump. Please refer to the cause and resolution that corresponds to the error message displayed by the Hybrid Servo Controller for troubleshooting. The error record will be stored in the internal memory of the Hybrid Servo Controller (up to the most recent six error messages) and can be read by the digital operation panel or communication through parametric readout.



- ☑ Upon the occurrence of anomaly, wait for five seconds after the anomaly is resolved before pressing the RESET key.
- ☑ For Hybrid Servo Controllers with power □ 22kW, wait for five minutes after the power is turned off and for ten minutes for models with power □ 30kW. Verify that the charging indicator is off. Measure the DC voltage between terminals ⊕~⊖, which should be below DC25V before opening the machine cover and starting the inspection.

5-1 Unusual Signal

5-1-1 Indicator Display



- Indicator of PG card power
- Indicator of Encoder feedback

- Powerindicator
- Powerindicator
- Warning indicator When the sin or cos phase voltage is lower than required values in the rotational transformer, the warning indicator will be on. Please check if the encoder wire is connected correctly. If it happens in operation, please check for any interference.

5-1-2 Error Messages Displayed on Digital Operation Panel KPVJ-LE01

Display Code	Description of Anomaly	Troubleshooting
Display Code		Check if the insulation of the wire from
	Over current occurs in	U-V-W to the hybrid servo motor is bad.
\square	acceleration; output current	The trie trie right derive meter le sauf
	exceeds by three times the rated current of the frequency inverter.	2. Check if the hybrid servo motor is stalled.
		3. Such errors occur when the red light of PG card flashes. The causes of these errors could be loose contact/ disconnection between encoder, motor drive and motor.
ocd	Over current occurs in deceleration; output current exceeds by three times the rated current of the frequency inverter.	4. When such errors occur at the beginning, during or at the end of pressure/ flow command, adjust the pressure/flow reference time (Pr00-46~ Pr00-49). Adjust also the ramp up/down rate of pressure/flow command (Pr00-29 to Pr00-32) from a controller or the motor drive.
		5. When such errors occur while pressure/ flow command is constant, adjust PI value (Pr00-20 ~ Pr00-25).
ocn	Over current occurs during constant speed; output current exceeds by three times the rated current of the frequency inverter.	6. Make sure if there's any disturbance/ noise, set Pr00-04: #11 (Pressure feedback), #12(Pressure command), 25 (flow command). Then observe if the values fluctuate.
		7. Replace with the Hybrid Servo Controller with larger output capacity.
065	Over current occurs when the system is at stop. Unusual hardware circuit by current detection.	Send back to manufacturer for repair.
осс	Shorting of top and bottom bridges in IGBT module are detected by Hybrid Servo Controller.	Send back to manufacturer for repair.
008	Over voltage occurs on the internal DC high voltage side detected by Hybrid Servo	230V: DC 415V 460V: DC 830V
	Controller during acceleration.	Check if the input voltage is within the
oud	Over voltage occurs on the internal DC high voltage side detected by Hybrid Servo Controller during deceleration.	range of voltage rating of Hybrid Servo Controller and monitor for any occurrence of surge voltage.

Display Code	Description of Anomaly	Troubleshooting
		2. For Hybrid Servo Controller with power below 22kW, the issue can be resolved by adjusting the software brake action level in Pr.02-00.
	Over voltage occurs on the	3. For Hybrid Servo Controller with power above 22kW, the issue can be resolved by adjusting the action level in the brake unit (Refer to Appendix B-6 for details.).
000	internal DC high voltage side detected by Hybrid Servo Controller during constant speed.	4. When such error occurred at the beginning, during or at the end of the pressure/ flow command, adjust Pr00-29 ~Pr0032 <ramp command="" down="" flow="" of="" pressure="" rate="" up=""> or Pr00-46 ~Pr00-49 <pressure flow="" reference="" s1="" s2="" time="">.</pressure></ramp>
		5. When such error occurred while the pressure/ flow command is constant, adjust Pr00-20 ~ Pr00-25 <pi value="">.</pi>
005	Over voltage occurs when the system is at stop. Unusual hardware circuit by current detection	Check if the input voltage is within the range of voltage rating of Hybrid Servo Controller and monitor for any occurrence of surge voltage.
108	The DC voltage of Hybrid Servo Controller is lower than the setting in Pr.02-07 in acceleration	Check if the voltage of input power is normal.
Lud	The DC voltage of Hybrid Servo Controller is lower than the setting in Pr.02-07 in deceleration	2. Check if there is any sudden heavy load.
Lun	The DC voltage of Hybrid Servo Controller is lower than the setting in Pr.02-07 when running at	3. Adjust the low voltage level in Pr.02-07.4. Lvn often occurs when the motor drive has
Lus	Constant speed The DC voltage of Hybrid Servo Controller is lower than the setting in Pr.02-07 when off	a power failure while the operating signals are still being sent.
9 H !	Phase loss protection	Check if only single phase power is sent or phase loss occurs for three phase models
		2. For models with 40HP and above, check if the AC side fuse is blown.
	Ground wire protection, applies when Hybrid Servo Controller detects the output is grounded and	Check the wire of hybrid servo motor is shorted or grounded.
GFF	the ground current is higher than its rated value by over 50%. Note that this protection is only for	2.Check if IGBT power module is damaged
	Hybrid Servo Controller and not for human.	insulation.
	Overheating of IGBT detected by Hybrid Servo Controller,	 Check if ambient temperature is too high. Check if there is any foreign object on the
oX :	exceeding the protection level 7.5~15HP: 90 °C 20~100HP: 100 °C	heat sink and if the fan is running. 3. Check if there is sufficient space for air
	20 100111 . 100 0	circulation for Hybrid Servo Controller.

Diaplay Codo	Description of Anomaly	Traublashasting
Display Code	Description of Anomaly	Troubleshooting 1. Check if ambient temperature is too high.
Overheating of heat sink detected by Hybrid Servo Controller, exceeding the protection level (90	2. Check if there is any foreign object on the heat sink and if the fan is running.	
	°C).	3.Check if there is sufficient space for air circulation for Hybrid Servo Controller
	(02-09 PTC level) Overheating inside the motor drive detected by	1. Check the control board, see if J7 is switched to KTY84 but external terminals AUI and CM don't receive signals from KTY84-130.
083	Hybrid Servo Controller, exceeding the protection level (Pr02-09 PTC level).	2.Check if the motor drive is blocked
		3.Check if the ambient temperature is too
		high
	ICDT overhoosted and conversel.	4.Increase the capacity of the motor drive Check the fan kit to see if it is blocked.
oXF	IGBT overheated and unusual fan function	Return to factory for repair.
	Output current exceeds the maximum capacity of Hybrid Servo Controller	Check if the hybrid servo motor is stalled.
οĹ		2. Check if the oil pump is stuck.
		3. Such errors occur when the red light of PG card flashes. The causes of these errors could be loose contact/ disconnection between encoder, motor drive and motor.
		4. Set Pr00-04=29 (v2.06 and above), observe if the value returns to zero after every molding cycle. If the number accumulates to 100, OL occurs.
		5. Change the molding conditions.
		6. Replace with the Hybrid Servo Controller with larger output capacity.
EoL;	Servo motor overloaded	1. Set Pr00-04=30 (v2.06 and above), observe if the value returns to zero after every molding cycle. If the number accumulates to 100, EoL occurs. Change the molding conditions.
		Replace with the Hybrid Servo Controller with larger output capacity,
		3. If the pressure-flow is too high during blending, such error occurs easily. To clear this error, decrease the pressure command and the flow command. Note that this overload protection is only available for version A motors.

Chapter 5 Methods of Anomaly Diagnosis | HES Series

Display Code	Description of Anomaly	Troubleshooting
FUSE	DC Fuse blown on (FUSE), for models below (including) 30HP	 Check if the transistor module fuse is bad. Check if the load side is shorted.
cF !	Error on memory write in	Press RESET key to return all parameters to factory default values
c F 2	Error on memory readout	If the above does not work, send back to manufacturer for repair
c d G	Detection of abnormal output of three-phase total current	
cdi	Detection of abnormal current in phase U	Turn off the power and restart. If the same problem persists, send back to manufacturer
c d 2	Detection of abnormal current in phase V	for repair
cd3	Detection of abnormal current in phase W	
<i>EF</i>	When external terminals EF are closed, Hybrid Servo Controller stops its output	Troubleshoot and press "RESET"
EF :	When external EMG terminal is not connected to the heating switch of hybrid servo motor or the motor is overheated (130 °C), Hybrid Servo Controller stops its input	Troubleshoot and press "RESET"
<i>68</i>	Braking transistor error	Press RESET. If the display still shows "bF", please send the unit back to manufacturer for repair

Display Code	Description of Anomaly	Troubleshooting
68 lo	Abnormal in OH1 hardware wire	Send back to manufacturer for repair.
6 H Z o	Abnormal in OH2 hardware wire	Send back to manufacturer for repair.
NdC	Clamp current detection error (Hd0)	
Hd I	Over-current detection error (Hd1)	Turn off the power and restart. If the same problem persists, send back to manufacturer
Hd2	Over-voltage detection error (Hd2)	for repair.
863	Ground current detection error (Hd3)	
PGF	PG feedback error (PGF1)	The actual rotating speed doesn't follow speed command and the elapsed time longer than 1 second. In this case, check if Pr01-30 Is not equal to zero and check PG feedback wiring.
9582	PG feedback loss (PGF2)	Check the PG feedback wiring. It could be an open circuit.
P6F3	Stalled PG feedback (the actual rotating speed is 115% faster than the maximum speed and the elapsed time longer than one second)	Check the PG feedback wiring. Check if PI gain and the settings for acceleration/ deceleration are suitable.
PCFY	PG slip error (PGF4	 3. Check if there is an output phase loss. The causes of these errors could be loose contact/ disconnection between encoder, hybrid servo motor controller and motor. (OC might also occur in different conditions.). 4. Check if the connection between oil pump and motor is stuck. 5. Send back to manufacturer for repair.
PSFS	PG card information error (PGF5)	Check if the settings of Pr.01-26 match those in the installed PG card. If so, please send back to manufacturer for repair.
5-3	Abnormal installation or action of JP18, the safety loop card/control board pin	 Check if the safety loop card is installed correctly on the control board and if the output action is normal. Check if pin JP18 is inserted into the wrong position on the control board.
9 م ه	Overpressure (ovP)	 Check if the pressure sensor is working properly and if its specification is correct. Adjust pressure PI control Pr.00-20~00-37 Check if the wiring of pressure sensor is correct. Check the position of SW100 dip switch (current type or open collector) on the control board if correct. Check if the wiring of pressure sensor is
PFbF	Pressure feedback fault (PfbF)	correct. It could be open-circuit 2. Check if the pressure sensor signal is below 1V.


Display Code	Description of Anomaly	Troubleshooting
AUE	Auto tuning error (AuE)	Check if the wiring of the motor is correct.
		Check if the motor's parameter settings are correct.
PrEu	Oil pump runs reversely (Prev)	1. Check if there is any zero shift at the
		pressure sensor.
		2. Check if the wiring of pressure sensor is
		correct.
noīL	Oil shortage (noil)	1. Check the amount of oil in the oil tank.
		Check if any leakage at hydraulic circuit.
		3. If there's a suction filter installed at the oil
		inlet, check if that suction filter is blocked up.

Alarm reset


Once the issue that tripped the system and triggers the alarm is eliminated, one can resume the system to normal status by pressing the RESET key on the digital keypad (as shown in the figure) to set the external terminal to "Anomaly reset command" and sending the command by turning on the terminal or via communication. Before any anomaly alarm is resolved, make sure the operation signal is at open circuit status (OFF) to avoid immediate machine running upon anomaly reset that may case mechanical damage or personnel casualty.




5-2 Over Current (OC)




5-3 Ground Fault (GFF)




5-4 Over Voltage (ov)




If you consider installing a brake unit, follow the wiring diagram below.




5-5 Low Voltage (Lv)




5-6 Over Heat (OH1)



5-7 Overload (oL)



5-8 Phase Loss (PHL)



5-9 Electromagnetic/Induction Noise

If there exist noise sources around Hybrid Servo Controller, they will affect Hybrid Servo Controller through radiation or the power lines, leading to malfunction of control loop and causing tripping or even damage of Hybrid Servo Controller. One natural solution is to make Hybrid Servo Controller immune to noise. However, it is not economical and the improvement is limited. It is best to resort to methods that achieve improvements outside Hybrid Servo Controller.

- 1. Add surge killer on the relay or contact to suppress switching surge between ON/OFF.
- 2. Shorten the wiring length of the control circuit or serial circuit and separate from the main circuit wiring.
- Comply with the wiring regulation for those shielded wire and use isolation amplifier for long wire.
- 4. The ground terminal of Hybrid Servo Controller must be connected to ground by following the associated regulations. It must have its own ground connection and cannot share with electrical welder and other power equipments.
- 5. Insert noise filter to the input terminal of Hybrid Servo Controller to prevent the noise entering from the power lines.

In a word, three-level solutions for electromagnetic noise are "no product", "no spread" and "no receive".

5-10 Environment and Facilities for Installation

The Hybrid Servo Controller is a device for electronic components. Detailed descriptions of the environment suitable for its operation can be found in the specifications. If the listed regulations cannot be followed for any reason, there must be corresponding remedial measures or contingency solutions.

- 1. To prevent vibration, anti-vibration spacer is the last choice. The vibration tolerance must be within the specification. The vibration effect is equal to the mechanical stress and it cannot occur frequently, continuously or repeatedly to prevent damaging AC motor drive.
- Store in a clean and dry location free from corrosive fumes/dust to prevent rustiness, poor contact. It also may cause short by low insulation in a humid location. The solution is to use both paint and dust-proof. For particular occasion, use the enclosure with whole-seal structure.
- 3. The ambient temperature must be just right. If the temperature is too high or too low, the lifetime and action reliability of electronic components will be affected. For semiconductor devices, once the conditions exceed the rated values, consequences associated with "damage" are expected. As a result, in addition to providing cooler and shades that block the direct sunlight that are aimed to achieve required ambient temperature, it is also necessary to perform cleaning and spot check the air filter in the storage tray of Hybrid Servo Controller and the angle of cooling fan. Moreover, the microcomputer may not work at extremely temperature, space heater is required for machines that are installed and operated in cold regions.
- 4. Avoid moisture and occurrence of condensation. If the Hybrid Servo Controller is expected to be shut down for an extended period of time, be careful not to let condensation happen, once the air conditioning is turned off. It is also preferred that the cooling equipment in the electrical room can also work as a dehumidifier.

Chapter 6 Maintenance

- 6-1 Maintenance and Inspections
- 6-2 Greasy Dirt Problem
- 6-3 Fiber Dust Problem
- 6-4 Erosion Problem
- 6-5 Industrial Dust Problem
- 6-6 Wiring and Installation Problem
- 6-7 Multi-function Input/Output Terminals Problem

The Hybrid Servo Controller has a comprehensive fault diagnostic system that includes several different alarms and fault messages. Once a fault is detected, the corresponding protective functions will be activated. The following faults are displayed as shown on the Hybrid Servo Controller digital keypad display. The six most recent faults can be read from the digital keypad or communication.

The Hybrid Servo Controller is made up by numerous components, such as electronic components, including IC, resistor, capacity, transistor, and cooling fan, relay, etc. These components can't be used permanently. They have limited-life even under normal operation. Preventive maintenance is required to operate this Hybrid Servo Controller in its optimal condition, and to ensure a long life.

Check your Hybrid Servo Controller regularly to ensure there are no abnormalities during operation and follows the precautions:



- ☑ Wait 5 seconds after a fault has been cleared before performing reset via keypad of input terminal.
- ☑ When the power is off after 5 minutes for □ 22kW models and 10 minutes for □ 30kW models, please confirm that the capacitors have fully discharged by measuring the voltage between + and -. The voltage between + and should be less than 25VDC.
- ☑ Only qualified personnel can install, wire and maintain drives. Please take off any metal objects, such as watches and rings, before operation. And only insulated tools are allowed.
- ☑ Never reassemble internal components or wiring.
- ☑ Make sure that installation environment comply with regulations without abnormal noise, vibration and smell.

6-1 Maintenance and Inspections

Before the check-up, always turn off the AC input power and remove the cover. Wait at least 10 minutes after all display lamps have gone out, and then confirm that the capacitors have fully discharged by measuring the voltage between DC+ and DC-. The voltage between DC+ and DC-should be less than 25VDC.

Ambient environment

		Ма	псе	
Check Items	Methods and Criterion		d	
		Daily	Half Year	One Year
Check the ambient temperature, humidity,	Visual inspection and			
vibration and see if there are any dust, gas,	measurement with equipment	\circ		
oil or water drops	with standard specification			
If there are any dangerous objects	Visual inspection	0		

Voltage

Check Items	Methods and Criterion		aintenance Period	
		Daily	Half Year	One Year
Check if the voltage of main circuit and	Measure with multimeter with	0		
control circuit is correct	standard specification			

Digital Keypad Display

Check Items Methods and Criterion	Maintenance Period			
		Daily	Half Year	One Year
Is the display clear for reading	Visual inspection	0		
Any missing characters	Visual inspection	0		

Mechanical parts

		Ма	псе	
Check Items	Methods and Criterion		Period	
		Daily	Half Year	One Year
If there is any abnormal sound or vibration	Visual and aural inspection		0	
If there are any loose screws	Tighten the screws		0	
If any part is deformed or damaged	Visual inspection		0	
If there is any color change by overheating	Visual inspection		0	
If there is any dust or dirt	Visual inspection		0	

Main circuit

		Ma	intenaı	ance	
Check Items	Methods and Criterion	Perio			
		Daily	Half Year	One Year	
If there are any loose or missing screws	Tighten or replace the screw	0			
If machine or insulator is deformed, cracked,	Visual inspection				
damaged or with color change due to	NOTE: Please ignore the				
overheating or ageing	color change of copper				
overneating or ageing	plate				
If there is any dust or dirt	Visual inspection		0		

Terminals and wiring of main circuit

Check Items Methods and Criterion	Methods and Criterion	Maintenance Period			
	Daily	Half Year	One Year		
If the terminal or the plate is color change or deformation due to overheat	Visual inspection		0		
If the insulator of wiring is damaged or color change	Visual inspection		0		
If there is any damage	Visual inspection	0			

DC capacity of main circuit

		Ma	псе		
Check Items	Methods and Criterion		Period		
	Daily	Half Year	One Year		
If there is any leak of liquid, color change, crack or deformation	Visual inspection	0			
If the safety valve is not removed? If valve is inflated?	Visual inspection	0			
Measure static capacity when required		0			

Resistor of main circuit

		Ma	псе	
Check Items	Methods and Criterion		Period	
		Daily	Half Year	One Year
If there is any peculiar smell or insulator cracks due to overheat	Visual inspection, smell	0		
If there is any disconnection	Visual inspection	0		
If connection is damaged? Measure with multimeter with standard specification	0			
	standard specification			

Transformer and reactor of main circuit

Check Items	Methods and Criterion		intenance Period		
		Daily	Half Year	One Year	
	If there is any abnormal vibration or peculiar smell	Visual, aural inspection and smell	0		

Magnetic contactor and relay of main circuit

Check Items	Methods and Criterion		aintenance Period	
		Daily	Half Year	One Year
If there are any loose screws	Visual and aural inspection	0		
If the contact works correctly	Visual inspection	0		

Printed circuit board and connector of main circuit

		Ма	intenar	nance	
Check Items	Methods and Criterion		Period		
		Daily	Half Year	One Year	
	Tighten the screws and				
If there are any loose screws and connectors	press the connectors firmly				
	in place.				
If there is any peculiar smell and color change	Visual and smell inspection		0		
If there is any crack, damage, deformation or corrosion	Visual inspection		0		
If there is any liquid is leaked or deformation in capacity	Visual inspection		0		

Cooling fan of cooling system

		Maintenance			
Check Items	Methods and Criterion		Period		
		Daily	Half Year	One Year	
	Visual, aural inspection and				
	turn the fan with hand (turn				
If there is any abnormal sound or vibration	off the power before		0		
	operation) to see if it rotates				
	smoothly				
If there is any loose screw	Tighten the screw		0		
If there is any color change due to overheat	Change fan		0		

Ventilation channel of cooling system

Check Items	Methods and Criterion	Maintenance Period			
		Daily	Half Year	One Year	
If there is any obstruction in the heat sink, air intake or air outlet	Visual inspection		0		



Please use the neutral cloth for clean and use dust cleaner to remove dust when necessary.

6-2 Greasy Dirt Problem

Serious greasy dirt problems generally occur in processing industries such as machine tools, punching machines and so on. Please be aware of the possible damages that greasy oil may cause to your drive:

- 1. Electronic components that silt up with greasy oil may cause the drive to burn out or even explode.
- 2. Most greasy dirt contains corrosive substances that may damage the drive.

Solution:

Install the Hybrid Servo Controller in a standard cabinet to keep it away from dirt. Clean and remove greasy dirt regularly to prevent damage of the drive.





6-3 Fiber Dust Problem

Serious fiber dust problems generally occur in the textile industry. Please be aware of the possible damages that fiber may cause to your drives:

- 1. Fiber that accumulates or adheres to the fans will lead to poor ventilation and cause overheating problems.
- 2. Plant environments in the textile industry have higher degrees of humidity that may cause the drive to burn out, become damaged or explode due to wet fiber dust adhering to the devices.

Solution:

Install the Hybrid Servo Controller in a standard cabinet to keep it away from fiber dust. Clean and remove fiber dust regularly to prevent damage to the drive.









6-4 Erosion Problem


Erosion problems may occur if any fluids flow into the drives. Please be aware of the damages that erosion may cause to your drive.

1. Erosion of internal components may cause the drive to malfunction and possibility to explode. **Solution:**

Install the Hybrid Servo Controller in a standard cabinet to keep it away from fluids. Clean the drive regularly to prevent erosion.







6-5 Industrial Dust Problem


Serious industrial dust pollution frequently occurs in stone processing plants, flour mills, cement plants, and so on. Please be aware of the possible damage that industrial dust may cause to your drives:

- 1. Dust accumulating on electronic components may cause overheating problem and shorten the service life of the drive.
- 2. Conductive dust may damage the circuit board and may even cause the drive to explode.

Solution:

Install the Hybrid Servo Controller in a standard cabinet and cover the drive with a dust cover. Clean the cabinet and ventilation hole regularly for good ventilation.






6-6 Wiring and Installation Problem

When wiring the drive, the most common problem is wrong wire installation or poor wiring. Please be aware of the possible damages that poor wiring may cause to your drives:

- 1. Screws are not fully fastened. Occurrence of sparks as impedance increases.
- 2. If a customer has opened the drive and modified the internal circuit board, the internal components may have been damaged.

Solution:

Ensure all screws are fastened when installing the Hybrid Servo Controller. If the Hybrid Servo Controller functions abnormally, send it back to the repair station. DO NOT try to reassemble the internal components or wire.








6-7 Multi-function Input/Output Terminals Problem


Multi-function input/output terminal errors are generally caused by over usage of terminals and not following specifications. Please be aware of the possible damages that errors on multi-function input/output terminals may cause to your drives:


1. Input/output circuit may burns out when the terminal usage exceeds its limit.

Solution:

Refer to the user manual for multi-function input output terminals usage and follow the specified voltage and current. DO NOT exceed the specification limits.







Appendix A: Instructions of Product Packaging

A-1 Descriptions of Product packaging: version A

A-2 Unpacking: version A

A-3 Detailed List of Product Packaging: version A
A-4 Detailed List of Product Packaging: version C



☑ This product is made by a manufacturing process with strict quality control. If the product is damaged in the delivery by external force or crushing, please contact your local agents.

A-1 Descriptions of Product Packaging: v. A

Packaging of the external box


Models:


HES063H23A; HES080G23A; HES080H23A;

HES100G23A; HES100H23A;

HES063G43A;HES063H43A; HES080G43A;

HES080H43A; HES100G43A; HES100H43A;








Models:

HES125H23A; HES160G23A;

HES125H43A; HES160G43A; HES160H43A; HES200G43A









A-2 Unpacking: v. A


STEP 1: Use flat head screwdriver to remove all the clips on the side of the crate.



STEP 2: Remove the bubble bag and the tube.





STEP 3: Lift the drive by using two lifting holes.




A-3 Detailed List of Product Packaging: v.A


HES063H23A






HES080G23A






HES080H23A




Unit: mm[inch]


Frame	W	W1	н	H1	D	S1	ı
D	255.0 [10.04]	226.0 [8.90]	403.8 [15.90]	384.0 [15.12]	168.0 [6.61]	8.5 [0.33]	ı


2 Servo oil pump HSP-032-110-23A




Component	Model Number	Quantity
Motor	ECMA-ER181BP3	1
Oil pump	EIPC3-032RK23	1
Pressure sensor	WIKA A-10	1











HES100H23A

Pressure sensor



WIKA A-10

1




HES100Z23A

1 Servo controller VFD220VL23A10ZA, corresponding PG card EMVJ-PG02R


Unit: mm[inch]

Frame	W	W1	Н	H1	D	S 1
D	255.0 [10.04]	226.0 [8.90]	403.8 [15.90]	384.0 [15.12]	168.0 [6.61]	8.5 [0.33]


2 Servo oil pump HSP-040-150-23A



Component	Model Number	Quantity
Motor	ECMA-ER221FPS	1
Oil pump	EIPC3-040RA23	1
Pressure sensor	WIKA A-10	1





HES125G23A




Unit: mm[inch]

Frame	W	W 1	Н	H1	D	S 1
D	255.0 [10.04]	226.0 [8.90]	403.8 [15.90]	384.0 [15.12]	168.0 [6.61]	8.5 [0.33]






	Component	Model Number	Quantity
ſ	Motor	ECMA-ER221FPS	1
ſ	Oil pump	EIPC3-050RK23	1
	Pressure sensor	WIKA A-10	1



HES125H23A

Oil pump

Pressure sensor



1

1

EIPC3-050RK23


WIKA A-10


3 Accessory Kit HESP-125-H-B-23

Component	Model Number	Quantity
	VFDB-2022	1
※2 Braking resistor	BR1K0W5P8	1




%1 Braking unit VFDB-2022






Unit: min



TYPE	L1 ± 2	L2 ± 2	W ± 1	H ± 1
MH 1000 W	400	385	100	50


HES160G23A



Unit: mm[inch]

Frame	W	W1	Н	H1	H2	D	D1	D2	S1	S2	S3
E2	370.0	335.0	595.0	589.0	560.0	260.0	132.5	18.0	13.0	13.0	18.0
	[14.57]	[13.19]	[23.43]	[23.19]	[22.05]	[10.24]	[5.22]	[0.71]	[0.51]	[0.51]	[0.71]

2 Servo oil pump HSP-064-150-23A




Component	Model Number	Quantity
Motor	ECMA-ER221FPS	1
Oil pump	EIPC3-064RK23	1
Pressure sensor	WIKA A-10	1


3 Accessory Kit HESP-160-G-B-23

Component	Model Number	Quantity
※1 Braking unit	VFDB-2022	1
※2 Braking resistor	BR1K0W5P8	1




%1 Braking unit VFDB-2022






%2 Braking resistor 1000W 5.8 Ω

Unit: min



TYPE	$L1 \pm 2$	L2 ± 2	W ± 1	H ± 1
MH 1000 W	400	385	100	50

HES160H23A



1

WIKA A-10


Pressure sensor


3 Accessory Kit HESP-160-H-B-23

Component	Model Number	Quantity
※1 Braking unit	VFDB-2022	1
※2 Braking resistor	BR1K0W5P8	1




%1 Braking unit VFDB-2022








Unit: min



TYPE	L1 ± 2	L2 ± 2	W ± 1	H ± 1	
MH 1000 W	400	385	100	50	


HES200G23A



Unit: mm[inch]

Frame	W	W1	Н	H1	H2	D	D1	D2	S1	S2	S3
E2	370.0	335.0	595.0	589.0	560.0	260.0	132.5	18.0	13.0	13.0	18.0
	[14.57]	[13.19]	[23.43]	[23.19]	[22.05]	[10.24]	[5.22]	[0.71]	[0.51]	[0.51]	[0.71]

2 Servo oil pump HSP-200-G-B-23




Component	Model Number	Quantity
Motor	ECMA-ER222APS	1
Oil pump	EIPC3-080RA23	1
Pressure sensor	WIKA A-10	1


3 Accessory Kit HESP-200-G-B-23

Component	Model Number	Quantity
※1 Braking unit	VFDB-2022	1
※2 Braking resistor	BR1K5W5P8	1




%1 Braking unit VFDB-2022







%2 Braking resistor 1500W 5.8 Ω Unit: min




TYPE	L1 ± 2	L2 ± 2	H ± 1	W ± 1
MH 1500 W	550	535	50	100


HES063G43A







HES063H43A







HES080G43A







HES080H43A






HES100G43A






HES100H43A




Frame	W	W1	н	H1	D	S1	
D	255.0 [10.04]	226.0 [8.90]	403.8 [15.90]	384.0 [15.12]	168.0 [6.61]	8.5 [0.33]	


2 Servo oil pump HSP-040-110-43A



Component	Model Number	Quantity
Motor	ECMA-KR181BP3	1
Oil pump	EIPC3-040RK23	1
Pressure sensor	WIKA A-10	1




HES100Z43A




Unit: mm[inch]

Frame	W	W1	Н	H1	D	S 1
D	255.0 [10.04]	226.0 [8.90]	403.8 [15.90]	384.0 [15.12]	168.0 [6.61]	8.5 [0.33]


2 Servo oil pump HSP-040-150-43A



Component	Model Number	Quantity
Motor	ECMA-KR221BP3	1
Oil pump	EIPC3-040RK23	1
Pressure sensor	WIKA A-10	1




HES125G43A



Unit: mm[inch]

Frame	W	W1	Н	H1	D	S 1	
D	255.0 [10.04]	226.0 [8.90]	403.8 [15.90]	384.0 [15.12]	168.0 [6.61]	8.5 [0.33]	






3 Accessory Kit HESP-125-G-N-43 Component Model Number Quantity Braking resistor BR1K0W020 1 Coding device cable 5m Magnetic ring of power cable Sensor clamp 1 Sensor clamp


% Braking resistor10000W 20 Ω

Unit: min



	TYPE	L1 ± 2	L2 ± 2	W ± 0.5	H ± 0.5
ĺ	MH 1000 W	400	385	100	50


HES125H43A




Unit: mm[inch]

Frame	W	W1	Н	H1	D	S1	
D	255.0 [10.04]	226.0 [8.90]	403.8 [15.90]	384.0 [15.12]	168.0 [6.61]	8.5 [0.33]	


2 Servo oil pump HSP-050-150-43B



Component	Model Number	Quantity
Motor	ECMA-KR221FPS	1
Oil pump	EIPC3-050RK23	1
Pressure sensor	WIKA A-10	1




HES160G43A




Unit: mm[inch]

Frame	W	W1	Н	H1	D	S1	
D	255.0 [10.04]	226.0 [8.90]	403.8 [15.90]	384.0 [15.12]	168.0 [6.61]	8.5 [0.33]	

2 Servo oil pump HSP-064-150-43A



Component	Model Number	Quantity
Motor	ECMA-KR221FPS	1
Oil pump	EIPC5-064RA23	1
Pressure sensor	WIKA A-10	1




HES160H43A

1 Servo controller VFD370VL43B16HA, , corresponding PG card EMVJ-PG02R D1 SEE DETAIL A 888 T I 오 -SEE DETAIL B DETAIL A DETAIL B (MOUNTING HOLE) (MOUNTING HOLE)

Unit: mm[inch]

Fram	e W	W1	Н	H1	H2	Н3	D	D1	D2	S1	S2	Ø1	Ø2	Ø3
F0	280.0	235.0	516.0	500.0	475.0	442.0	251.7	94.2	16.0	11.0	18.0	62.7	34.0	22.0
E0	[11.02]	[9.25]	[20.31]	[19.69]	[18.70]	[17.40]	[9.91]	[3.71]	[0.63]	[0.43]	[0.71]	[2.47]	[1.34]	[0.87]





3 Accessory Kit HESP-160-H-B-43

Component	Model Number	Quantity
%1 Braking unit	VFDB-4045	1
※2 Braking resistor	MHR1K5W013	1




%1 Braking unit VFDB-4045





※2 Braking resistor 1500W 13Ω

Unit: min



TYPE	L1 ± 2	L2 ± 2	H±1	W ± 1
MH 1500 W	550	535	50	100


HES200G43A

1 Servo controller VFD370VL43B20GA, corresponding PG card EMVJ-PG02R D1 SEE DETAIL A 888 로 H 오 SEE DETAIL B DETAIL A (MOUNTING HOLE) DETAIL B (MOUNTING HOLE)

Unit: mm[inch]

Frame	W	W1	Н	H1	H2	Н3	D	D1	D2	S1	S2	Ø1	Ø2	Ø3
F0	280.0	235.0	516.0	500.0	475.0	442.0	251.7	94.2	16.0	11.0	18.0	62.7	34.0	22.0
E0	[11.02]	[9.25]	[20.31]	[19.69]	[18.70]	[17.40]	[9.91]	[3.71]	[0.63]	[0.43]	[0.71]	[2.47]	[1.34]	[0.87]

2 Servo oil pump HSP-080-200-43A




Component	Model Number	Quantity
Motor	ECMA-KR222APS	1
Oil pump	EIPC5-080-RA23-10	1
Pressure sensor	WIKA A-10	1


3 Accessory Kit HESP-200-G-B-43

Component	Model Number	Quantity
%1 Braking unit	VFDB-4045	1
※2 Braking resistor	MHR1K5W013	1




%1 Braking unit VFDB-4045





%2 Braking resistor 1500W 13 Ω

Unit: min





TYPE	L1 ± 2	L2 ± 2	H±1	W ± 1
MH 1500 W	550	535	50	100

A-4 Detailed List of Product Packaging: v.C

Corresponding Models:


HES	S063H23C
HES	S063H43C
HES	6063M43C
HES	080H23C
HES	S080H43C
HES	080M43C
HES	S100H23C
	S100H43C
HES	S100M43C
HES	S125H23C
HES	S125H43C
HES	S125M43C
HES	3160H23C
HES	S160H43C
HES	S160M43C
HES	S200H23C
HES	S200H43C
HES	S200M43C
HES	3250G23C
HES	S250M43C
HES	320M43C







01. HES063H23C

1 Servo controller: VFD110VL23A06HC W W1










Unit: mm[inch]

	Frame	W	Н	D	W1	H1	S 1
<u></u>	mm	235	350	146	204	337	6.5
C	inch	9.25	13.78	5.75	8.03	13.27	0.26

2 Servo oil pump: HSP-025-100-23C



component	model number	Quantity
Motor	MSJ-DR201AE42C	1
Oil pump	HSP-025-100-23C	1


3 Accessory Kit: HESP-063-H-NC23

component	model number	Quantity
Braking resistor	BR300W8P3 (MH300W)	1
Pressure sensor; WIKA A-10		1
Magnetic ring of power cable		3
Sensor clamp		1

Note: An encoder cable (model number: CBHE-E5M) is in the HSP Servo oil pump packaging




4: Braking resistor: BR300W8P3 (MH300W)



TYPE	L1 ± 2	L2 ± 2	W ± 0.5	H ± 0.5
MH 300 W	215	200	60	30

02. HES080H23C


1 Servo controller: VFD150VL23A08HC:



Unit: mm[inch]

ı	Frame	W	Н	D	W1	H1	S1
_	mm	255	403.8	168.0	226.0	384	8.5
ا	inch	10.04	15.90	6.61	8.90	15.12	0.33

2 Servo oil pump: HSP-032-140-43C



3 Accessory Kit: HESP-080-H-NC23

component	model number	Quantity
Braking resistor	BR1K0W5P8 (MH1000W)	1
Pressure sensor: WIKA A-10	第四日 会 4 5 1 会 元 二	1
Magnetic ring of power cable		3
Sensor clamp		1


Note: An encoder cable (model number: CBHE-E5M) is in the HSP Servo oil pump packaging



4 Braking resistor: BR1K0W5P8 (MH1000W)


Shape & Dimension:

(Unit: min)



TYPE	L1 ± 2	L2 ± 2	$W \pm 0.5$	$H \pm 0.5$
MH 1000 W	400	385	100	50


03. HES100H23C



Unit: mm[inch]

Frame		Frame	W	Н	D	W 1	H1	S1
	_	mm	255	403.8	168.0	226.0	384	8.5
	ا	inch	10.04	15.90	6.61	8.90	15.12	0.33

2 Servo oil pump: HSP-040-140-23C



component	model number	Quantity
Motor	MSJ-DR201EE42C	1
Oil pump	HSP-040-140-23C,	1

3 Accessory Kit: HESP-100-H-NC23:

component	model number	Quantity
Braking resistor	BR1K0W5P8 (MH1000W)	1
Pressure sensor: WIKA A-10		1
Magnetic ring of power cable		3
Sensor clamp		1


Note: An encoder cable (model number: CBHE-E5M) is in the HSP Servo oil pump packaging



4 Braking resistor: : BR1K0W5P8 (MH1000W)


Shape & Dimension:

(Unit: min)



TYPE	L1 ± 2	L2 ± 2	$W \pm 0.5$	$H \pm 0.5$
MH 1000 W	400	385	100	50


04. HES125H23C



Unit: mm[inch]

Frame		Frame	W	Н	D	W1	H1	S1
	D	mm	255	403.8	168.0	226.0	384	8.5
	ا	inch	10.04	15.90	6.61	8.90	15.12	0.33

2 Servo oil pump: HSP-050-180-23C



component	model number	Quantity
Motor	MSJ-DR201IE42C	1
Oil pump	HSP-050-180-23C	1

3 Accessory Kit: HESP-125-H-NC23

component	model number	Quantity
Braking resistor	BR1K0W5P8 (MH1000W)	1
Pressure sensor: WIKA A-10		1
Magnetic ring of power cable		3
Sensor clamp		1


Note: An encoder cable (model number: CBHE-E5M) is in the HSP Servo oil pump packaging



4 Braking resistor: BR1K0W5P8 (MH1000W)


Shape & Dimension:

(Unit: min)



TYPE	L1 ± 2	L2 ± 2	$W \pm 0.5$	$H \pm 0.5$
MH 1000 W	400	385	100	50


05. HES160H23C



Unit: mm[inch]

Fr	ame	W	Н	D	W1	H1	H2	D1	D2	S1	S2	S 3
E2	mm	370.0	595.0	260.0	335.0	589.0	560.0	132.5	18.0	13.0	13.0	18.0
C Z	inch	14.57	23.43	10.24	13.19	23.1	22.05	5.22	0.71	0.51	0.51	0.71

2 Servo oil pump: HSP-064-230-23C



component	model number	Quantity
Motor	MSJ-GR202DE42C	1
Oil pump	HSP-064-230-23C	1

3 Accessory Kit: HESP-160-H-BC23

component	model number	Quantity
Braking resistor	BR1K0W5P8 (MH1000W)	1
Pressure sensor: WIKA A-10		1
Magnetic ring of power cable		3
Sensor clamp		1


Note: An encoder cable (model number: CBHE-E5M) is in the HSP Servo oil pump packaging



4 Braking resistor: BR1K0W5P8 (MH1000W)


Shape & Dimension:

(Unit: min)



TYPE	L1 ± 2	L2 ± 2	$W \pm 0.5$	$H \pm 0.5$
MH 1000 W	400	385	100	50


06. HES200H23C



Unit: mm[inch]

Fr	ame	W	Н	D	W1	H1	H2	D1	D2	S1	S2	S3
E2	mm	370.0	595.0	260.0	335.0	589.0	560.0	132.5	18.0	13.0	13.0	18.0
CZ	inch	14.57	23.43	10.24	13.19	23.1	22.05	5.22	0.71	0.51	0.51	0.71

2 Servo oil pump: HSP-080-270-23C



component	model number	Quantity
Motor	MSJ-DR202HE42C	1
Oil pump	HSP-080-270-23C	1

3 Accessory Kit: HESP-200-H-BC23

component	model number	Quantity	
Braking resistor	BR1K0W5P8 (MH1000W)	1	
Pressure sensor: WIKA A-10	第四日 会会	1	
Magnetic ring of power cable		3	
Sensor clamp		1	


Note: An encoder cable (model number: CBHE-E5M) is in the HSP Servo oil pump packaging



4 Braking resistor: BR1K0W5P8 (MH1000W)


Shape & Dimension:

(Unit: min)



TYPE	L1 ± 2	L2 ± 2	W ± 0.5	$H \pm 0.5$
MH 1000 W	400	385	100	50


07. HES250G23C



Unit: mm[inch]

Fr	ame	w	Н	D	W1	H1	H2	D1	D2	S1	S2	S 3
E2	mm	370.0	595.0	260.0	335.0	589.0	560.0	132.5	18.0	13.0	13.0	18.0
CZ	inch	14.57	23.43	10.24	13.19	23.1	22.05	5.22	0.71	0.51	0.51	0.71

2 Servo oil pump: HSP-100-270-23C



component	model number	Quantity
Motor	MSJ-DR202HE42C	1
Oil pump	HSP-100-270-23C	1

3 Accessory Kit: HESP-250-G-BC23

component	model number	Quantity
※ Braking resistor	BR1K0W5P8 (MH1000W)	1
Pressure sensor: WIKA A-10		1
Magnetic ring of power cable		3
Sensor clamp		1


Note: An encoder cable (model number: CBHE-E5M) is in the HSP Servo oil pump packaging



4 Braking resistor: BR1K0W5P8 (MH1000W)

Shape & Dimension:


(Unit: min)





TYPE	L1 ± 2	L2 ± 2	$W \pm 0.5$	$H \pm 0.5$
MH 1000 W	400	385	100	50

08. HES063H43C

1 Servo controller: VFD110VL43A06HC W W1










Unit: mm[inch]

Frame		W	Н	D	W1	H1	S 1
	mm	235	350	146	204	337	6.5
	inch	9.25	13.78	5.75	8.03	13.27	0.26

2 Servo oil pump: HSP-025-100-43C



component	model number	Quantity
Motor	MSJ-IR201AE42C	1
Oil pump	HSP-025-100-43C	1


3 Accessory Kit: HESP-063-H-NC43

component	model number	Quantity
Braking resistor	BR300W025 (MH300W)	1
Pressure sensor: WIKA A-10		1
Magnetic ring of power cable		1
Sensor clamp		1

Note: An encoder cable (model number: CBHE-E5M) is in the HSP Servo oil pump packaging




4 Braking resistor: BR300W025 (MH300W)





TYPE	L1 ± 2	L2 ± 2	W ± 0.5	$H \pm 0.5$
MH 300 W	215	200	60	30

09. HES080H43C

1 Servo controller: VFD150VL43B08HC W W1










Unit: mm[inch]

Frame		W	Н	D	W1	H1	S1
	mm	235	350	146	204	337	6.5
	inch	9.25	13.78	5.75	8.03	13.27	0.26

2 Servo oil pump: HSP-032-100-43C



component	model number	Quantity
Motor	MSJ-IR201AE42C	1
Oil pump	HSP-032-100-43C	1


3 Accessory Kit: HESP-080-H-NC43

component	model number	Quantity
Braking resistor	BR300W025 (MH300W)	1
Pressure sensor: WIKA A-10	Man A C I	1
Magnetic ring of power cable		1
Sensor clamp		1

Note: An encoder cable (model number: CBHE-E5M) is in the HSP Servo oil pump packaging




4 Braking resistor: BR300W025 (MH300W)





TYPE	L1 ± 2	L2 ± 2	W ± 0.5	H ± 0.5
MH 300 W	215	200	60	30

10. HES100H43C

1 Servo controller: VFD185VL43B10HC










Unit: mm[inch]

Frame	W	Н	D	W1	H1	S 1
mm	235	350	146	204	337	6.5
inch	9.25	13.78	5.75	8.03	13.27	0.26

2 Servo oil pump: HSP-040-140-43C



component	model number	Quantity
Motor	MSJ-IR201EE42C	1
Oil pump	HSP-040-140-43C	1


3 Accessory Kit: HESP-100-H-NC43

component	model number	Quantity
Braking resistor	BR300W025 (MH300W)	1
Pressure sensor: WIKA A-10		1
Magnetic ring of power cable		1
Sensor clamp		1

Note: An encoder cable (model number: CBHE-E5M) is in the HSP Servo oil pump packaging




4 Braking resistor: BR1K0W025 (MH1000W)



TYPE	L1 ± 2	1.2 ± 2	W ± 0.5	H ± 0.5
MH 1000 W	400	385	100	50

11. HES125H43C


1 Servo controller: VFD220VL43A12HC



Unit: mm[inch]

ı	Frame	W	Н	D	W1	H1	S1
_	mm	255	403.8	168.0	226.0	384	8.5
ا	inch	10.04	15.90	6.61	8.90	15.12	0.33

2 Servo oil pump: HSP-050-180-43C



component	model number	Quantity
Motor	MSJ-IR201IE42C	1
Oil pump	HSP-050-180-43C	1


3 Accessory Kit: HESP-125-H-NC43

component	model number	Quantity
Braking resistor	BR1K0W025 (MH1000W)	1
Pressure sensor: WIKA A-10	Minus (A.C.)	1
Magnetic ring of power cable		3
Sensor clamp		1

Note: An encoder cable (model number: CBHE-E5M) is in the HSP Servo oil pump packaging




4 Braking resistor: BR1K0W025 (MH1000W)



TYPE	L1 ± 2	1.2 ± 2	W ± 0.5	H ± 0.5
MH 1000 W	400	385	100	50

12. HES160H43C


1 Servo controller: VFD300VL43B16HC



Unit: mm[inch]

Frame	W	Н	D	W1	H1	S 1
mm	255	403.8	168.0	226.0	384	8.5
inch	10.04	15.90	6.61	8.90	15.12	0.33

2 Servo oil pump: HSP-064-230-43C



component	model number	Quantity
Motor	MSJ-OR202DE42C	1
Oil pump	HSP-064-230-43C	1


3 Accessory Kit: HESP-160-H-NC43

component	model number	Quantity
Braking resistor	MHR1K0W014 (MH1000W)	1
Pressure sensor: WIKA A-10	Non Add	1
Magnetic ring of power cable		3
Sensor clamp		1

Note: An encoder cable (model number: CBHE-E5M) is in the HSP Servo oil pump packaging




4 Braking resistor: MHR1K0W014 (MH1000W)



TYPE	L1 ± 2	L2 ± 2	W ± 0.5	H ± 0.5
MH 1000 W	400	385	100	50


13. HES200H43C



Unit: mm[inch]

Frame		W	Н	D	W1	H1	S 1
	mm	255	403.8	168.0	226.0	384	8.5
	inch	10.04	15.90	6.61	8.90	15.12	0.33

2 Servo oil pump: HSP-080-250-43C



component	model number	Quantity
Motor	MSJ-LR202FE42C	1
Oil pump	HSP-080-250-43C	1


3 Accessory Kit: HESP-200-H-NC43

component	model number	Quantity
Braking resistor	MHR1K0W014 (MH1000W)	1
Pressure sensor: WIKA A-10	No. (A.S.)	1
Magnetic ring of power cable		3
Sensor clamp		1

Note: An encoder cable (model number: CBHE-E5M) is in the HSP Servo oil pump packaging




4 Braking resistor: MHR1K0W014 (MH1000W)



TYPE	L1 ± 2	L2 ± 2	W ± 0.5	H ± 0.5
MH 1000 W	400	385	100	50


14. HES250M43C



Unit: mm[inch]

Fr	ame	W	Н	D	W1	H1	H2	D1	D2	S1	S2	S 3
E2	mm	370.0	595.0	260.0	335.0	589.0	560.0	132.5	18.0	13.0	13.0	18.0
CZ	inch	14.57	23.43	10.24	13.19	23.1	22.05	5.22	0.71	0.51	0.51	0.71

2 Servo oil pump: HSP-125-450-43C




component	model number	Quantity
Motor	MSJ-OR264FE48C	1
Oil pump	HSP-125-450-43C	1

3 Accessory Kit: HESP-250-M-BC43


component	model number	Quantity
Braking resistor	MHR1K5W013 (MH1500W)	1
Braking resistor	ALANCIA TOTAL	1
Pressure sensor: WIKA A-10	Man A C	1
Magnetic ring of power cable		3
Sensor clamp		1
Casing tube		1

Note: An encoder cable (model number: CBHE-E5M) is in the HSP Servo oil pump packaging







15. HES320M43C



Unit: mm[inch]

Fr	ame	w	Н	D	W1	H1	H2	D1	D2	S1	S2	S 3
E2	mm	370.0	595.0	260.0	335.0	589.0	560.0	132.5	18.0	13.0	13.0	18.0
	inch	14.57	23.43	10.24	13.19	23.1	22.05	5.22	0.71	0.51	0.51	0.71






3 Accessory Kit: HESP-320-M-BC43

component	model number	Quantity
Braking resistor	MHR1K5W013 (MH1500W)	1
Braking resistor	ALANCIA TOTAL TOTA	1
Pressure sensor: WIKA A-10		1
Magnetic ring of power cable		3
Sensor clamp		1
Casing tube		1


Note: An encoder cable (model number: CBHE-E5M) is in the HSP Servo oil pump packaging







16. HES063M43C

1 Servo controller: VFD150VL43B06MC W W1










Unit: mm[inch]

Frame		W	Н	D	W1	H1	S 1
	mm	235	350	146	204	337	6.5
	inch	9.25	13.78	5.75	8.03	13.27	0.26

2 Servo oil pump: HSP-032-100-43C



component	model number	Quantity
Motor	MSJ-IR201AE42C	1
Oil pump	HSP-032-100-43C	1

3 Accessory Kit: HESP-063-M-NC43


component	model number	Quantity
Braking resistor	BR300W025 (MH300W)	1
Pressure sensor: WIKA A-10	Em AS	1
Magnetic ring of power cable		1
Sensor clamp		1
Casing tube		1

Note: An encoder cable (model number: CBHE-E5M) is in the HSP Servo oil pump packaging



4: Braking resistor: BR300W025 (MH300W)


(Unit: min)





TYPE	L1 ± 2	L2 ± 2	W ± 0.5	H ± 0.5
MH 300 W	215	200	60	30

17. HES080M43C

1 Servo controller: VFD185VL43B08MC W W1










Unit: mm[inch]

Frame	W	Н	D	W1	H1	S1
mm	235	350	146	204	337	6.5
inch	9.25	13.78	5.75	8.03	13.27	0.26

2 Servo oil pump: HSP-040-100-43C



component	model number	Quantity
Motor	MSJ-IR201AE42C	1
Oil pump	HSP-040-100-43C	1

3 Accessory Kit: HESP-080-M-NC43


component	model number	Quantity
Braking resistor	BR300W025 (MH300W)	1
Pressure sensor: WIKA A-10	Em A2	1
Magnetic ring of power cable		1
Sensor clamp		1
Casing tube		1

Note: An encoder cable (model number: CBHE-E5M) is in the HSP Servo oil pump packaging




4: Braking resistor: BR300W025 (MH300W)

(Unit : min)



TYPE	L1 ± 2	L2 ± 2	W ± 0.5	H ± 0.5
MH 300 W	215	200	60	30


18. HES100M43C



Unit: mm [inch]

ı	Frame	W	Н	D	W1	H1	S1
_	mm	255	403.8	168.0	226.0	384	8.5
ا	inch	10.04	15.90	6.61	8.90	15.12	0.33

2 Servo oil pump: HSP-050-140-43C



component	model number	Quantity
Motor	MSJ-IR201EE42C	1
Oil pump	HSP-050-140-43C	1


3 Accessory Kit: HESP-100-M-NC43

component	model number	Quantity
Braking resistor	BR1K0W025 (MH1000W)	1
Pressure sensor: WIKA A-10	Em AS	1
Magnetic ring of power cable		1
Sensor clamp		1
Casing tube		1

Note: An encoder cable (model number: CBHE-E5M) is in the HSP Servo oil pump packaging




4: Braking resistor: BR1K0W025 (MH1000W):



TYPE	L1 ± 2	1.2 ± 2	W ± 0.5	H ± 0.5
MH 1000 W	400	385	100	50


19. HES125M43C



Unit: mm[inch]

Frame	W	Н	D	W1	H1	S 1
mm	255	403.8	168.0	226.0	384	8.5
inch	10.04	15.90	6.61	8.90	15.12	0.33

2 Servo oil pump: HSP-064-180-43C



component	model number	Quantity
Motor	MSJ-IR201IE42C	1
Oil pump	HSP-064-180-43C	1

3 Accessory Kit: HESP-125-M-NC43


component	model number	Quantity
Braking resistor	MHR1K0W014 (MH1000W)	1
Pressure sensor: WIKA A-10		1
Magnetic ring of power cable		3
Sensor clamp		1
casing tube		1

Note: An encoder cable (model number: CBHE-E5M) is in the HSP Servo oil pump packaging



4: Braking resistor: MHR1K0W014 (MH1000W)


(Unit : min)



TYPE	L1 ± 2	L2 ± 2	W ± 0.5	H ± 0.5
MH 1000 W	400	385	100	50

20. HES160M43C


1 Servo controller: VFD300VL43B16MC



Unit: mm[inch]

Frame		W	Н	D	W1	H1	S1
	mm	255	403.8	168.0	226.0	384	8.5
	inch	10.04	15.90	6.61	8.90	15.12	0.33

2 Servo oil pump: HSP-080-230-43C



component	model number	Quantity
Motor	MSJ-OR202DE42C	1
Oil pump	HSP-080-230-43C	1

3 Accessory Kit: HESP-160-M-NC43


component	model number	Quantity
Braking resistor	MHR1K0W014 (MH1000W)	1
Pressure sensor: WIKA A-10	100 AM	1
Magnetic ring of power cable		3
Sensor clamp		1
Casing tube		1

Note: An encoder cable (model number: CBHE-E5M) is in the HSP Servo oil pump packaging



4: Braking resistor: MHR1K0W014 (MH1000W):


(Unit : min)





TYPE	L1 ± 2	L2 ± 2	W ± 0.5	H ± 0.5
MH 300 W	215	200	60	30

21. HES200M43C

1 Servo controller: VFD370VL43B20MC








Unit: mm[inch]

框號	W	W1	Н	H1	H2	Н3	D	D1*	D2	S1	S2	Ø1	Ø2	Ø3
E0	280.0			500.0		442.0						62.7	34.0	22.0
EU	[11.02]	[9.25]	[20.31]	[19.69]	[18.70]	[17.40]	[9.91]	[3.71]	[0.63]	[0.43]	[0.71]	[2.47]	[1.34]	[0.87]

2 Servo oil pump: HSP-100-250-43C



component	model number	Quantity
Motor	MSJ-LR202FE42C	1
Oil pump	HSP-100-250-43C	1

3 Accessory Kit: HESP-200-MBC43


component	model number	Quantity
Braking resistor	MHR1K0W014 (MH1000W)	1
Pressure sensor: WIKA A-10	Mana A.S.	1
Magnetic ring of power cable		3
Sensor clamp		1
Casing tube		1

Note: An encoder cable (model number: CBHE-E5M) is in the HSP Servo oil pump packaging




4: Braking resistor: MHR1K0W014 (MH1000W)

(Unit : min)



TYPE	L1 ± 2	L2 ± 2	W ± 0.5	H ± 0.5
MH 300 W	215	200	60	30



Unit: mm[inch]

HESmodel	Α	В	С	D	Е	F	G	Н	H1	W	W1	Oil Inlet	Oil Outlet
number													
HES063H23C	695	381		194									3/4" PT
HES080H23C	741	417		219									3/4 F1
HES100H23C	752	417	170	219								1-1/4" PT	1" PT
HES125H23C	802	453		259			95		154				1 61
HES160H23C	859	489		304								2" PT	1" PT
HES200H23C	956	575	200	399			100		314			2-1/2" PT	1-1/4" PT
HES250G23C	972	575	200	399					314			Z-1/Z F1	1-1/4 F1
HES063H43C	695	381		194									3/4" PT
HES080H43C	705	381		194									3/4 F1
HES100H43C	752	417	170	219	340	340 400	95	376		314	180	1-1/4" PT	
HES125H43C	802	453		259	340	400				314	100		1"PT
HES160H43C	859	489		304									
HES200H43C	956	575	200	399			100		154			2" PT	1-1/4" PT
HES063M43C	705	381		194									3/4" PT
HES080M43C	716	381	170	194									
HES100M43C	766	417	170	219			95					1-1/4" PT	1" PT
HES125M43C	823	453		259									
HES160M43C	870	489	200	324			100					2" PT	1-1/4" PT
HES200M43C	972	575	200	399			100					2-1/2" PT	1-1/4 P1
HES250M43C	1028	577	230	275	420	500	140	458	184	426	250	2-1/2"PT	1-1/2"PT
HES320M43C	1098	631	230	327	420	500	140	456	104	420	200	3"PT	1-1/2 F1

Appendix B: Optional Accessories

- B-1 Non-fuse Circuit Breaker Chart
- **B-2** Reactor
- B-3 Digital Keypad KPV-CE01
- **B-4** Communication Card
- B-5 EMI Filter
- B-6 Brake Unit



- ☑ This AC motor drive has gone through rigorous quality control tests at the factory before shipment. If the package is damaged during shipping, please contact your dealer.
- ☑ All accessories manufactured by us are to be used exclusively in the Hybrid Servo Controllers made by us. Please do not purchase accessories with unknown manufacturing information and use them on our Hybrid Servo Controllers to avoid the risk of malfunction.

B-1 Non-fuse Circuit Breaker Chart

UL certification: Per UL 508, paragraph 45.8.4, part a.

The rated current of the breaker shall be within 2 to 4 times rated input current of hybrid servo Controller.

Hybrid Servo Controller.

3-phase									
Model Number	Recommended								
	Input Current (A)								
VFD055VL23A-J	50								
VFD055VL43A-J	30								
VFD075VL23A-J	60								
VFD075VL43A-J	40								
VFD110VL23A-J	100								
VFD110VL43A-J	50								
VFD150VL23A-J	125								
VFD150VL43A-J	60								
VFD185VL23A-J	150								
VFD185VL43A-J	75								

3-phase									
Model Number	Recommended Input Current (A)								
VFD220VL23A-J	175								
VFD220VL43A-J	100								
VFD300VL23A-J	225								
VFD300VL43A-J	125								
VFD370VL23A-J	250								
VFD370VL43A-J	150								
VFD450VL43A-J	175								
VFD550VL43A-J	250								
VFD750VL43A-J	300								

Fuses of smaller amp rating than those shown in the table are allowed.

230V Model	Innut Current I (A)	Line Fuse		
Number	Input Current I (A)	I (A)	Bussmann P/N	
VFD055VL23A-J	25	50	JJN-50	
VFD075VL23A-J	31	60	JJN-60	
VFD110VL23A-J	47	100	JJN-100	
VFD150VL23A-J	60	125	JJN-125	
VFD185VL23A-J	80	150	JJN-150	
VFD220VL23A-J	90	175	JJN-175	
VFD300VL23A-J	106	225	JJN-225	
VFD370VL23A-J	126	250	JJN-250	

460V Model	Input Current L (A)	Line Fuse		
Number	Input Current I (A)	I (A)	Bussmann P/N	
VFD055VL43A-J	14	30	JJN-30	
VFD075VL43A-J	18	40	JJN-40	
VFD110VL43A-J	24	50	JJN-50	
VFD150VL43A-J	31	60	JJN-60	
VFD185VL43A-J	39	75	JJN-70	
VFD220VL43A-J	47	100	JJN-100	
VFD300VL43A-J	56	125	JJN-125	
VFD370VL43A-J	67	150	JJN-150	
VFD450VL43A-J	87	175	JJN-175	
VFD550VL43A-J	101	250	JJN-250	
VFD750VL43A-J	122	300	JJN-300	

B-2 Reactor

B-2-1 AC Input Reactor

230V, 50/60Hz, 3-phase

kW	HP	Rated Amps of AC Reactors Max. Continuous A	Max. Continuous Amps		
		(A)	of AC Reactors (A)	3% Impedance	5% Impedance
5.5	7.5	25	37.5	0.5	1.2
7.5	10	35	52.5	0.4	0.8
11	15	55	82.5	0.25	0.5
15	20	80	120	0.2	0.4
18.5	25	80	120	0.2	0.4
22	30	100	150	0.15	0.3
30	40	130	195	0.1	0.2
37	50	160	240	0.075	0.15

460V, 50/60Hz, 3-phase

-400 V, 30/001 IZ, 0-pilase						
kW	HP	Rated Amps of AC Reactors	Max. Continuous Amps	Inductance (mh)		
		(A)	of AC Reactors (A)	3% Impedance	5% Impedance	
5.5	7.5	12	18	2.5	4.2	
7.5	10	18	27	1.5	2.5	
11	15	25	37.5	1.2	2	
15	20	35	52.5	8.0	1.2	
18.5	25	35	52.5	8.0	1.2	
22	30	45	67.5	0.7	1.2	
30	40	55	82.5	0.5	0.85	
37	50	80	120	0.4	0.7	
45	60	80	120	0.4	0.7	
55	75	100	150	0.3	0.45	
75	100	130	195	0.2	0.3	

AC Output Reactor Specifications

230V, 50/60Hz, 3-phase

kW	HP	Rated Amps of AC Reactors	Max. Continuous Amps	Inductance (mh)		
NVV	'"	(A)	of AC Reactors (A)	3% Impedance		
5.5	7.5	25	37.5	0.5	1.2	
7.5	10	35	52.5	0.4	0.8	
11	15	55	82.5	0.25	0.5	
15	20	80	120	0.2	0.4	
18.5	25	80	120	0.2	0.4	
22	30	100	150	0.15	0.3	
30	40	130	195	0.1	0.2	
37	50	160	240	0.075	0.15	

460V, 50/60Hz, 3-phase

kW	HP Rated Amps of AC Reactors		Max. Continuous Amps	Inductance (mh)		
KVV	1115	(A)	(A) of AC Reactors (A) 3°			
5.5	7.5	18	27	1.5	2.5	
7.5	10	18	27	1.5	2.5	
11	15	25	37.5	1.2	2	
15	20	35	52.5	8.0	1.2	
18.5	25	45	67.5	0.7	1.2	
22	30	45	67.5	0.7	1.2	
30	40	80	120	0.4	0.7	
37	50	80	120	0.4	0.7	
45	60	100	150	0.3	0.45	
55	75	130	195	0.2	0.3	
75	100	160	240	0.15	0.23	

Applications for AC Reactor

Connected in input circuit


Application 1

When more than one drive is connected to the same power, one of them is ON during operation.

Question

When applying to one of the Hybrid Servo Controller, the charge current of capacity may cause voltage ripple. The Hybrid Servo Controller may damage when over current occurs during operation.

Correct wiring




Application 2

Silicon rectifier and Hybrid Servo Controller are connected to the same power.

Question

Surges will be generated at the instant of silicon rectifier switching on/off. These surges may damage the mains circuit.

Correct wiring



Application 3

Used to improve the input power factor, to reduce harmonics and provide protection from AC line disturbances $_{\bar{z}}$ (Surges, switching spikes, short interruptions, etc.). AC line reactor should be installed when the power supply capacity is 500kVA or more and exceeds 6 times the inverter capacity, or the mains wiring distance \leq 10m.

Question


When power capacity is too large, line impedance will be small and the charge current will be too large. That may damage Hybrid Servo Controller due to higher rectifier temperature.

Correct wiring



B-2-2 Zero Phase Reactor

RF220X00A UNIT: mm (inch)



Cable type			ended (mm²)	Qty.	Wiring
(Note)	AWG	mm ²	Nominal (mm²)		Method
Single-	≤10	≤5.3	≤5.5	1	Figure A
core	≤2	≤33.6	≤38	3	Figure B
	≤12	≤3.3	≤3.5	1	Figure A
Three- core	≤1	≤42.4	≤50	3	Figure B



600V insulated power cable

- The above table is for reference only. Please choose cables with suitable types and diameters, so that the cable must be of the right size to pass through the center of the reactor.
- Please do not cross the ground wire. Only the motor wire or the power cable is to be threaded.
- When long motor output cable I used, the zero-phase reactor may be needed to minimize the effect of radiation.

Figure A

Each wire must be wrapped at least three times when it threads the zero phase reactor, with the reactor placed as close to the Hybrid Servo Controller as possible.





Figure B

Please thread the wire directly through the three zero phase reactors aligned in parallel.



B-2-3 DC Reactor

230V DC Choke

Input Voltage	kW	HP	DC Amps	Inductance (mh)
	5.5	7.5	32	0.85
	7.5	10	40	0.75
2201/	11	15	62	Built-in
230V _{AC} 50/60Hz	15	20	92	Built-in
3-Phase	18.5	25	110	Built-in
3-Filase	22	30	125	Built-in
	30	40	-	Built-in
	37	50	-	Built-in


460V DC Choke

Input Voltage	kW	HP	DC Amps	Inductance (mh)
	5.5	7.5	18	3.75
	7.5	10	25	4.00
	11	15	32	Built-in
	15	20	50	Built-in
460V _{AC}	18.5	25	62	Built-in
50/60Hz	22	30	80	Built-in
3-Phase	30	40	92	Built-in
	37	50	110	Built-in
	45	60	125	Built-in
	55	75	200	Built-in
	75	100	240	Built-in

B-3 Digital Keypad KPV-CE01


The digital keypad is the display of VFD-VJ series. The following keypad appearance is only for reference. See the product for actual appearance.

Description of the Digital Keypad KPV-CE01




Display Message	Description
⁶ 8000	Displays the drive Master frequency.
H 5000	Displays the actual output frequency present at terminals U/T1, V/T2, and W/T3.
u 18000	User defined unit (where U = F x Pr00-06)
8 <u>5.0</u>	Displays the load current
c 20	The counter value (C).
0 (-00	Displays the selected parameter.
	Displays the actual stored value of the selected parameter.
88	External Fault.
-End-	Display "End" for approximately 1 second if input has been accepted. After a parameter value has been set, the new value is automatically stored in memory.
-6	Display "Err", if the input is invalid.

How to Operate the Digital Keypad KPV-CE01




To copy parameters 1

Copy parameters from the Drive to the KPV-CE01




To copy parameters 2


Copy parameters from the KPV-CE01 to the Drive




Dimension of the Digital Keypad (KPV-CE01)

Unit: mm [inch]







Reference Table for the LCD Display of the Digital Keypad

1 (CICICIIO	o labic	, 101 (11)		Diopidy	01 1110	Digital	rtoypa	G		
Number	0	1	2	3	4	5	6	7	8	9
LCD		!	2	3	4	5	8	7	8	9
English Alphabet	Α	b	Сс	d	E	F	G	Hh	I	Jj
LCD	R	6	$\mathcal{L}_{\mathcal{L}}$	ď	E	F	5	X X	;	ر ن
English Alphabet	К	L	n	Oo	Р	q	r	S	Tt	U
LCD	H	L	n	00	P	9		5	75	IJ
English Alphabet	V	Υ	Z							
LCD	U	3	-							

B-4 Communication Card

EMVJ-MF01



Terminal	Description			
	Ground			
SG-	DC 405 composition points			
SG+	RS485 connection points			
GND	Common Signal Terminal			
POWER	Power Light			
Tx	When the light is on, it is set as master			
Rx	When the light is on, a message sent from the master is received			

NOTE

- 1) Use shielded twisted-pair cables for wiring to prevent voltage coupling and eliminate electrical noise and interference.
- 2) The shield of shielded twisted-pair cables should be connected to the SHIELD end =.

B-5 EMI Filter

Driver	Filter Model No.	Web link of references
VFD150VL43A	KMF336A	http://www.dem-uk.com/roxburgh/products/emc_emi_industrial_filters/
VI D 130 V L 43A		KMF336A Three Phase Industrial Mains Filters - High Performance 36 Amps
VFD110VL23A	LANGOGOA	http://www.dem-uk.com/roxburgh/products/emc_emi_industrial_filters/
VFD185VL43A VFD220VL43A	KMF350A	KMF350 Three Phase Industrial Mains Filters - General Purpose 50 Amps
VFD150VL23A		http://www.dem-uk.com/roxburgh/products/emc_emi_industrial_filters/
VFD300VL43A VFD370VL43A	KMF370A	KMF370A Three Phase Industrial Mains Filters - High Performance 70 Amps
VFD185VL23A	KMF3100A	http://www.dem-uk.com/roxburgh/products/emc_emi_industrial_filters/
VFD220VL23A	RIVIESTOUA	KMF3100A Three Phase Industrial Mains Filters - High Performance 100 Amps
VFD300VL23A	LANGUAGOA	http://www.dem-uk.com/roxburgh/products/emc_emi_industrial_filters/
VFD370VL23A KMF3150A VFD550VL43A		KMF3150A Three Phase Industrial Mains Filters - High Performance 150 Amps
VFD110VL43A	KMF325A	http://www.dem-uk.com/roxburgh/products/emc emi industrial filters/
VI DI IUVL43A		KMF325A Three Phase Industrial Mains Filters - High Performance 25 Amps

EMI Filter Installation

All electrical equipment, including drives, will generate high-frequency/low-frequency noise and will interfere with peripheral equipment by radiation or conduction when in operation. By using an EMI filter with correct installation, much interference can be eliminated. It is recommended to use DELTA EMI filter to have the best interference elimination performance.

We assure that it can comply with following rules when drive and EMI filter are installed and wired according to user manual:

- 1. EN61000-6-4
- 2. EN61800-3: 1996
- 3. EN55011 (1991) Class A Group 1

General precaution

- 1. EMI filter and drive should be installed on the same metal plate. It is recommended to install the drive on the filter.
- 2. Please wire as short as possible. Metal plate should be grounded. The cover of EMI filter and drive or grounding should be fixed on the metal plate and the contact area should be as large as possible.

Choose suitable motor cable and precautions

Improper installation and choice of motor cable will affect the performance of EMI filter. Be sure to observe the following precautions when selecting motor cable.

- 1. Use the cable with shielding (double shielding is the best). The shielding on both ends of the motor cable should be grounded with the minimum length and maximum contact area.
- 2. Remove any paint on metal saddle for good ground contact with the plate and shielding as shown in figure 1.
- 3. The shielding net of motor cable and the plate must be connected correctly. The shielding net on the two ends of motor cable should be fixes by the metal saddle and the plate. See figure 2 for correct connection.

Protective coating required at contacts between brackets and metal plates to ensure good contact.




Figure 1




Figure 2

The length of motor cable

When motor is driven by a drive of PWM type, the motor terminals will experience surge voltages easily due to components conversion of drive and cable capacitance. When the motor cable is very long (especially for the 460V series), surge voltages may reduce insulation quality. To prevent this situation, please follow the rules below:

Use a motor with enhanced insulation. Connect an output reactor (optional) to the output terminals of the drive. The length of the cable between drive and motor should be as short as possible (10 to 20 m or less).

For models 7.5hp/5.5kW and above:

Insulation level of motor	1000V	1300V	1600V
460Vac input voltage	66 ft (20m)	328 ft (100m)	1312 ft (400m)
230Vac input voltage	1312 ft (400m)	1312 ft (400m)	1312 ft (400m)

If the length is too long, the stray capacitance between cables will increase and may cause leakage current. It will activate the protection of over current, increase leakage current or not insure the correction of current display. The worst case is that drive may damage.


To drive the 460V series motor, if there is one relay installed between the Hybrid Servo Controller and motor to protect the motor from over-heating, the relay might malfunction even if the length of the wire is below 50 meters. Thus, a filter for output current shall be added (optional for purchase).


NOTE:

- When a thermal O/L relay protected by motor is used between Hybrid Servo Controller and motor, it may malfunction (especially for 460V series), even if the length of motor cable is only 165 ft (50m) or less. To prevent it, please use a filter.
- Never connect phase lead capacitors or surge absorbers to the output terminals of the Hybrid Servo Controller.

B-6 Brake Unit


Individual Parts and Function Explanation





Input voltage setting for VFDB-2015/2022/4030/4045

Wiring of brake unit and motor drive:



The Voltage Settings

1. Adjust Voltage: The + (P) and - (N) sides of the hydraulic servo motor controller are the DC power source of the control unit. Therefore, after wiring and before operation, it is very important to set the voltage of the control unit according to the input voltage of the hydraulic servo motor controller. This setting will affect the state of activation voltage of the control unit. The following table shows the state address of individual voltage actions.

Voltage: 230 VAC	Braking Start-up voltage DC Bus (+(P), -(N)) Voltage	Voltage: 230 VAC	Braking Start-up voltage DC Bus (+(P), -(N)) Voltage
190Vac	330Vdc	380Vac	660Vdc
200Vac	345Vdc	400Vac	690Vdc
210Vac	360Vdc	415Vac	720Vdc
220Vac	380Vdc	440Vac	760Vdc
230Vac	400Vdc	460Vac	800Vdc
240Vac	415Vdc	480Vac	830Vdc

Table 1: The Selection of Power Voltage and Operation Potential of PN DC Voltage

Terminal Wire Gauge

Circuit	Terminal Mark	Wire Gauge AWG (mm ²)	Screw	Torque
Power Input Circuit	+ (P) \ - (N)	10~12AWG (3.5~5.5mm ²)	M4	18 kgf-cm (15.6 in-lbf)
Braking Resistor	B1 · B2	10~12AWG (3.5~5.5mm ²)	M4	18 kgf-cm (15.6 in-lbf)
SLAVE Circuit	Output M1 · M2 Input S1 · S2	20~18AWG (0.25~0.75mm²) (with shielded wires)	M2	4 kgf-cm (3 in-lbf)
Fault Circuit	RA · RB · RC	20~18AWG (0.25~0.75mm ²)	M2	4 kgf-cm (3 in-lbf)

Specifications

Specific	auons				
Voltage Class		230V Series		460V Series	
Model VFDB-		2022		4045	
Max. Motor Capacity (kW)		22		45	
Output Rating	Max. Discharge Current (A) 10%ED	60		60	
	Continuous Discharge Current (A)	20		18	
	Braking Start-up Voltage (DC)	330/345/360/380/ 400/415±3V		660/690/720/760/ 800/830±6V	
Input Rating	DC Voltage	200 ~400VDC		400 ~800VDC	
Min. Equivalent Resistor for Each Braking Unit		10Ω	6.8Ω	20Ω	13.6Ω
Protection	Heat Sink Overheat	Temperature over +95°C (203°F)			
	Alarm Output	Relay contact 5A120Vac/28Vdc(RA.RB.RC)			
	Power Charge Display	Blackout until bus (+~-) voltage is below 50VDC			
Environment	Installation Location	Indoor (no corrosive gases, metallic dust)			
	Operating Temperature	-10°C ~+50°C (14°F to 122°F)			
	Storage Temperature	-20°C ~+60°C (-4°F to 140°F)			
	Humidity	90% Non-condensing			
	Vibration	20Hz 以下 9.8m/S²(1G)、20~50Hz 2m/S²(0.2G)			
Mechanical Configuration		Wall-mounted enclosed type IP50			